

# Sangoma P Codes

## Overview

Sangoma phone configs use "P Codes" or Programming Codes. Each P Code is assigned a number. The configs then use a standard XML layout, ie: <pcode>value</pcode>. Below is a list of all P Codes, the value that Endpoint Manager sets by default, and the description of the P Code including possible settings.

## Sangoma Phone P Codes

P271

EPM Default Value: \_\_line1Enable\_\_

Description: Account Active (In Use). 0 - No, 1 - Yes

P47

EPM Default Value: \_\_line1Dest\_\_:\_\_line1ServerPort\_\_

Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P4567

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P130

EPM Default Value: \_\_transport1\_\_

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P52

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P35

EPM Default Value: \_\_line1Ext\_\_

Description: SIP User ID

P36

EPM Default Value: \_\_line1Ext\_\_

Description: Authenticate ID

P34

EPM Default Value: \_\_line1Pass\_\_

Description: Authenticate password

P3

EPM Default Value: \_\_line1Name\_\_

Description: Name

P103

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P63

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P31

EPM Default Value: \_\_line1Enable\_\_

Description: SIP Registration. 0 - No, 1 - Yes

P81

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P32

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P109  
EPM Default Value: 1  
Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P78  
EPM Default Value: 0  
Description: Use Random Port.0 - No, 1 - Yes

P33  
EPM Default Value: \_\_voicemail\_\_  
Description: Voice Mail UserID(UserID for voice mail system)

P57  
EPM Default Value: \_\_line1Codec1\_\_  
Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P58  
EPM Default Value: \_\_line1Codec2\_\_  
Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P59  
EPM Default Value: \_\_line1Codec3\_\_  
Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P60  
EPM Default Value: \_\_line1Codec4\_\_  
Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P61  
EPM Default Value: \_\_line1Codec5\_\_  
Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P62  
EPM Default Value: \_\_line1Codec6\_\_  
Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P37  
EPM Default Value: 2  
Description: Voice Frames Per TX

P49  
EPM Default Value: 0  
Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P79  
EPM Default Value: 101  
Description: DTMF Payload Type

P74  
EPM Default Value: 0  
Description: Send Flash Event.0 - no, 1 - yes

P191  
EPM Default Value: 0  
Description: Enable Call Features.0 - no, 1 - yes

P197  
EPM Default Value:  
Description: Proxy Require

P101  
EPM Default Value:  
Description: Use NAT IP(use in SIP/SDP message if specified)

P183  
EPM Default Value: \_\_srtpMode1\_\_  
Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P50  
EPM Default Value: 0  
Description: VAD.0 - no, 1 - yes

P291

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P133

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P132

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P104

EPM Default Value: \_\_ringtone\_\_

Description: Account Ring Tone

P185

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P72

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4200

EPM Default Value: \_\_dialpattern\_\_

Description: Dial Plan (dial plan prefix string).

P99

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P65

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P129

EPM Default Value: \_\_acr\_\_

Description: Anonymous Call Rejection.0 - no, 1 - yes

P258

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P90

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P298

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P299

EPM Default Value: \_\_remoteDisconnect\_\_

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P260

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P261

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P262

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P263

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P264  
EPM Default Value: 0  
Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P266  
EPM Default Value: 0  
Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P267  
EPM Default Value: 1  
Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P265  
EPM Default Value: 0  
Description: Force INVITE (Always refresh with INVITE instead of UPDATE ) 0 - No, 1 - Yes

P251  
EPM Default Value: 30  
Description: Hook Flash Timing

P252  
EPM Default Value: 100  
Description: Hook Flash Timing

P198  
EPM Default Value: 100  
Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P134  
EPM Default Value:  
Description: Eventlist BLF URL

P8771  
EPM Default Value: 0  
Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8791  
EPM Default Value: 0  
Description: SIP Server Type

P8811  
EPM Default Value: 0  
Description: 100 reliable retransmission

P8841  
EPM Default Value: 0  
Description: Early-Session 0 - Disable, 1 - Enable

P4705  
EPM Default Value: \_\_directedCallPickup\_\_  
Description: Direct Call Pickup Code

P4706  
EPM Default Value:  
Description: Group Call Pickup Code

P401  
EPM Default Value: \_\_line2Enable\_\_  
Description: Account Active (In Use). 0 - No, 1 - Yes

P747  
EPM Default Value: \_\_line2Dest\_\_:\_\_line2ServerPort\_\_  
Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P987  
EPM Default Value:  
Description: Failover SIP Server(Optional, used when primary server no response)

P4568  
EPM Default Value: 0  
Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P748

EPM Default Value:

Description: Outbound Proxy(proxy.myprovider.com, or IP address, if any)

P830

EPM Default Value: \_\_transport2\_\_

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P730

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P735

EPM Default Value: \_\_line2Ext\_\_

Description: SIP User ID

P736

EPM Default Value: \_\_line2Ext\_\_

Description: Authenticate ID

P734

EPM Default Value: \_\_line2Pass\_\_

Description: Authenticate password

P703

EPM Default Value: \_\_line2Name\_\_

Description: Name

P702

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P763

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P731

EPM Default Value: \_\_line2Enable\_\_

Description: SIP Registration. 0 - No, 1 - Yes

P752

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P732

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P813

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P778

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P426

EPM Default Value: \_\_line2Ext\_\_

Description: Voice Mail UserID(UserID for voice mail system)

P757

EPM Default Value: \_\_line2Codec1\_\_

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P758

EPM Default Value: \_\_line2Codec2\_\_

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P759

EPM Default Value: \_\_line2Codec3\_\_

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P760

EPM Default Value: \_\_line2Codec4\_\_

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P761

EPM Default Value: \_\_line2Codec5\_\_

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P762

EPM Default Value: \_\_line2Codec6\_\_

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P737

EPM Default Value: 2

Description: Voice Frames Per TX

P749

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P779

EPM Default Value: 101

Description: DTMF Payload Type

P774

EPM Default Value: 0

Description: Send Flash Event.0 - no, 1 - yes

P151

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P866

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P443

EPM Default Value: \_\_srtpMode2\_\_

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P750

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P460

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P831

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P832

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P423

EPM Default Value: \_\_ringtone\_\_

Description: Account Ring Tone

P816

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P772

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4201

EPM Default Value: \_\_dialpattern\_\_

Description: Dial Plan (dial plan prefix string).

P709

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P421

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P446

EPM Default Value: \_\_acr\_\_

Description: Anonymous Call Rejection.0 - no, 1 - yes

P458

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P425

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P438

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P439

EPM Default Value: \_\_remoteDisconnect\_\_

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P434

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P427

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P428

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P429

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P430

EPM Default Value: 0

Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P432

EPM Default Value: 0

Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P433

EPM Default Value: 1

Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P431

EPM Default Value: 0

Description: Force INVITE (Always refresh with INVITE instead of UPDATE ) 0 - No, 1 - Yes

P811

EPM Default Value: 30

Description: Hook Flash Timing

P812

EPM Default Value: 100

Description: Hook Flash Timing

P767

EPM Default Value: 100

Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P444

EPM Default Value:

Description: Eventlist BLF URL

P8772

EPM Default Value: 0

Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8792

EPM Default Value: 0

Description: SIP Server Type

P8812

EPM Default Value: 0

Description: 100 reliable retransmission

P8842

EPM Default Value: 0

Description: Early-Session 0 - Disable, 1 - Enable

P4715

EPM Default Value: \_\_directedCallPickup\_\_

Description: Direct Call Pickup Code

P4716

EPM Default Value:

Description: Group Call Pickup Code

P501

EPM Default Value: \_\_line3Enable\_\_

Description: Account Active (In Use). 0 - No, 1 - Yes

P502

EPM Default Value: \_\_line3Dest\_\_:\_\_line3ServerPort\_\_

Description: Primary SIP Server(eg:[sip.mycompany.com](http://sip.mycompany.com) or IP address)

P988

EPM Default Value:

Description: Failover SIP Server(Optional, used when primary server no response)

P4569

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P503

EPM Default Value:

Description: Outbound Proxy([proxy.myprovider.com](http://proxy.myprovider.com), or IP address, if any)

P930

EPM Default Value: \_\_transport3\_\_

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P514

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P504

EPM Default Value: \_\_line3Ext\_\_

Description: SIP User ID

P505

EPM Default Value: \_\_line3Ext\_\_

Description: Authenticate ID

P506

EPM Default Value: \_\_line3Pass\_\_

Description: Authenticate password

P507

EPM Default Value: \_\_line3Name\_\_

Description: Name

P508

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P509

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes



P510

EPM Default Value: \_\_line3Enable\_\_

Description: SIP Registration. 0 - No, 1 - Yes

P511

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P512

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P913

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P578

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P526

EPM Default Value: \_\_line3Ext\_\_

Description: Voice Mail UserID(UserID for voice mail system)

P551

EPM Default Value: \_\_line3Codec1\_\_

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P552

EPM Default Value: \_\_line3Codec2\_\_

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P553

EPM Default Value: \_\_line3Codec3\_\_

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P554

EPM Default Value: \_\_line3Codec4\_\_

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P555

EPM Default Value: \_\_line3Codec5\_\_

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P556

EPM Default Value: \_\_line3Codec6\_\_

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P537

EPM Default Value: 2

Description: Voice Frames Per TX

P559

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P579

EPM Default Value: 101

Description: DTMF Payload Type

P1891

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P518

EPM Default Value:

Description: Proxy Require

P566

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P543

EPM Default Value: \_\_srtpMode3\_\_

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P550

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P591

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P1133

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P1132

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P523

EPM Default Value: \_\_ringtone\_\_

Description: Account Ring Tone

P1885

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P1672

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4202

EPM Default Value: \_\_dialpattern\_\_

Description: Dial Plan (dial plan prefix string).

P515

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P521

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P1846

EPM Default Value: \_\_acr\_\_

Description: Anonymous Call Rejection.0 - no, 1 - yes

P567

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P525

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P538

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P539

EPM Default Value: \_\_remoteDisconnect\_\_

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P534

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P527

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P528

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P529

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P530

EPM Default Value: 0

Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P532

EPM Default Value: 0

Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P533

EPM Default Value: 1

Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P531

EPM Default Value: 0

Description: Force INVITE (Always refresh with INVITE instead of UPDATE ) 0 - No, 1 - Yes

P1811

EPM Default Value: 30

Description: Hook Flash Timing

P1812

EPM Default Value: 100

Description: Hook Flash Timing

P524

EPM Default Value: 100

Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P544

EPM Default Value:

Description: Eventlist BLF URL

P8773

EPM Default Value: 0

Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8793

EPM Default Value: 0

Description: SIP Server Type

P8813

EPM Default Value: 0

Description: 100 reliable retransmission

P8843

EPM Default Value: 0

Description: Early-Session 0 - Disable, 1 - Enable

P4725

EPM Default Value: \_\_directedCallPickup\_\_

Description: Direct Call Pickup Code

P4726

EPM Default Value:

Description: Group Call Pickup Code

P601

EPM Default Value: \_\_line4Enable\_\_

Description: Account Active (In Use). 0 - No, 1 - Yes

P602

EPM Default Value: \_\_line4Dest\_\_:\_\_line4ServerPort\_\_

Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P989

EPM Default Value:

Description: Failover SIP Server(Optional, used when primary server no response)

P4570

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P603

EPM Default Value:

Description: Outbound Proxy(proxy.myprovider.com, or IP address, if any)

P1030

EPM Default Value: \_\_transport4\_\_

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P614

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P604

EPM Default Value: \_\_line4Ext\_\_

Description: SIP User ID

P605

EPM Default Value: \_\_line4Ext\_\_

Description: Authenticate ID

P606

EPM Default Value: \_\_line4Pass\_\_

Description: Authenticate password

P607

EPM Default Value: \_\_line4Name\_\_

Description: Name

P608

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P609

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P610

EPM Default Value: \_\_line4Enable\_\_

Description: SIP Registration. 0 - No, 1 - Yes

P611

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P612

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P1013

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P678

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P626

EPM Default Value: \_\_line4Ext\_\_

Description: Voice Mail UserID(UserID for voice mail system)

P651

EPM Default Value: \_\_line4Codec1\_\_

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P652

EPM Default Value: \_\_line4Codec2\_\_

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P653

EPM Default Value: \_\_line4Codec3\_\_

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P654

EPM Default Value: \_\_line4Codec4\_\_

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P655

EPM Default Value: \_\_line4Codec5\_\_

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P656

EPM Default Value: \_\_line4Codec6\_\_

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P637

EPM Default Value: 2

Description: Voice Frames Per TX

P659

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P679

EPM Default Value: 101

Description: DTMF Payload Type

P1991

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P618

EPM Default Value:

Description: Proxy Require

P666

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P643

EPM Default Value: \_\_srtpMode4\_\_

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P695

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P691

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P1233

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P1232

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P623

EPM Default Value: \_\_ringtone\_\_

Description: Account Ring Tone

P1886

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P1772

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P42033

EPM Default Value: \_\_dialpattern\_\_

Description: Dial Plan (dial plan prefix string).

P615

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P621

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P1946

EPM Default Value: \_\_acr\_\_

Description: Anonymous Call Rejection.0 - no, 1 - yes

P667

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P625

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P638

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P639

EPM Default Value: \_\_remoteDisconnect\_\_

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P634

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P627

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P628

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P629

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P630

EPM Default Value: 0

Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P632

EPM Default Value: 0

Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P633

EPM Default Value: 1

Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P631

EPM Default Value: 0

Description: Force INVITE (Always refresh with INVITE instead of UPDATE ) 0 - No, 1 - Yes

P1911

EPM Default Value: 30

Description: Hook Flash Timing

P1912

EPM Default Value: 100

Description: Hook Flash Timing

P624  
EPM Default Value: 100  
Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P644  
EPM Default Value:  
Description: Eventlist BLF URL

P8774  
EPM Default Value: 0  
Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8794  
EPM Default Value: 0  
Description: SIP Server Type

P8814  
EPM Default Value: 0  
Description: 100 reliable retransmission

P8844  
EPM Default Value: 0  
Description: Early-Session 0 - Disable, 1 - Enable

P4735  
EPM Default Value: \_\_directedCallPickup\_\_  
Description: Direct Call Pickup Code

P4736  
EPM Default Value:  
Description: Group Call Pickup Code

P8  
EPM Default Value: 0  
Description: WAN. 0 - DHCP, 1 - Static IP Address, 2 - PPPoE

P146  
EPM Default Value:  
Description: DHCP HostName, DHCP option 12. Max length allowed is 64 characters. Default value is 0.

P147  
EPM Default Value:  
Description: DHCP Domain

P148  
EPM Default Value:  
Description: DHCP Vendor Class ID, DHCP option 60. Max length allowed is 64 characters.  
Phone Default Value: udhcp 1.12.1

P149  
EPM Default Value:  
Description: DHCP User Class

P9  
EPM Default Value: 0  
Description: IP Address 1'st octet

P10  
EPM Default Value: 0  
Description: IP Address 2'nd octet

P11  
EPM Default Value: 0  
Description: IP Address 3'rd octet

P12  
EPM Default Value: 0  
Description: IP Address 4'th octet

P13  
EPM Default Value: 0  
Description: Subnet Mask 1'st octet

P14

EPM Default Value: 0  
Description: Subnet Mask 2'nd octet

P15  
EPM Default Value: 0  
Description: Subnet Mask 3'rd octet

P16  
EPM Default Value: 0  
Description: Subnet Mask 4'th octet

P17  
EPM Default Value: 0  
Description: Default Gateway 1'st octet

P18  
EPM Default Value: 0  
Description: Default Gateway 2'nd octet

P19  
EPM Default Value: 0  
Description: Default Gateway 3'rd octet

P20  
EPM Default Value: 0  
Description: Default Gateway 4'th octet

P21  
EPM Default Value: 8  
Description: Primary DNS 1'st octet

P22  
EPM Default Value: 8  
Description: Primary DNS 2'nd octet

P23  
EPM Default Value: 8  
Description: Primary DNS 3'rd octet

P24  
EPM Default Value: 8  
Description: Primary DNS 4'th octet

P25  
EPM Default Value: 8  
Description: Secondary DNS 1'st octet

P26  
EPM Default Value: 8  
Description: Secondary DNS 2'nd octet

P27  
EPM Default Value: 4  
Description: Secondary DNS 3'rd octet

P28  
EPM Default Value: 4  
Description: Secondary DNS 4'th octet

P82  
EPM Default Value:  
Description: PPPoE account ID

P83  
EPM Default Value:  
Description: PPPoE password

P269  
EPM Default Value:  
Description: PPPoE Service Name

P92  
EPM Default Value: 8  
Description: DNS Server 1'st octet



P93  
EPM Default Value: 8  
Description: DNS Server 2'nd octet

P94  
EPM Default Value: 8  
Description: DNS Server 3'rd octet

P95  
EPM Default Value: 8  
Description: DNS Server 4'th octet

P189  
EPM Default Value: 1  
Description: Reply To ICMP

P190  
EPM Default Value: 1  
Description: Http Access 0 - no, 1 - yes

P231  
EPM Default Value: \_\_pc\_port\_\_  
Description: PC Port 1 - As Bridge, 0 - as Router, 2 - as Expansion module

P111  
EPM Default Value: 192.168.66.1  
Description: IP Address

P110  
EPM Default Value: 255.255.255.0  
Description: Subnet Mask

P112  
EPM Default Value: 24  
Description: IP Lease Time

P5438  
EPM Default Value: \_\_lldp\_\_  
Description: LLDP Active 0 - Disable, 1 - Enable

P5439  
EPM Default Value: \_\_lldpPacket\_\_  
Description: Packed Interval

P38  
EPM Default Value: 48  
Description: Layer 3 QoS (Diff-Serv or Precedence value)

P51  
EPM Default Value: \_\_vVlan\_\_  
Description: Layer 2 QoS. 802.1Q/VLAN Tag (VLAN classification for RTP)

P87  
EPM Default Value: \_\_vVlanP\_\_  
Description: Layer 2 QoS. 802.1p priority value (0 - 7).

P229  
EPM Default Value: \_\_dVlan\_\_  
Description: Data VLAN Tag (vaild only when Bridge mode)

P30  
EPM Default Value: \_\_timeserver1\_\_  
Description: NTP Server

P144  
EPM Default Value: 0  
Description: Allow DHCP Option 42 To Override NTP Server 0 - no, 1 - yes

P8629  
EPM Default Value: \_\_vpnEnable\_\_  
Description: VPN Active 0 - no, 1 - yes

P901  
EPM Default Value: 80  
Description: Web Server HTTP Port

P8724

EPM Default Value: 443

Description: Web Server HTTPS Port

P8725

EPM Default Value: 1

Description: Web Server Type 0 - Disable, 1 - HTTP&HTTPS, 2 - HTTP Only, 3 - HTTPS Only

P8626

EPM Default Value: \_\_vlanMode\_\_

Description: 802.1X Mode 0 - Disable, 1 - EAP-MD5

P8627

EPM Default Value: \_\_vlanIdentity\_\_

Description: Identity

P8628

EPM Default Value: \_\_vlanPass\_\_

Description: MD5 Password

P76

EPM Default Value:

Description: STUN Server (url or ip:port)

P84

EPM Default Value: 20

Description: Keep-ative Interval(seconds default:20)

P2525

EPM Default Value: \_\_language\_\_

Description: Web Language 0 - English, 1 - Chinese

P64

EPM Default Value: \_\_timezone\_\_

Description: Time Zone

P143

EPM Default Value: 0

Description: DHCP Time 0 - no, 1 - yes

P75

EPM Default Value: \_\_daylight\_\_

Description: Daylight Saving Time 0 - no, 1 - yes

P102

EPM Default Value: \_\_dateFormat\_\_

Description: Date Display Format 0 - Year - Month - Day, 1 - Month - Day - Year, 2 - Day - Month - Year

P8624

EPM Default Value: \_\_timeFormat\_\_

Description: Time Format, 1-12 Hour,0-24 Hour

P88

EPM Default Value: 0

Description: Lock Keypad Update 0 - no, 1 - yes

P1300

EPM Default Value: \_\_keypressTone\_\_

Description: Keypad DTMF Tone 1 - no, 0 - yes

P249

EPM Default Value: 0

Description: MIC Volume Amplification 0 - 0dB default, 1 - +6dB, 2 - +4dB, 3 - +2dB, 4 - -2dB, 5 - -4dB, 6 - -6dB

P8940

EPM Default Value: \_\_screensavertimeout\_\_

Description: Screen Time Out 0 - Off, 1 - 1min, 2 - 2min, 3 - 5min, 4 - 10min, 5 - 30min

P8950

EPM Default Value: \_\_screensaver\_\_

Description: ScreenSaver Type 0 - backlight off, 0 - time & logo, 2 - photo switch

P8721

EPM Default Value: \_\_ringtone\_\_

Description: Ring Tones

P85

EPM Default Value: \_\_entryTimeout\_\_

Description: NO Key Entry Timeout(in seconds, 0 means never timeout, default is 0 seconds)

P3734

EPM Default Value: \_\_powerStatusEnable\_\_

Description: LED Status.Power Status.0 - no, 1 - yes

P3735

EPM Default Value: \_\_ringingStatusEnable\_\_

Description: LED Status.Ringing Status.0 - no, 1 - yes

P3736

EPM Default Value: \_\_misscallsStatusEnable\_\_

Description: LED Status. MissCalls Status.0 - no, 1 - yes

P53100

EPM Default Value: 0

Description: Forward--always 1 - on, 0 - off

P53101

EPM Default Value:

Description: Target(Target number for transfer)

P53102

EPM Default Value:

Description: On Code

P53103

EPM Default Value:

Description: Off Code

P53110

EPM Default Value: 0

Description: Forward--Busy 1 - on, 0 - off

P53111

EPM Default Value:

Description: Target(Target number for transfer)

P53112

EPM Default Value:

Description: On Code

P53113

EPM Default Value:

Description: Off Code

P53120

EPM Default Value: 0

Description: Forward--No Answer 1 - on, 0 - off

P53124

EPM Default Value:

Description: After Ring Time(seconds)(waiting time for NoAnswer forward)

P53121

EPM Default Value:

Description: Target(Target number for transfer)

P53122

EPM Default Value:

Description: On Code

P53123

EPM Default Value:

Description: Off Code

P53200

EPM Default Value: \_\_dndOn\_\_

Description: Do Not Disturb.DND On Code(The feature code to enable DND,the phone will send the feature code directly to open DND)

P53201

EPM Default Value: \_\_dndOff\_\_

Description: Do Not Disturb.DND Off Code(The feature code to disable DND,the phone will send the feature code directly to close DND)

P53202

EPM Default Value:

Description: Do Not Disturb.Authorized Numbers(comma separated)

P4210

EPM Default Value: \_\_hotline\_\_

Description: Hotline.Hotline Number

P8638

EPM Default Value: 0

Description: Hotline.Hotline Time-out(seconds)(0~180s)

P3201

EPM Default Value: 1

Description: Transfer Settings.Blind Transfer On Hook.0 - off, 1 - on

P3202

EPM Default Value: 1

Description: Transfer Settings.Semi-Attended Transfer.0 - off, 1 - on

P3204

EPM Default Value: 1

Description: Transfer Settings.Attended Transfer On Hook.0 - off, 1 - on

P3205

EPM Default Value: 1

Description: Transfer Settings.Transfer Mode via DSSkey 0 - Attended Transfer, 1 - Blind Transfer, 2 - New Call

P4701

EPM Default Value: 0

Description: Call Pickup.Direct Call Pickup.0 - off, 1 - on

P4745

EPM Default Value: \_\_directedCallPickup\_\_

Description: Call Pickup.Direct Call Pickup Code

P4702

EPM Default Value: 0

Description: Call Pickup.Group Call Pickup.0 - off, 1 - on

P4746

EPM Default Value:

Description: Call Pickup.Group Call Pickup Code

P4703

EPM Default Value: \_\_blfVisual\_\_

Description: Call Pickup.Visual Alert for BLF Pickup.0 - off, 1 - on

P4704

EPM Default Value: \_\_blfAudio\_\_

Description: Call Pickup.Audio Alert for BLF Pickup.0 - off, 1 - on

P8630

EPM Default Value: 0

Description: Phone Lock.Keypad Lock.0 - Disabled, 1 - All Keys, 2 - Menu Key 3 - Function Keys, 4 - Answer All Only

P5730

EPM Default Value:

Description: Phone Lock.Phone Unlock Pin(0~15digital)

P5731

EPM Default Value:

Description: Phone Lock.Auto Lock Time-Out(0~3600s)

P5732

EPM Default Value:

Description: Phone Lock.Emergency

P4000

EPM Default Value: f1=350@-13,f2=440@-13,c=0/0;

Description: Call Progress Tones.Dial Tone

P4001  
EPM Default Value: f1=440@-19,f2=480@-19,c=2000/4000;  
Description: Call Progress Tones.Ringback Tone

P4002  
EPM Default Value: f1=480@-24,f2=620@-24,c=500/500;  
Description: Call Progress Tones.Busy Tone

P4003  
EPM Default Value: f1=480@-24,f2=620@-24,c=250/250;  
Description: Call Progress Tones.Reorder Tone

P4004  
EPM Default Value: f1=350@-11,f2=440@-11,c=100/100-100/100-100/100;  
Description: Call Progress Tones.Confirmation Tone

P4005  
EPM Default Value: f1=440@-13,c=300/10000-300/10000-0/0;  
Description: Call Progress Tones.Call Waiting Tone

P58100  
EPM Default Value: 0  
Description: SMS Account.0 - Account 1, 1 - Account 2, 2 - Account 3, 3 - Account 4

P3701  
EPM Default Value:  
Description: Setup Completed(This message will be sent out when the phone is start-up completed, available for use.)

P3702  
EPM Default Value:  
Description: Registered (This message will be sent out when an account is successfully registered.)

P3703  
EPM Default Value:  
Description: Deregistered (This message will be sent out when an account is deregistered.)

P3704  
EPM Default Value:  
Description: Register Failed(This message will be sent out when an account is registered failed.)

P3705  
EPM Default Value:  
Description: Offhook(This message will be sent out when the phone is off hook.)

P3706  
EPM Default Value:  
Description: Onhook(This message will be sent out when the phone is on hook.)

P3707  
EPM Default Value:  
Description: Incoming Call(This message will be sent out when there is an incoming call.)

P3708  
EPM Default Value:  
Description: Outgoing Call(This message will be sent out when there is an outgoing call.)

P3709  
EPM Default Value:  
Description: Call Established(This message will be sent out when a call is established.)

P3710  
EPM Default Value:  
Description: Call Terminated(This message will be sent out when a call is terminated.)

P3711  
EPM Default Value:  
Description: Open DND(This message will be sent out when DND is enabled.)

P3712  
EPM Default Value:  
Description: Close DND(This message will be sent out when DND is disabled.)

P3713

EPM Default Value:

Description: Open Always Forward(This message will be sent out when always-forward is enabled.)

P3714

EPM Default Value:

Description: Close Always Forward(This message will be sent out when always-forward is disabled.)

P3715

EPM Default Value:

Description: Open Busy Forward(This message will be sent out when busy-forward is enabled.)

P3716

EPM Default Value:

Description: Close Busy Forward(This message will be sent out when busy-forward is disabled.)

P3717

EPM Default Value:

Description: Open No Busy Forward(This message will be sent out when no-answer-forward is enabled.)

P3718

EPM Default Value:

Description: Close No Busy Forward(This message will be sent out when no-answer-forward is disable.)

P3719

EPM Default Value:

Description: Transfer Call(This message will be sent out when transferring a call(including all kinds of transfer).)

P3720

EPM Default Value:

Description: Blind Transfer call(This message will be sent out when doing blind-transfer.)

P3721

EPM Default Value:

Description: Attended Transfer Call(This message will be sent out when doing attended and semi-attended transfer.)

P3722

EPM Default Value:

Description: Hold(This message will be sent out when holding a call.)

P3723

EPM Default Value:

Description: Unhold(This message will be sent out when unholding the call.)

P3724

EPM Default Value:

Description: Mute(This message will be sent out when muting a call.)

P3725

EPM Default Value:

Description: Unmute(This message will be sent out when unmuting a call.)

P3726

EPM Default Value:

Description: Missed Call(This message will be sent out when there is a new missed call even if missed call logs is disabled.)

P3727

EPM Default Value:

Description: Idle ToBusy( call logs is disabled.)

P3728

EPM Default Value:

Description: Busy To Idle( Busy to IdleBusy to Idle)

P3729

EPM Default Value:

Description: Forward Incoming Call( Forward Incoming Call)

P3730

EPM Default Value:

Description: Reject Incoming Call( Reject Incoming Call)

P3731  
EPM Default Value:  
Description: Answer New Incoming Call(Answer New Incoming Call)

P3732  
EPM Default Value:  
Description: TransferFinished(Transfer Finished)

P3733  
EPM Default Value:  
Description: Transfer Failed(Transfer Failed)

P2  
EPM Default Value: \_\_adminPass\_\_  
Description: Admin password for web interface

P212  
EPM Default Value: \_\_protocol\_\_  
Description: Firmware Upgrade Upgrade Mode.0 - TFTP, 1 - HTTP, 2 - FTP

P192  
EPM Default Value: \_\_firmware\_\_  
Description: Firmware Server Path

P237  
EPM Default Value: \_\_provisionAddress\_\_  
Description: Config Server Path

P1360  
EPM Default Value: \_\_ftpuser\_\_  
Description: HTTP/FTP/HTTPS UserName

P1361  
EPM Default Value: \_\_ftppass\_\_  
Description: HTTP/FTP/HTTPS Password

P1145  
EPM Default Value: 66  
Description: Allow DHCP Option

P145  
EPM Default Value: 0  
Description: To Override Server. 0 - no, 1 - yes

P194  
EPM Default Value: 1  
Description: AUTO Upgrade. 0 - no, 1 - yes

P193  
EPM Default Value: \_\_resync\_\_  
Description: check for upgrade every () Minutes

P238  
EPM Default Value: 0  
Description: Upgrade Check Mode 0 - Always Check For New Firmware, 1 - check new firmware only when F/W pre/suffix changes, 2 - Always Skip The Firmware Check

P240  
EPM Default Value: 0  
Description: Authenticate Cfg File 0 - no, 1 - yes

P331  
EPM Default Value:  
Description: Phonebook XML Download

P332  
EPM Default Value: 0  
Description: Phonebook Download Interval(the interval time should be 0-720 days))

P333  
EPM Default Value: 0  
Description: Remove Manually-edited Entries On Download.0 - no, 1 - yes

P330

EPM Default Value: 0

Description: Phonebook XML Download Enable.0 - no, 1 - yes,HTTP, 2 - yes,TFTP, 3 - yes,FTP

P8150

EPM Default Value: 0

Description: SNMP Service Enable.0 - no, 1 - yes

P8151

EPM Default Value:

Description: SNMP Get Community

P8152

EPM Default Value:

Description: SNMP Set Community

P8153

EPM Default Value:

Description: SNMP Manager IP 1

P8154

EPM Default Value:

Description: SNMP Manager IP 2

P8155

EPM Default Value:

Description: SNMP Manager IP 3

P8156

EPM Default Value:

Description: SNMP Manager IP 4

P207

EPM Default Value:

Description: System Log.Syslog Server

Values: Dotted IP address of server, not inclusive of port definition. Port defaults to 514 and is not configurable.

P208

EPM Default Value: 0

Description: System Log.Syslog level 0 - NONE, 1 - DEBUG, 2 - INFO, 3 - WARNING, 4 - ERROR

P41200

EPM Default Value: \_\_line1type\_\_

Description: linekey\_type\_01

P41300

EPM Default Value: \_\_line1value\_\_

Description: linekey\_value\_01

P41400

EPM Default Value: \_\_line1label\_\_

Description: linekey\_label\_01

P41500

EPM Default Value: \_\_line1acct\_\_

Description: linekey\_account\_01

P41600

EPM Default Value: \_\_line1pu\_\_

Description: linekey\_pickup\_01

P41201

EPM Default Value: \_\_line2type\_\_

Description: linekey\_type\_02

P41301

EPM Default Value: \_\_line2value\_\_

Description: linekey\_value\_02

P41401

EPM Default Value: \_\_line2label\_\_

Description: linekey\_label\_02



P41501  
EPM Default Value: \_\_line2acct\_\_  
Description: linekey\_account\_02

P41601  
EPM Default Value: \_\_line2pu\_\_  
Description: linekey\_pickup\_02

P41202  
EPM Default Value: \_\_line3type\_\_  
Description: linekey\_type\_03

P41302  
EPM Default Value: \_\_line3value\_\_  
Description: linekey\_value\_03

P41402  
EPM Default Value: \_\_line3label\_\_  
Description: linekey\_label\_03

P41502  
EPM Default Value: \_\_line3acct\_\_  
Description: linekey\_account\_03

P41602  
EPM Default Value: \_\_line3pu\_\_  
Description: linekey\_pickup\_03

P41203  
EPM Default Value: \_\_line4type\_\_  
Description: linekey\_type\_04

P41303  
EPM Default Value: \_\_line4value\_\_  
Description: linekey\_value\_04

P41403  
EPM Default Value: \_\_line4label\_\_  
Description: linekey\_label\_04

P41503  
EPM Default Value: \_\_line4acct\_\_  
Description: linekey\_account\_04

P41603  
EPM Default Value: \_\_line4pu\_\_  
Description: linekey\_pickup\_04

P20200  
EPM Default Value: \_\_line5type\_\_  
Description: Linekey Type

P20604  
EPM Default Value: \_\_line5mode\_\_  
Description: Linekey Mode

P20201  
EPM Default Value: \_\_line5value\_\_  
Description: Linekey Value

P20202  
EPM Default Value: \_\_line5label\_\_  
Description: Linekey Label

P20203  
EPM Default Value: \_\_line5acct\_\_  
Description: Linekey Account

P20204  
EPM Default Value: \_\_line5pu\_\_  
Description: Linekey PickupCode

P20205  
EPM Default Value: \_\_line6type\_\_  
Description: Linekey Type

P20605  
EPM Default Value: \_\_line6mode\_\_  
Description: Linekey Mode

P20206  
EPM Default Value: \_\_line6value\_\_  
Description: Linekey Value

P20207  
EPM Default Value: \_\_line6label\_\_  
Description: Linekey Label

P20208  
EPM Default Value: \_\_line6acct\_\_  
Description: Linekey Account

P20209  
EPM Default Value: \_\_line6pu\_\_  
Description: Linekey PickupCode

P20210  
EPM Default Value: \_\_line7type\_\_  
Description: Linekey Type

P20606  
EPM Default Value: \_\_line7mode\_\_  
Description: Linekey Mode

P20211  
EPM Default Value: \_\_line7value\_\_  
Description: Linekey Value

P20212  
EPM Default Value: \_\_line7label\_\_  
Description: Linekey Label

P20213  
EPM Default Value: \_\_line7acct\_\_  
Description: Linekey Account

P20214  
EPM Default Value: \_\_line7pu\_\_  
Description: Linekey PickupCode

P20215  
EPM Default Value: \_\_line8type\_\_  
Description: Linekey Type

P20607  
EPM Default Value: \_\_line8mode\_\_  
Description: Linekey Mode

P20216  
EPM Default Value: \_\_line8value\_\_  
Description: Linekey Value

P20217  
EPM Default Value: \_\_line8label\_\_  
Description: Linekey Label

P20218  
EPM Default Value: \_\_line8acct\_\_  
Description: Linekey Account

P20219  
EPM Default Value: \_\_line8pu\_\_  
Description: Linekey PickupCode

P20220  
EPM Default Value: \_\_line9type\_\_  
Description: Linekey Type

P20608  
EPM Default Value: \_\_line9mode\_\_  
Description: Linekey Mode

P20221  
EPM Default Value: \_\_line9value\_\_  
Description: Linekey Value

P20222  
EPM Default Value: \_\_line9label\_\_  
Description: Linekey Label

P20223  
EPM Default Value: \_\_line9acct\_\_  
Description: Linekey Account

P20224  
EPM Default Value: \_\_line9pu\_\_  
Description: Linekey PickupCode

P20225  
EPM Default Value: \_\_line10type\_\_  
Description: LineKey Type

P20609  
EPM Default Value: \_\_line10mode\_\_  
Description: LineKey Mode

P20226  
EPM Default Value: \_\_line10value\_\_  
Description: LineKey Value

P20227  
EPM Default Value: \_\_line10label\_\_  
Description: LineKey Label

P20228  
EPM Default Value: \_\_line10acct\_\_  
Description: LineKey Account

P20229  
EPM Default Value: \_\_line10pu\_\_  
Description: LineKey PickupCode

P20230  
EPM Default Value: \_\_line11type\_\_  
Description: LineKey Type

P20610  
EPM Default Value: \_\_line11mode\_\_  
Description: LineKey Mode

P20231  
EPM Default Value: \_\_line11value\_\_  
Description: LineKey Value

P20232  
EPM Default Value: \_\_line11label\_\_  
Description: LineKey Label

P20233  
EPM Default Value: \_\_line11acct\_\_  
Description: LineKey Account

P20234  
EPM Default Value: \_\_line11pu\_\_  
Description: LineKey PickupCode

P20235  
EPM Default Value: \_\_line12type\_\_  
Description: LineKey Type

P20611  
EPM Default Value: \_\_line12mode\_\_  
Description: LineKey Mode

P20236  
EPM Default Value: \_\_line12value\_\_  
Description: LineKey Value

P20237  
EPM Default Value: \_\_line12label\_\_  
Description: LineKey Label

P20238  
EPM Default Value: \_\_line12acct\_\_  
Description: LineKey Account

P20239  
EPM Default Value: \_\_line12pu\_\_  
Description: LineKey PickupCode

P20240  
EPM Default Value: \_\_line13type\_\_  
Description: LineKey Type

P20612  
EPM Default Value: \_\_line13mode\_\_  
Description: LineKey Mode

P20241  
EPM Default Value: \_\_line13value\_\_  
Description: LineKey Value

P20242  
EPM Default Value: \_\_line13label\_\_  
Description: LineKey Label

P20243  
EPM Default Value: \_\_line13acct\_\_  
Description: LineKey Account

P20244  
EPM Default Value: \_\_line13pu\_\_  
Description: LineKey PickupCode

P20245  
EPM Default Value: \_\_line14type\_\_  
Description: LineKey Type

P20613  
EPM Default Value: \_\_line14mode\_\_  
Description: LineKey Mode

P20246  
EPM Default Value: \_\_line14value\_\_  
Description: LineKey Value

P20247  
EPM Default Value: \_\_line14label\_\_  
Description: LineKey Label

P20248  
EPM Default Value: \_\_line14acct\_\_  
Description: LineKey Account

P20249  
EPM Default Value: \_\_line14pu\_\_  
Description: LineKey PickupCode

P20250  
EPM Default Value: \_\_line15type\_\_  
Description: LineKey Type

P20614  
EPM Default Value: \_\_line15mode\_\_  
Description: LineKey Mode

P20251  
EPM Default Value: \_\_line15value\_\_  
Description: LineKey Value

P20252  
EPM Default Value: \_\_line15label\_\_  
Description: LineKey Label

P20253  
EPM Default Value: \_\_line15acct\_\_  
Description: LineKey Account

P20254  
EPM Default Value: \_\_line15pu\_\_  
Description: LineKey PickupCode

P20255  
EPM Default Value: \_\_line16type\_\_  
Description: LineKey Type

P20615  
EPM Default Value: \_\_line16mode\_\_  
Description: LineKey Mode

P20256  
EPM Default Value: \_\_line16value\_\_  
Description: LineKey Value

P20257  
EPM Default Value: \_\_line16label\_\_  
Description: LineKey Label

P20258  
EPM Default Value: \_\_line16acct\_\_  
Description: LineKey Account

P20259  
EPM Default Value: \_\_line16pu\_\_  
Description: LineKey PickupCode

P20260  
EPM Default Value: \_\_line17type\_\_  
Description: LineKey Type

P20616  
EPM Default Value: \_\_line17mode\_\_  
Description: LineKey Mode

P20261  
EPM Default Value: \_\_line17value\_\_  
Description: LineKey Value

P20262  
EPM Default Value: \_\_line17label\_\_  
Description: LineKey Label

P20263  
EPM Default Value: \_\_line17acct\_\_  
Description: LineKey Account

P20264  
EPM Default Value: \_\_line17pu\_\_  
Description: LineKey PickupCode

P20265  
EPM Default Value: \_\_line18type\_\_  
Description: LineKey Type

P20617  
EPM Default Value: \_\_line18mode\_\_  
Description: LineKey Mode

P20266  
EPM Default Value: \_\_line18value\_\_  
Description: LineKey Value

P20267  
EPM Default Value: \_\_line18label\_\_  
Description: LineKey Label

P20268  
EPM Default Value: \_\_line18acct\_\_  
Description: LineKey Account

P20269  
EPM Default Value: \_\_line18pu\_\_  
Description: LineKey PickupCode

P20270  
EPM Default Value: \_\_line19type\_\_  
Description: LineKey Type

P20618  
EPM Default Value: \_\_line19mode\_\_  
Description: LineKey Mode

P20271  
EPM Default Value: \_\_line19value\_\_  
Description: LineKey Value

P20272  
EPM Default Value: \_\_line19label\_\_  
Description: LineKey Label

P20273  
EPM Default Value: \_\_line19acct\_\_  
Description: LineKey Account

P20274  
EPM Default Value: \_\_line19pu\_\_  
Description: LineKey PickupCode

P20275  
EPM Default Value: \_\_line20type\_\_  
Description: LineKey Type

P20619  
EPM Default Value: \_\_line20mode\_\_  
Description: LineKey Mode

P20276  
EPM Default Value: \_\_line20value\_\_  
Description: LineKey Value

P20277  
EPM Default Value: \_\_line20label\_\_  
Description: LineKey Label

P20278  
EPM Default Value: \_\_line20acct\_\_  
Description: LineKey Account

P20279  
EPM Default Value: \_\_line20pu\_\_  
Description: LineKey PickupCode

P20280  
EPM Default Value: \_\_line21type\_\_  
Description: LineKey Type

P20620  
EPM Default Value: \_\_line21mode\_\_  
Description: LineKey Mode

P20281  
EPM Default Value: \_\_line21value\_\_  
Description: LineKey Value

P20282  
EPM Default Value: \_\_line21label\_\_  
Description: LineKey Label

P20283  
EPM Default Value: \_\_line21acct\_\_  
Description: LineKey Account

P20284  
EPM Default Value: \_\_line21pu\_\_  
Description: LineKey PickupCode

P20285  
EPM Default Value: \_\_line22type\_\_  
Description: LineKey Type

P20621  
EPM Default Value: \_\_line22mode\_\_  
Description: LineKey Mode

P20286  
EPM Default Value: \_\_line22value\_\_  
Description: LineKey Value

P20287  
EPM Default Value: \_\_line22label\_\_  
Description: LineKey Label

P20288  
EPM Default Value: \_\_line22acct\_\_  
Description: LineKey Account

P20289  
EPM Default Value: \_\_line22pu\_\_  
Description: LineKey PickupCode

P20290  
EPM Default Value: \_\_line23type\_\_  
Description: LineKey Type

P20622  
EPM Default Value: \_\_line23mode\_\_  
Description: LineKey Mode

P20291  
EPM Default Value: \_\_line23value\_\_  
Description: LineKey Value

P20292  
EPM Default Value: \_\_line23label\_\_  
Description: LineKey Label

P20293  
EPM Default Value: \_\_line23acct\_\_  
Description: LineKey Account

P20294  
EPM Default Value: \_\_line23pu\_\_  
Description: LineKey PickupCode

P20295  
EPM Default Value: \_\_line24type\_\_  
Description: LineKey Type

P20623  
EPM Default Value: \_\_line24mode\_\_  
Description: LineKey Mode

P20296  
EPM Default Value: \_\_line24value\_\_  
Description: LineKey Value

P20297  
EPM Default Value: \_\_line24label\_\_  
Description: LineKey Label

P20298  
EPM Default Value: \_\_line24acct\_\_  
Description: LineKey Account

P20299  
EPM Default Value: \_\_line24pu\_\_  
Description: LineKey PickupCode

P20300  
EPM Default Value: \_\_line25type\_\_  
Description: Linekey Type

P20624  
EPM Default Value: \_\_line25mode\_\_  
Description: LineKey Mode

P20301  
EPM Default Value: \_\_line25value\_\_  
Description: LineKey Value

P20302  
EPM Default Value: \_\_line25label\_\_  
Description: LineKey Label

P20303  
EPM Default Value: \_\_line25acct\_\_  
Description: LineKey Account

P20304  
EPM Default Value: \_\_line25pu\_\_  
Description: LineKey PickupCode

P20305  
EPM Default Value: \_\_line26type\_\_  
Description: LineKey Type

P20625  
EPM Default Value: \_\_line26mode\_\_  
Description: LineKey Mode

P20306  
EPM Default Value: \_\_line26value\_\_  
Description: LineKey Value

P20307  
EPM Default Value: \_\_line26label\_\_  
Description: LineKey Label

P20308  
EPM Default Value: \_\_line26acct\_\_  
Description: LineKey Account

P20309  
EPM Default Value: \_\_line26pu\_\_  
Description: LineKey PickupCode



P20310  
EPM Default Value: \_\_line27type\_\_  
Description: LineKey Type

P20626  
EPM Default Value: \_\_line27mode\_\_  
Description: LineKey Mode

P20311  
EPM Default Value: \_\_line27value\_\_  
Description: LineKey Value

P20312  
EPM Default Value: \_\_line27label\_\_  
Description: LineKey Label

P20313  
EPM Default Value: \_\_line27acct\_\_  
Description: LineKey Account

P20314  
EPM Default Value: \_\_line27pu\_\_  
Description: LineKey PickupCode

P20315  
EPM Default Value: \_\_line28type\_\_  
Description: LineKey Type

P20627  
EPM Default Value: \_\_line28mode\_\_  
Description: LineKey Mode

P20316  
EPM Default Value: \_\_line28value\_\_  
Description: LineKey Value

P20317  
EPM Default Value: \_\_line28label\_\_  
Description: LineKey Label

P20318  
EPM Default Value: \_\_line28acct\_\_  
Description: LineKey Account

P20319  
EPM Default Value: \_\_line28pu\_\_  
Description: LineKey PickupCode

P20320  
EPM Default Value: \_\_line29type\_\_  
Description: LineKey Type

P20628  
EPM Default Value: \_\_line29mode\_\_  
Description: LineKey Mode

P20321  
EPM Default Value: \_\_line29value\_\_  
Description: LineKey Value

P20322  
EPM Default Value: \_\_line29label\_\_  
Description: LineKey Label

P20323  
EPM Default Value: \_\_line29acct\_\_  
Description: LineKey Account

P20324  
EPM Default Value: \_\_line29pu\_\_  
Description: LineKey PickupCode

P20325  
EPM Default Value: \_\_line30type\_\_  
Description: LineKey Type

P20629  
EPM Default Value: \_\_line30mode\_\_  
Description: LineKey Mode

P20326  
EPM Default Value: \_\_line30value\_\_  
Description: LineKey Value

P20327  
EPM Default Value: \_\_line30label\_\_  
Description: LineKey Label

P20328  
EPM Default Value: \_\_line30acct\_\_  
Description: LineKey Account

P20329  
EPM Default Value: \_\_line30pu\_\_  
Description: LineKey PickupCode

P20330  
EPM Default Value: \_\_line31type\_\_  
Description: LineKey Type

P20630  
EPM Default Value: \_\_line31mode\_\_  
Description: LineKey Mode

P20331  
EPM Default Value: \_\_line31value\_\_  
Description: LineKey Value

P20332  
EPM Default Value: \_\_line31label\_\_  
Description: LineKey Label

P20333  
EPM Default Value: \_\_line31acct\_\_  
Description: LineKey Account

P20334  
EPM Default Value: \_\_line31pu\_\_  
Description: LineKey PickupCode

P20335  
EPM Default Value: \_\_line32type\_\_  
Description: LineKey Type

P20631  
EPM Default Value: \_\_line32mode\_\_  
Description: LineKey Mode

P20336  
EPM Default Value: \_\_line32value\_\_  
Description: LineKey Value

P20337  
EPM Default Value: \_\_line32label\_\_  
Description: LineKey Label

P20338  
EPM Default Value: \_\_line32acct\_\_  
Description: LineKey Account

P20339  
EPM Default Value: \_\_line32pu\_\_  
Description: LineKey PickupCode

P20340  
EPM Default Value: \_\_line33type\_\_  
Description: LineKey Type

P20632  
EPM Default Value: \_\_line33mode\_\_  
Description: LineKey Mode

P20341  
EPM Default Value: \_\_line33value\_\_  
Description: LineKey Value

P20342  
EPM Default Value: \_\_line33label\_\_  
Description: LineKey Label

P20343  
EPM Default Value: \_\_line33acct\_\_  
Description: LineKey Account

P20344  
EPM Default Value: \_\_line33pu\_\_  
Description: LineKey PickupCode

P20345  
EPM Default Value: \_\_line34type\_\_  
Description: LineKey Type

P20633  
EPM Default Value: \_\_line34mode\_\_  
Description: LineKey Mode

P20346  
EPM Default Value: \_\_line34value\_\_  
Description: LineKey Value

P20347  
EPM Default Value: \_\_line34label\_\_  
Description: LineKey Label

P20348  
EPM Default Value: \_\_line34acct\_\_  
Description: LineKey Account

P20349  
EPM Default Value: \_\_line34pu\_\_  
Description: LineKey PickupCode

P20350  
EPM Default Value: \_\_line35type\_\_  
Description: Linekey Type

P20634  
EPM Default Value: \_\_line35mode\_\_  
Description: LineKey Mode

P20351  
EPM Default Value: \_\_line35value\_\_  
Description: LineKey Value

P20352  
EPM Default Value: \_\_line35label\_\_  
Description: LineKey Label

P20353  
EPM Default Value: \_\_line35acct\_\_  
Description: LineKey Account

P20354  
EPM Default Value: \_\_line35pu\_\_  
Description: LineKey PickupCode

P20355  
EPM Default Value: \_\_line36type\_\_  
Description: LineKey Type

P20635  
EPM Default Value: \_\_line36mode\_\_  
Description: LineKey Mode

P20356  
EPM Default Value: \_\_line36value\_\_  
Description: LineKey Value

P20357  
EPM Default Value: \_\_line36label\_\_  
Description: LineKey Label

P20358  
EPM Default Value: \_\_line36acct\_\_  
Description: LineKey Account

P20359  
EPM Default Value: \_\_line36pu\_\_  
Description: LineKey PickupCode

P23000  
EPM Default Value: \_\_line37type\_\_  
Description: LineKey Type

P23001  
EPM Default Value: \_\_line37mode\_\_  
Description: LineKey Mode

P23002  
EPM Default Value: \_\_line37value\_\_  
Description: LineKey Value

P23003  
EPM Default Value: \_\_line37label\_\_  
Description: LineKey Label

P23004  
EPM Default Value: \_\_line37acct\_\_  
Description: LineKey Account

P23005  
EPM Default Value: \_\_line37pu\_\_  
Description: LineKey PickupCode

P23006  
EPM Default Value: \_\_line38type\_\_  
Description: LineKey Type

P23007  
EPM Default Value: \_\_line38mode\_\_  
Description: LineKey Mode

P23008  
EPM Default Value: \_\_line38value\_\_  
Description: LineKey Value

P23009  
EPM Default Value: \_\_line38label\_\_  
Description: LineKey Label

P23010  
EPM Default Value: \_\_line38acct\_\_  
Description: LineKey Account

P23011  
EPM Default Value: \_\_line38pu\_\_  
Description: LineKey PickupCode

P23012  
EPM Default Value: \_\_line39type\_\_  
Description: LineKey Type

P23013  
EPM Default Value: \_\_line39mode\_\_  
Description: LineKey Mode

P23014  
EPM Default Value: \_\_line39value\_\_  
Description: LineKey Value

P23015  
EPM Default Value: \_\_line39label\_\_  
Description: LineKey Label

P23016  
EPM Default Value: \_\_line39acct\_\_  
Description: LineKey Account

P23017  
EPM Default Value: \_\_line39pu\_\_  
Description: LineKey PickupCode

P23018  
EPM Default Value: \_\_line40type\_\_  
Description: LineKey Type

P23019  
EPM Default Value: \_\_line40mode\_\_  
Description: LineKey Mode

P23020  
EPM Default Value: \_\_line40value\_\_  
Description: LineKey Value

P23021  
EPM Default Value: \_\_line40label\_\_  
Description: LineKey Label

P23022  
EPM Default Value: \_\_line40acct\_\_  
Description: LineKey Account

P23023  
EPM Default Value: \_\_line40pu\_\_  
Description: LineKey PickupCode

P23024  
EPM Default Value: \_\_line41type\_\_  
Description: LineKey Type

P23025  
EPM Default Value: \_\_line41mode\_\_  
Description: LineKey Mode

P23026  
EPM Default Value: \_\_line41value\_\_  
Description: LineKey Value

P23027  
EPM Default Value: \_\_line41label\_\_  
Description: LineKey Label

P23028  
EPM Default Value: \_\_line41acct\_\_  
Description: LineKey Account

P23029  
EPM Default Value: \_\_line41pu\_\_  
Description: LineKey PickupCode

P23030  
EPM Default Value: \_\_line42type\_\_  
Description: LineKey Type

P23031  
EPM Default Value: \_\_line42mode\_\_  
Description: LineKey Mode

P23032  
EPM Default Value: \_\_line42value\_\_  
Description: LineKey Value

P23033  
EPM Default Value: \_\_line42label\_\_  
Description: LineKey Label

P23034  
EPM Default Value: \_\_line42acct\_\_  
Description: LineKey Account

P23035  
EPM Default Value: \_\_line42pu\_\_  
Description: LineKey PickupCode

P23036  
EPM Default Value: \_\_line43type\_\_  
Description: LineKey Type

P23037  
EPM Default Value: \_\_line43mode\_\_  
Description: LineKey Mode

P23038  
EPM Default Value: \_\_line43value\_\_  
Description: LineKey Value

P23039  
EPM Default Value: \_\_line43label\_\_  
Description: LineKey Label

P23040  
EPM Default Value: \_\_line43acct\_\_  
Description: LineKey Account

P23041  
EPM Default Value: \_\_line43pu\_\_  
Description: LineKey PickupCode

P23042  
EPM Default Value: \_\_line44type\_\_  
Description: LineKey Type

P23043  
EPM Default Value: \_\_line44mode\_\_  
Description: LineKey Mode

P23044  
EPM Default Value: \_\_line44value\_\_  
Description: LineKey Value

P23045  
EPM Default Value: \_\_line44label\_\_  
Description: LineKey Label

P23046  
EPM Default Value: \_\_line44acct\_\_  
Description: LineKey Account

P23047  
EPM Default Value: \_\_line44pu\_\_  
Description: LineKey PickupCode

P23048  
EPM Default Value: \_\_line45type\_\_  
Description: LineKey Type

P23049  
EPM Default Value: \_\_line45mode\_\_  
Description: LineKey Mode

P23050  
EPM Default Value: \_\_line45value\_\_  
Description: LineKey Value

P23051  
EPM Default Value: \_\_line45label\_\_  
Description: LineKey Label

P23052  
EPM Default Value: \_\_line45acct\_\_  
Description: LineKey Account

P23053  
EPM Default Value: \_\_line45pu\_\_  
Description: LineKey PickupCode

P42200  
EPM Default Value: \_\_b1type\_\_  
Description: memkey\_type\_01

P42300  
EPM Default Value: \_\_b1value\_\_  
Description: memkey\_value\_01

P42400  
EPM Default Value: \_\_b1acct\_\_  
Description: memkey\_account\_01

P42500  
EPM Default Value: \_\_b1pu\_\_  
Description: memkey\_pickup\_01

P42201  
EPM Default Value: \_\_b2type\_\_  
Description: memkey\_type\_02

P42301  
EPM Default Value: \_\_b2value\_\_  
Description: memkey\_value\_02

P42401  
EPM Default Value: \_\_b2acct\_\_  
Description: memkey\_account\_02

P42501  
EPM Default Value: \_\_b2pu\_\_  
Description: memkey\_pickup\_02

P42202  
EPM Default Value: \_\_b3type\_\_  
Description: memkey\_type\_03

P42302  
EPM Default Value: \_\_b3value\_\_  
Description: memkey\_value\_03

P42402  
EPM Default Value: \_\_b3acct\_\_  
Description: memkey\_account\_03

P42502  
EPM Default Value: \_\_b3pu\_\_  
Description: memkey\_pickup\_03

P42203  
EPM Default Value: \_\_b4type\_\_  
Description: memkey\_type\_04

P42303  
EPM Default Value: \_\_b4value\_\_  
Description: memkey\_value\_04

P42403  
EPM Default Value: \_\_b4acct\_\_  
Description: memkey\_account\_04

P42503  
EPM Default Value: \_\_b4pu\_\_  
Description: memkey\_pickup\_04

P42204  
EPM Default Value: \_\_b5type\_\_  
Description: memkey\_type\_05

P42304  
EPM Default Value: \_\_b5value\_\_  
Description: memkey\_value\_05

P42404  
EPM Default Value: \_\_b5acct\_\_  
Description: memkey\_account\_05

P42504  
EPM Default Value: \_\_b5pu\_\_  
Description: memkey\_pickup\_05

P42205  
EPM Default Value: \_\_b6type\_\_  
Description: memkey\_type\_06

P42305  
EPM Default Value: \_\_b6value\_\_  
Description: memkey\_value\_06

P42405  
EPM Default Value: \_\_b6acct\_\_  
Description: memkey\_account\_06

P42505  
EPM Default Value: \_\_b6pu\_\_  
Description: memkey\_pickup\_06

P42206  
EPM Default Value: \_\_b7type\_\_  
Description: memkey\_type\_07

P42306  
EPM Default Value: \_\_b7value\_\_  
Description: memkey\_value\_07

P42406  
EPM Default Value: \_\_b7acct\_\_  
Description: memkey\_account\_07

P42506  
EPM Default Value: \_\_b7pu\_\_  
Description: memkey\_pickup\_07

P42207  
EPM Default Value: \_\_b8type\_\_  
Description: memkey\_type\_08

P42307  
EPM Default Value: \_\_b8value\_\_  
Description: memkey\_value\_08



P42407  
EPM Default Value: \_\_b8acct\_\_  
Description: memkey\_account\_08

P42507  
EPM Default Value: \_\_b8pu\_\_  
Description: memkey\_pickup\_08

P42208  
EPM Default Value: \_\_b9type\_\_  
Description: memkey\_type\_09

P42308  
EPM Default Value: \_\_b9value\_\_  
Description: memkey\_value\_09

P42408  
EPM Default Value: \_\_b9acct\_\_  
Description: memkey\_account\_09

P42508  
EPM Default Value: \_\_b9pu\_\_  
Description: memkey\_pickup\_09

P42209  
EPM Default Value: \_\_b10type\_\_  
Description: memkey\_type\_10

P42309  
EPM Default Value: \_\_b10value\_\_  
Description: memkey\_value\_10

P42409  
EPM Default Value: \_\_b10acct\_\_  
Description: memkey\_account\_10

P42509  
EPM Default Value: \_\_b10pu\_\_  
Description: memkey\_pickup\_10

P43200  
EPM Default Value: \_\_sk1type\_\_  
Description: softkey\_type\_01

P43300  
EPM Default Value: \_\_sk1acct\_\_  
Description: softkey\_account\_01

P43400  
EPM Default Value: \_\_sk1value\_\_  
Description: softkey\_value\_01

P43201  
EPM Default Value: \_\_sk2type\_\_  
Description: softkey\_type\_02

P43301  
EPM Default Value: \_\_sk2acct\_\_  
Description: softkey\_account\_02

P43401  
EPM Default Value: \_\_sk2value\_\_  
Description: softkey\_value\_02

P43202  
EPM Default Value: \_\_sk3type\_\_  
Description: softkey\_type\_03

P43302  
EPM Default Value: \_\_sk3acct\_\_  
Description: softkey\_account\_03

P43402  
EPM Default Value: \_\_sk3value\_\_  
Description: softkey\_value\_03

P43203  
EPM Default Value: \_\_sk4type\_\_  
Description: softkey\_type\_04

P43303  
EPM Default Value: \_\_sk4acct\_\_  
Description: softkey\_account\_04

P43403  
EPM Default Value: \_\_sk4value\_\_  
Description: softkey\_value\_04

P60000  
EPM Default Value: \_\_exp11type\_\_  
Description: Expansion Module 1 key 1type

P60001  
EPM Default Value: \_\_exp11value\_\_  
Description: Expansion Module 1 key 1value

P60002  
EPM Default Value: \_\_exp11label\_\_  
Description: Expansion Module 1 key 1label

P60003  
EPM Default Value: \_\_exp11acct\_\_  
Description: Expansion Module 1 key 1account

P60004  
EPM Default Value: \_\_exp11pu\_\_  
Description: Expansion Module 1 key 1pickup up

P60005  
EPM Default Value: \_\_exp12type\_\_  
Description: Expansion Module 1 key 2type

P60006  
EPM Default Value: \_\_exp12value\_\_  
Description: Expansion Module 1 key 2value

P60007  
EPM Default Value: \_\_exp12label\_\_  
Description: Expansion Module 1 key 2label

P60008  
EPM Default Value: \_\_exp12acct\_\_  
Description: Expansion Module 1 key 2account

P60009  
EPM Default Value: \_\_exp12pu\_\_  
Description: Expansion Module 1 key 2pickup up

P60010  
EPM Default Value: \_\_exp13type\_\_  
Description: Expansion Module 1 key 3type

P60011  
EPM Default Value: \_\_exp13value\_\_  
Description: Expansion Module 1 key 3value

P60012  
EPM Default Value: \_\_exp13label\_\_  
Description: Expansion Module 1 key 3label

P60013  
EPM Default Value: \_\_exp13acct\_\_  
Description: Expansion Module 1 key 3account

P60014  
EPM Default Value: \_\_exp13pu\_\_  
Description: Expansion Module 1 key 3pickup up

P60015  
EPM Default Value: \_\_exp14type\_\_  
Description: Expansion Module 1 key 4type

P60016  
EPM Default Value: \_\_exp14value\_\_  
Description: Expansion Module 1 key 4value

P60017  
EPM Default Value: \_\_exp14label\_\_  
Description: Expansion Module 1 key 4label

P60018  
EPM Default Value: \_\_exp14acct\_\_  
Description: Expansion Module 1 key 4account

P60019  
EPM Default Value: \_\_exp14pu\_\_  
Description: Expansion Module 1 key 4pickup up

P60020  
EPM Default Value: \_\_exp15type\_\_  
Description: Expansion Module 1 key 5type

P60021  
EPM Default Value: \_\_exp15value\_\_  
Description: Expansion Module 1 key 5value

P60022  
EPM Default Value: \_\_exp15label\_\_  
Description: Expansion Module 1 key 5label

P60023  
EPM Default Value: \_\_exp15acct\_\_  
Description: Expansion Module 1 key 5account

P60024  
EPM Default Value: \_\_exp15pu\_\_  
Description: Expansion Module 1 key 5pickup up

P60025  
EPM Default Value: \_\_exp16type\_\_  
Description: Expansion Module 1 key 6type

P60026  
EPM Default Value: \_\_exp16value\_\_  
Description: Expansion Module 1 key 6value

P60027  
EPM Default Value: \_\_exp16label\_\_  
Description: Expansion Module 1 key 6label

P60028  
EPM Default Value: \_\_exp16acct\_\_  
Description: Expansion Module 1 key 6account

P60029  
EPM Default Value: \_\_exp16pu\_\_  
Description: Expansion Module 1 key 6pickup up

P60030  
EPM Default Value: \_\_exp17type\_\_  
Description: Expansion Module 1 key 7type

P60031  
EPM Default Value: \_\_exp17value\_\_  
Description: Expansion Module 1 key 7value

P60032  
EPM Default Value: \_\_exp17label\_\_  
Description: Expansion Module 1 key 7label

P60033  
EPM Default Value: \_\_exp17acct\_\_  
Description: Expansion Module 1 key 7account

P60034  
EPM Default Value: \_\_exp17pu\_\_  
Description: Expansion Module 1 key 7pickup up

P60035  
EPM Default Value: \_\_exp18type\_\_  
Description: Expansion Module 1 key 8type

P60036  
EPM Default Value: \_\_exp18value\_\_  
Description: Expansion Module 1 key 8value

P60037  
EPM Default Value: \_\_exp18label\_\_  
Description: Expansion Module 1 key 8label

P60038  
EPM Default Value: \_\_exp18acct\_\_  
Description: Expansion Module 1 key 8account

P60039  
EPM Default Value: \_\_exp18pu\_\_  
Description: Expansion Module 1 key 8pickup up

P60040  
EPM Default Value: \_\_exp19type\_\_  
Description: Expansion Module 1 key 9type

P60041  
EPM Default Value: \_\_exp19value\_\_  
Description: Expansion Module 1 key 9value

P60042  
EPM Default Value: \_\_exp19label\_\_  
Description: Expansion Module 1 key 9label

P60043  
EPM Default Value: \_\_exp19acct\_\_  
Description: Expansion Module 1 key 9account

P60044  
EPM Default Value: \_\_exp19pu\_\_  
Description: Expansion Module 1 key 9pickup up

P60045  
EPM Default Value: \_\_exp110type\_\_  
Description: Expansion Module 1 key 10type

P60046  
EPM Default Value: \_\_exp110value\_\_  
Description: Expansion Module 1 key 10value

P60047  
EPM Default Value: \_\_exp110label\_\_  
Description: Expansion Module 1 key 10label

P60048  
EPM Default Value: \_\_exp110acct\_\_  
Description: Expansion Module 1 key 10account

P60049  
EPM Default Value: \_\_exp110pu\_\_  
Description: Expansion Module 1 key 10pickup up

P60050  
EPM Default Value: \_\_exp111type\_\_  
Description: Expansion Module 1 key 11type

P60051  
EPM Default Value: \_\_exp111value\_\_  
Description: Expansion Module 1 key 11value

P60052  
EPM Default Value: \_\_exp111label\_\_  
Description: Expansion Module 1 key 11label

P60053  
EPM Default Value: \_\_exp111acct\_\_  
Description: Expansion Module 1 key 11account

P60054  
EPM Default Value: \_\_exp111pu\_\_  
Description: Expansion Module 1 key 11pickup up

P60055  
EPM Default Value: \_\_exp112type\_\_  
Description: Expansion Module 1 key 12type

P60056  
EPM Default Value: \_\_exp112value\_\_  
Description: Expansion Module 1 key 12value

P60057  
EPM Default Value: \_\_exp112label\_\_  
Description: Expansion Module 1 key 12label

P60058  
EPM Default Value: \_\_exp112acct\_\_  
Description: Expansion Module 1 key 12account

P60059  
EPM Default Value: \_\_exp112pu\_\_  
Description: Expansion Module 1 key 12pickup up

P60060  
EPM Default Value: \_\_exp113type\_\_  
Description: Expansion Module 1 key 13type

P60061  
EPM Default Value: \_\_exp113value\_\_  
Description: Expansion Module 1 key 13value

P60062  
EPM Default Value: \_\_exp113label\_\_  
Description: Expansion Module 1 key 13label

P60063  
EPM Default Value: \_\_exp113acct\_\_  
Description: Expansion Module 1 key 13account

P60064  
EPM Default Value: \_\_exp113pu\_\_  
Description: Expansion Module 1 key 13pickup up

P60065  
EPM Default Value: \_\_exp114type\_\_  
Description: Expansion Module 1 key 14type

P60066  
EPM Default Value: \_\_exp114value\_\_  
Description: Expansion Module 1 key 14value

P60067  
EPM Default Value: \_\_exp114label\_\_  
Description: Expansion Module 1 key 14label

P60068  
EPM Default Value: \_\_exp114acct\_\_  
Description: Expansion Module 1 key 14account

P60069  
EPM Default Value: \_\_exp114pu\_\_  
Description: Expansion Module 1 key 14pickup up

P60070  
EPM Default Value: \_\_exp115type\_\_  
Description: Expansion Module 1 key 15type

P60071  
EPM Default Value: \_\_exp115value\_\_  
Description: Expansion Module 1 key 15value

P60072  
EPM Default Value: \_\_exp115label\_\_  
Description: Expansion Module 1 key 15label

P60073  
EPM Default Value: \_\_exp115acct\_\_  
Description: Expansion Module 1 key 15account

P60074  
EPM Default Value: \_\_exp115pu\_\_  
Description: Expansion Module 1 key 15pickup up

P60075  
EPM Default Value: \_\_exp116type\_\_  
Description: Expansion Module 1 key 16type

P60076  
EPM Default Value: \_\_exp116value\_\_  
Description: Expansion Module 1 key 16value

P60077  
EPM Default Value: \_\_exp116label\_\_  
Description: Expansion Module 1 key 16label

P60078  
EPM Default Value: \_\_exp116acct\_\_  
Description: Expansion Module 1 key 16account

P60079  
EPM Default Value: \_\_exp116pu\_\_  
Description: Expansion Module 1 key 16pickup up

P60080  
EPM Default Value: \_\_exp117type\_\_  
Description: Expansion Module 1 key 17type

P60081  
EPM Default Value: \_\_exp117value\_\_  
Description: Expansion Module 1 key 17value

P60082  
EPM Default Value: \_\_exp117label\_\_  
Description: Expansion Module 1 key 17label

P60083  
EPM Default Value: \_\_exp117acct\_\_  
Description: Expansion Module 1 key 17account

P60084  
EPM Default Value: \_\_exp117pu\_\_  
Description: Expansion Module 1 key 17pickup up

P60085  
EPM Default Value: \_\_exp118type\_\_  
Description: Expansion Module 1 key 18type

P60086  
EPM Default Value: \_\_exp118value\_\_  
Description: Expansion Module 1 key 18value

P60087  
EPM Default Value: \_\_exp118label\_\_  
Description: Expansion Module 1 key 18label

P60088  
EPM Default Value: \_\_exp118acct\_\_  
Description: Expansion Module 1 key 18account

P60089  
EPM Default Value: \_\_exp118pu\_\_  
Description: Expansion Module 1 key 18pickup up

P60090  
EPM Default Value: \_\_exp119type\_\_  
Description: Expansion Module 1 key 19type

P60091  
EPM Default Value: \_\_exp119value\_\_  
Description: Expansion Module 1 key 19value

P60092  
EPM Default Value: \_\_exp119label\_\_  
Description: Expansion Module 1 key 19label

P60093  
EPM Default Value: \_\_exp119acct\_\_  
Description: Expansion Module 1 key 19account

P60094  
EPM Default Value: \_\_exp119pu\_\_  
Description: Expansion Module 1 key 19pickup up

P60095  
EPM Default Value: \_\_exp120type\_\_  
Description: Expansion Module 1 key 20type

P60096  
EPM Default Value: \_\_exp120value\_\_  
Description: Expansion Module 1 key 20value

P60097  
EPM Default Value: \_\_exp120label\_\_  
Description: Expansion Module 1 key 20label

P60098  
EPM Default Value: \_\_exp120acct\_\_  
Description: Expansion Module 1 key 20account

P60099  
EPM Default Value: \_\_exp120pu\_\_  
Description: Expansion Module 1 key 20pickup up

P60100  
EPM Default Value: \_\_exp121type\_\_  
Description: Expansion Module 1 key 21type

P60101  
EPM Default Value: \_\_exp121value\_\_  
Description: Expansion Module 1 key 21value

P60102  
EPM Default Value: \_\_exp121label\_\_  
Description: Expansion Module 1 key 21label

P60103  
EPM Default Value: \_\_exp121acct\_\_  
Description: Expansion Module 1 key 21account

P60104  
EPM Default Value: \_\_exp121pu\_\_  
Description: Expansion Module 1 key 21pickup up

P60105  
EPM Default Value: \_\_exp122type\_\_  
Description: Expansion Module 1 key 22type

P60106  
EPM Default Value: \_\_exp122value\_\_  
Description: Expansion Module 1 key 22value

P60107  
EPM Default Value: \_\_exp122label\_\_  
Description: Expansion Module 1 key 22label

P60108  
EPM Default Value: \_\_exp122acct\_\_  
Description: Expansion Module 1 key 22account

P60109  
EPM Default Value: \_\_exp122pu\_\_  
Description: Expansion Module 1 key 22pickup up

P60110  
EPM Default Value: \_\_exp123type\_\_  
Description: Expansion Module 1 key 23type

P60111  
EPM Default Value: \_\_exp123value\_\_  
Description: Expansion Module 1 key 23value

P60112  
EPM Default Value: \_\_exp123label\_\_  
Description: Expansion Module 1 key 23label

P60113  
EPM Default Value: \_\_exp123acct\_\_  
Description: Expansion Module 1 key 23account

P60114  
EPM Default Value: \_\_exp123pu\_\_  
Description: Expansion Module 1 key 23pickup up

P60115  
EPM Default Value: \_\_exp124type\_\_  
Description: Expansion Module 1 key 24type

P60116  
EPM Default Value: \_\_exp124value\_\_  
Description: Expansion Module 1 key 24value

P60117  
EPM Default Value: \_\_exp124label\_\_  
Description: Expansion Module 1 key 24label

P60118  
EPM Default Value: \_\_exp124acct\_\_  
Description: Expansion Module 1 key 24account

P60119  
EPM Default Value: \_\_exp124pu\_\_  
Description: Expansion Module 1 key 24pickup up

P60120  
EPM Default Value: \_\_exp125type\_\_  
Description: Expansion Module 1 key 25type

P60121  
EPM Default Value: \_\_exp125value\_\_  
Description: Expansion Module 1 key 25value



P60122  
EPM Default Value: \_\_exp125label\_\_  
Description: Expansion Module 1 key 25label

P60123  
EPM Default Value: \_\_exp125acct\_\_  
Description: Expansion Module 1 key 25account

P60124  
EPM Default Value: \_\_exp125pu\_\_  
Description: Expansion Module 1 key 25pickup up

P60125  
EPM Default Value: \_\_exp126type\_\_  
Description: Expansion Module 1 key 26type

P60126  
EPM Default Value: \_\_exp126value\_\_  
Description: Expansion Module 1 key 26value

P60127  
EPM Default Value: \_\_exp126label\_\_  
Description: Expansion Module 1 key 26label

P60128  
EPM Default Value: \_\_exp126acct\_\_  
Description: Expansion Module 1 key 26account

P60129  
EPM Default Value: \_\_exp126pu\_\_  
Description: Expansion Module 1 key 26pickup up

P60130  
EPM Default Value: \_\_exp127type\_\_  
Description: Expansion Module 1 key 27type

P60131  
EPM Default Value: \_\_exp127value\_\_  
Description: Expansion Module 1 key 27value

P60132  
EPM Default Value: \_\_exp127label\_\_  
Description: Expansion Module 1 key 27label

P60133  
EPM Default Value: \_\_exp127acct\_\_  
Description: Expansion Module 1 key 27account

P60134  
EPM Default Value: \_\_exp127pu\_\_  
Description: Expansion Module 1 key 27pickup up

P60135  
EPM Default Value: \_\_exp128type\_\_  
Description: Expansion Module 1 key 28type

P60136  
EPM Default Value: \_\_exp128value\_\_  
Description: Expansion Module 1 key 28value

P60137  
EPM Default Value: \_\_exp128label\_\_  
Description: Expansion Module 1 key 28label

P60138  
EPM Default Value: \_\_exp128acct\_\_  
Description: Expansion Module 1 key 28account

P60139  
EPM Default Value: \_\_exp128pu\_\_  
Description: Expansion Module 1 key 28pickup up

P60140  
EPM Default Value: \_\_exp129type\_\_  
Description: Expansion Module 1 key 29type

P60141  
EPM Default Value: \_\_exp129value\_\_  
Description: Expansion Module 1 key 29value

P60142  
EPM Default Value: \_\_exp129label\_\_  
Description: Expansion Module 1 key 29label

P60143  
EPM Default Value: \_\_exp129acct\_\_  
Description: Expansion Module 1 key 29account

P60144  
EPM Default Value: \_\_exp129pu\_\_  
Description: Expansion Module 1 key 29pickup up

P60145  
EPM Default Value: \_\_exp130type\_\_  
Description: Expansion Module 1 key 30type

P60146  
EPM Default Value: \_\_exp130value\_\_  
Description: Expansion Module 1 key 30value

P60147  
EPM Default Value: \_\_exp130label\_\_  
Description: Expansion Module 1 key 30label

P60148  
EPM Default Value: \_\_exp130acct\_\_  
Description: Expansion Module 1 key 30account

P60149  
EPM Default Value: \_\_exp130pu\_\_  
Description: Expansion Module 1 key 30pickup up

P60150  
EPM Default Value: \_\_exp131type\_\_  
Description: Expansion Module 1 key 31type

P60151  
EPM Default Value: \_\_exp131value\_\_  
Description: Expansion Module 1 key 31value

P60152  
EPM Default Value: \_\_exp131label\_\_  
Description: Expansion Module 1 key 31label

P60153  
EPM Default Value: \_\_exp131acct\_\_  
Description: Expansion Module 1 key 31account

P60154  
EPM Default Value: \_\_exp131pu\_\_  
Description: Expansion Module 1 key 31pickup up

P60155  
EPM Default Value: \_\_exp132type\_\_  
Description: Expansion Module 1 key 32type

P60156  
EPM Default Value: \_\_exp132value\_\_  
Description: Expansion Module 1 key 32value

P60157  
EPM Default Value: \_\_exp132label\_\_  
Description: Expansion Module 1 key 32label

P60158  
EPM Default Value: \_\_exp132acct\_\_  
Description: Expansion Module 1 key 32account

P60159  
EPM Default Value: \_\_exp132pu\_\_  
Description: Expansion Module 1 key 32pickup up

P60160  
EPM Default Value: \_\_exp133type\_\_  
Description: Expansion Module 1 key 33type

P60161  
EPM Default Value: \_\_exp133value\_\_  
Description: Expansion Module 1 key 33value

P60162  
EPM Default Value: \_\_exp133label\_\_  
Description: Expansion Module 1 key 33label

P60163  
EPM Default Value: \_\_exp133acct\_\_  
Description: Expansion Module 1 key 33account

P60164  
EPM Default Value: \_\_exp133pu\_\_  
Description: Expansion Module 1 key 33pickup up

P60165  
EPM Default Value: \_\_exp134type\_\_  
Description: Expansion Module 1 key 34type

P60166  
EPM Default Value: \_\_exp134value\_\_  
Description: Expansion Module 1 key 34value

P60167  
EPM Default Value: \_\_exp134label\_\_  
Description: Expansion Module 1 key 34label

P60168  
EPM Default Value: \_\_exp134acct\_\_  
Description: Expansion Module 1 key 34account

P60169  
EPM Default Value: \_\_exp134pu\_\_  
Description: Expansion Module 1 key 34pickup up

P60170  
EPM Default Value: \_\_exp135type\_\_  
Description: Expansion Module 1 key 35type

P60171  
EPM Default Value: \_\_exp135value\_\_  
Description: Expansion Module 1 key 35value

P60172  
EPM Default Value: \_\_exp135label\_\_  
Description: Expansion Module 1 key 35label

P60173  
EPM Default Value: \_\_exp135acct\_\_  
Description: Expansion Module 1 key 35account

P60174  
EPM Default Value: \_\_exp135pu\_\_  
Description: Expansion Module 1 key 35pickup up

P60175  
EPM Default Value: \_\_exp136type\_\_  
Description: Expansion Module 1 key 36type

P60176  
EPM Default Value: \_\_exp136value\_\_  
Description: Expansion Module 1 key 36value

P60177  
EPM Default Value: \_\_exp136label\_\_  
Description: Expansion Module 1 key 36label

P60178  
EPM Default Value: \_\_exp136acct\_\_  
Description: Expansion Module 1 key 36account

P60179  
EPM Default Value: \_\_exp136pu\_\_  
Description: Expansion Module 1 key 36pickup up

P60180  
EPM Default Value: \_\_exp137type\_\_  
Description: Expansion Module 1 key 37type

P60181  
EPM Default Value: \_\_exp137value\_\_  
Description: Expansion Module 1 key 37value

P60182  
EPM Default Value: \_\_exp137label\_\_  
Description: Expansion Module 1 key 37label

P60183  
EPM Default Value: \_\_exp137acct\_\_  
Description: Expansion Module 1 key 37account

P60184  
EPM Default Value: \_\_exp137pu\_\_  
Description: Expansion Module 1 key 37pickup up

P60185  
EPM Default Value: \_\_exp138type\_\_  
Description: Expansion Module 1 key 38type

P60186  
EPM Default Value: \_\_exp138value\_\_  
Description: Expansion Module 1 key 38value

P60187  
EPM Default Value: \_\_exp138label\_\_  
Description: Expansion Module 1 key 38label

P60188  
EPM Default Value: \_\_exp138acct\_\_  
Description: Expansion Module 1 key 38account

P60189  
EPM Default Value: \_\_exp138pu\_\_  
Description: Expansion Module 1 key 38pickup up

P60190  
EPM Default Value: \_\_exp139type\_\_  
Description: Expansion Module 1 key 39type

P60191  
EPM Default Value: \_\_exp139value\_\_  
Description: Expansion Module 1 key 39value

P60192  
EPM Default Value: \_\_exp139label\_\_  
Description: Expansion Module 1 key 39label

P60193  
EPM Default Value: \_\_exp139acct\_\_  
Description: Expansion Module 1 key 39account

P60194  
EPM Default Value: \_\_exp139pu\_\_  
Description: Expansion Module 1 key 39pickup up

P60195  
EPM Default Value: \_\_exp140type\_\_  
Description: Expansion Module 1 key 40type

P60196  
EPM Default Value: \_\_exp140value\_\_  
Description: Expansion Module 1 key 40value

P60197  
EPM Default Value: \_\_exp140label\_\_  
Description: Expansion Module 1 key 40label

P60198  
EPM Default Value: \_\_exp140acct\_\_  
Description: Expansion Module 1 key 40account

P60199  
EPM Default Value: \_\_exp140pu\_\_  
Description: Expansion Module 1 key 40pickup up

P61000  
EPM Default Value: \_\_exp21type\_\_  
Description: Expansion Module 6 key 1type

P61001  
EPM Default Value: \_\_exp21value\_\_  
Description: Expansion Module 6 key 1value

P61002  
EPM Default Value: \_\_exp21label\_\_  
Description: Expansion Module 6 key 1label

P61003  
EPM Default Value: \_\_exp21acct\_\_  
Description: Expansion Module 6 key 1account

P61004  
EPM Default Value: \_\_exp21pu\_\_  
Description: Expansion Module 6 key 1pickup up

P61005  
EPM Default Value: \_\_exp22type\_\_  
Description: Expansion Module 6 key 2type

P61006  
EPM Default Value: \_\_exp22value\_\_  
Description: Expansion Module 6 key 2value

P61007  
EPM Default Value: \_\_exp22label\_\_  
Description: Expansion Module 6 key 2label

P61008  
EPM Default Value: \_\_exp22acct\_\_  
Description: Expansion Module 6 key 2account

P61009  
EPM Default Value: \_\_exp22pu\_\_  
Description: Expansion Module 6 key 2pickup up

P61010  
EPM Default Value: \_\_exp23type\_\_  
Description: Expansion Module 6 key 3type

P61011  
EPM Default Value: \_\_exp23value\_\_  
Description: Expansion Module 6 key 3value

P61012  
EPM Default Value: \_\_exp23label\_\_  
Description: Expansion Module 6 key 3label

P61013  
EPM Default Value: \_\_exp23acct\_\_  
Description: Expansion Module 6 key 3account

P61014  
EPM Default Value: \_\_exp23pu\_\_  
Description: Expansion Module 6 key 3pickup up

P61015  
EPM Default Value: \_\_exp24type\_\_  
Description: Expansion Module 6 key 4type

P61016  
EPM Default Value: \_\_exp24value\_\_  
Description: Expansion Module 6 key 4value

P61017  
EPM Default Value: \_\_exp24label\_\_  
Description: Expansion Module 6 key 4label

P61018  
EPM Default Value: \_\_exp24acct\_\_  
Description: Expansion Module 6 key 4account

P61019  
EPM Default Value: \_\_exp24pu\_\_  
Description: Expansion Module 6 key 4pickup up

P61020  
EPM Default Value: \_\_exp25type\_\_  
Description: Expansion Module 6 key 5type

P61021  
EPM Default Value: \_\_exp25value\_\_  
Description: Expansion Module 6 key 5value

P61022  
EPM Default Value: \_\_exp25label\_\_  
Description: Expansion Module 6 key 5label

P61023  
EPM Default Value: \_\_exp25acct\_\_  
Description: Expansion Module 6 key 5account

P61024  
EPM Default Value: \_\_exp25pu\_\_  
Description: Expansion Module 6 key 5pickup up

P61025  
EPM Default Value: \_\_exp26type\_\_  
Description: Expansion Module 6 key 6type

P61026  
EPM Default Value: \_\_exp26value\_\_  
Description: Expansion Module 6 key 6value

P61027  
EPM Default Value: \_\_exp26label\_\_  
Description: Expansion Module 6 key 6label

P61028  
EPM Default Value: \_\_exp26acct\_\_  
Description: Expansion Module 6 key 6account

P61029  
EPM Default Value: \_\_exp26pu\_\_  
Description: Expansion Module 6 key 6pickup up

P61030  
EPM Default Value: \_\_exp27type\_\_  
Description: Expansion Module 6 key 7type

P61031  
EPM Default Value: \_\_exp27value\_\_  
Description: Expansion Module 6 key 7value

P61032  
EPM Default Value: \_\_exp27label\_\_  
Description: Expansion Module 6 key 7label

P61033  
EPM Default Value: \_\_exp27acct\_\_  
Description: Expansion Module 6 key 7account

P61034  
EPM Default Value: \_\_exp27pu\_\_  
Description: Expansion Module 6 key 7pickup up

P61035  
EPM Default Value: \_\_exp28type\_\_  
Description: Expansion Module 6 key 8type

P61036  
EPM Default Value: \_\_exp28value\_\_  
Description: Expansion Module 6 key 8value

P61037  
EPM Default Value: \_\_exp28label\_\_  
Description: Expansion Module 6 key 8label

P61038  
EPM Default Value: \_\_exp28acct\_\_  
Description: Expansion Module 6 key 8account

P61039  
EPM Default Value: \_\_exp28pu\_\_  
Description: Expansion Module 6 key 8pickup up

P61040  
EPM Default Value: \_\_exp29type\_\_  
Description: Expansion Module 6 key 9type

P61041  
EPM Default Value: \_\_exp29value\_\_  
Description: Expansion Module 6 key 9value

P61042  
EPM Default Value: \_\_exp29label\_\_  
Description: Expansion Module 6 key 9label

P61043  
EPM Default Value: \_\_exp29acct\_\_  
Description: Expansion Module 6 key 9account

P61044  
EPM Default Value: \_\_exp29pu\_\_  
Description: Expansion Module 6 key 9pickup up

P61045  
EPM Default Value: \_\_exp210type\_\_  
Description: Expansion Module 6 key 10type

P61046  
EPM Default Value: \_\_exp210value\_\_  
Description: Expansion Module 6 key 10value

P61047  
EPM Default Value: \_\_exp210label\_\_  
Description: Expansion Module 6 key 10label

P61048  
EPM Default Value: \_\_exp210acct\_\_  
Description: Expansion Module 6 key 10account

P61049  
EPM Default Value: \_\_exp210pu\_\_  
Description: Expansion Module 6 key 10pickup up

P61050  
EPM Default Value: \_\_exp211type\_\_  
Description: Expansion Module 6 key 11type

P61051  
EPM Default Value: \_\_exp211value\_\_  
Description: Expansion Module 6 key 11value

P61052  
EPM Default Value: \_\_exp211label\_\_  
Description: Expansion Module 6 key 11label

P61053  
EPM Default Value: \_\_exp211acct\_\_  
Description: Expansion Module 6 key 11account

P61054  
EPM Default Value: \_\_exp211pu\_\_  
Description: Expansion Module 6 key 11pickup up

P61055  
EPM Default Value: \_\_exp212type\_\_  
Description: Expansion Module 6 key 12type

P61056  
EPM Default Value: \_\_exp212value\_\_  
Description: Expansion Module 6 key 12value

P61057  
EPM Default Value: \_\_exp212label\_\_  
Description: Expansion Module 6 key 12label

P61058  
EPM Default Value: \_\_exp212acct\_\_  
Description: Expansion Module 6 key 12account

P61059  
EPM Default Value: \_\_exp212pu\_\_  
Description: Expansion Module 6 key 12pickup up

P61060  
EPM Default Value: \_\_exp213type\_\_  
Description: Expansion Module 6 key 13type

P61061  
EPM Default Value: \_\_exp213value\_\_  
Description: Expansion Module 6 key 13value

P61062  
EPM Default Value: \_\_exp213label\_\_  
Description: Expansion Module 6 key 13label

P61063  
EPM Default Value: \_\_exp213acct\_\_  
Description: Expansion Module 6 key 13account

P61064  
EPM Default Value: \_\_exp213pu\_\_  
Description: Expansion Module 6 key 13pickup up

P61065  
EPM Default Value: \_\_exp214type\_\_  
Description: Expansion Module 6 key 14type



P61066  
EPM Default Value: \_\_exp214value\_\_  
Description: Expansion Module 6 key 14value

P61067  
EPM Default Value: \_\_exp214label\_\_  
Description: Expansion Module 6 key 14label

P61068  
EPM Default Value: \_\_exp214acct\_\_  
Description: Expansion Module 6 key 14account

P61069  
EPM Default Value: \_\_exp214pu\_\_  
Description: Expansion Module 6 key 14pickup up

P61070  
EPM Default Value: \_\_exp215type\_\_  
Description: Expansion Module 6 key 15type

P61071  
EPM Default Value: \_\_exp215value\_\_  
Description: Expansion Module 6 key 15value

P61072  
EPM Default Value: \_\_exp215label\_\_  
Description: Expansion Module 6 key 15label

P61073  
EPM Default Value: \_\_exp215acct\_\_  
Description: Expansion Module 6 key 15account

P61074  
EPM Default Value: \_\_exp215pu\_\_  
Description: Expansion Module 6 key 15pickup up

P61075  
EPM Default Value: \_\_exp216type\_\_  
Description: Expansion Module 6 key 16type

P61076  
EPM Default Value: \_\_exp216value\_\_  
Description: Expansion Module 6 key 16value

P61077  
EPM Default Value: \_\_exp216label\_\_  
Description: Expansion Module 6 key 16label

P61078  
EPM Default Value: \_\_exp216acct\_\_  
Description: Expansion Module 6 key 16account

P61079  
EPM Default Value: \_\_exp216pu\_\_  
Description: Expansion Module 6 key 16pickup up

P61080  
EPM Default Value: \_\_exp217type\_\_  
Description: Expansion Module 6 key 17type

P61081  
EPM Default Value: \_\_exp217value\_\_  
Description: Expansion Module 6 key 17value

P61082  
EPM Default Value: \_\_exp217label\_\_  
Description: Expansion Module 6 key 17label

P61083  
EPM Default Value: \_\_exp217acct\_\_  
Description: Expansion Module 6 key 17account

P61084  
EPM Default Value: \_\_exp217pu\_\_  
Description: Expansion Module 6 key 17pickup up

P61085  
EPM Default Value: \_\_exp218type\_\_  
Description: Expansion Module 6 key 18type

P61086  
EPM Default Value: \_\_exp218value\_\_  
Description: Expansion Module 6 key 18value

P61087  
EPM Default Value: \_\_exp218label\_\_  
Description: Expansion Module 6 key 18label

P61088  
EPM Default Value: \_\_exp218acct\_\_  
Description: Expansion Module 6 key 18account

P61089  
EPM Default Value: \_\_exp218pu\_\_  
Description: Expansion Module 6 key 18pickup up

P61090  
EPM Default Value: \_\_exp219type\_\_  
Description: Expansion Module 6 key 19type

P61091  
EPM Default Value: \_\_exp219value\_\_  
Description: Expansion Module 6 key 19value

P61092  
EPM Default Value: \_\_exp219label\_\_  
Description: Expansion Module 6 key 19label

P61093  
EPM Default Value: \_\_exp219acct\_\_  
Description: Expansion Module 6 key 19account

P61094  
EPM Default Value: \_\_exp219pu\_\_  
Description: Expansion Module 6 key 19pickup up

P61095  
EPM Default Value: \_\_exp220type\_\_  
Description: Expansion Module 6 key 20type

P61096  
EPM Default Value: \_\_exp220value\_\_  
Description: Expansion Module 6 key 20value

P61097  
EPM Default Value: \_\_exp220label\_\_  
Description: Expansion Module 6 key 20label

P61098  
EPM Default Value: \_\_exp220acct\_\_  
Description: Expansion Module 6 key 20account

P61099  
EPM Default Value: \_\_exp220pu\_\_  
Description: Expansion Module 6 key 20pickup up

P61100  
EPM Default Value: \_\_exp221type\_\_  
Description: Expansion Module 6 key 21type

P61101  
EPM Default Value: \_\_exp221value\_\_  
Description: Expansion Module 6 key 21value

P61102  
EPM Default Value: \_\_exp221label\_\_  
Description: Expansion Module 6 key 21label

P61103  
EPM Default Value: \_\_exp221acct\_\_  
Description: Expansion Module 6 key 21account

P61104  
EPM Default Value: \_\_exp221pu\_\_  
Description: Expansion Module 6 key 21pickup up

P61105  
EPM Default Value: \_\_exp222type\_\_  
Description: Expansion Module 6 key 22type

P61106  
EPM Default Value: \_\_exp222value\_\_  
Description: Expansion Module 6 key 22value

P61107  
EPM Default Value: \_\_exp222label\_\_  
Description: Expansion Module 6 key 22label

P61108  
EPM Default Value: \_\_exp222acct\_\_  
Description: Expansion Module 6 key 22account

P61109  
EPM Default Value: \_\_exp222pu\_\_  
Description: Expansion Module 6 key 22pickup up

P61110  
EPM Default Value: \_\_exp223type\_\_  
Description: Expansion Module 6 key 23type

P61111  
EPM Default Value: \_\_exp223value\_\_  
Description: Expansion Module 6 key 23value

P61112  
EPM Default Value: \_\_exp223label\_\_  
Description: Expansion Module 6 key 23label

P61113  
EPM Default Value: \_\_exp223acct\_\_  
Description: Expansion Module 6 key 23account

P61114  
EPM Default Value: \_\_exp223pu\_\_  
Description: Expansion Module 6 key 23pickup up

P61115  
EPM Default Value: \_\_exp224type\_\_  
Description: Expansion Module 6 key 24type

P61116  
EPM Default Value: \_\_exp224value\_\_  
Description: Expansion Module 6 key 24value

P61117  
EPM Default Value: \_\_exp224label\_\_  
Description: Expansion Module 6 key 24label

P61118  
EPM Default Value: \_\_exp224acct\_\_  
Description: Expansion Module 6 key 24account

P61119  
EPM Default Value: \_\_exp224pu\_\_  
Description: Expansion Module 6 key 24pickup up

P61120  
EPM Default Value: \_\_exp225type\_\_  
Description: Expansion Module 6 key 25type

P61121  
EPM Default Value: \_\_exp225value\_\_  
Description: Expansion Module 6 key 25value

P61122  
EPM Default Value: \_\_exp225label\_\_  
Description: Expansion Module 6 key 25label

P61123  
EPM Default Value: \_\_exp225acct\_\_  
Description: Expansion Module 6 key 25account

P61124  
EPM Default Value: \_\_exp225pu\_\_  
Description: Expansion Module 6 key 25pickup up

P61125  
EPM Default Value: \_\_exp226type\_\_  
Description: Expansion Module 6 key 26type

P61126  
EPM Default Value: \_\_exp226value\_\_  
Description: Expansion Module 6 key 26value

P61127  
EPM Default Value: \_\_exp226label\_\_  
Description: Expansion Module 6 key 26label

P61128  
EPM Default Value: \_\_exp226acct\_\_  
Description: Expansion Module 6 key 26account

P61129  
EPM Default Value: \_\_exp226pu\_\_  
Description: Expansion Module 6 key 26pickup up

P61130  
EPM Default Value: \_\_exp227type\_\_  
Description: Expansion Module 6 key 27type

P61131  
EPM Default Value: \_\_exp227value\_\_  
Description: Expansion Module 6 key 27value

P61132  
EPM Default Value: \_\_exp227label\_\_  
Description: Expansion Module 6 key 27label

P61133  
EPM Default Value: \_\_exp227acct\_\_  
Description: Expansion Module 6 key 27account

P61134  
EPM Default Value: \_\_exp227pu\_\_  
Description: Expansion Module 6 key 27pickup up

P61135  
EPM Default Value: \_\_exp228type\_\_  
Description: Expansion Module 6 key 28type

P61136  
EPM Default Value: \_\_exp228value\_\_  
Description: Expansion Module 6 key 28value

P61137  
EPM Default Value: \_\_exp228label\_\_  
Description: Expansion Module 6 key 28label

P61138  
EPM Default Value: \_\_exp228acct\_\_  
Description: Expansion Module 6 key 28account

P61139  
EPM Default Value: \_\_exp228pu\_\_  
Description: Expansion Module 6 key 28pickup up

P61140  
EPM Default Value: \_\_exp229type\_\_  
Description: Expansion Module 6 key 29type

P61141  
EPM Default Value: \_\_exp229value\_\_  
Description: Expansion Module 6 key 29value

P61142  
EPM Default Value: \_\_exp229label\_\_  
Description: Expansion Module 6 key 29label

P61143  
EPM Default Value: \_\_exp229acct\_\_  
Description: Expansion Module 6 key 29account

P61144  
EPM Default Value: \_\_exp229pu\_\_  
Description: Expansion Module 6 key 29pickup up

P61145  
EPM Default Value: \_\_exp230type\_\_  
Description: Expansion Module 6 key 30type

P61146  
EPM Default Value: \_\_exp230value\_\_  
Description: Expansion Module 6 key 30value

P61147  
EPM Default Value: \_\_exp230label\_\_  
Description: Expansion Module 6 key 30label

P61148  
EPM Default Value: \_\_exp230acct\_\_  
Description: Expansion Module 6 key 30account

P61149  
EPM Default Value: \_\_exp230pu\_\_  
Description: Expansion Module 6 key 30pickup up

P61150  
EPM Default Value: \_\_exp231type\_\_  
Description: Expansion Module 6 key 31type

P61151  
EPM Default Value: \_\_exp231value\_\_  
Description: Expansion Module 6 key 31value

P61152  
EPM Default Value: \_\_exp231label\_\_  
Description: Expansion Module 6 key 31label

P61153  
EPM Default Value: \_\_exp231acct\_\_  
Description: Expansion Module 6 key 31account

P61154  
EPM Default Value: \_\_exp231pu\_\_  
Description: Expansion Module 6 key 31pickup up

P61155  
EPM Default Value: \_\_exp232type\_\_  
Description: Expansion Module 6 key 32type

P61156  
EPM Default Value: \_\_exp232value\_\_  
Description: Expansion Module 6 key 32value

P61157  
EPM Default Value: \_\_exp232label\_\_  
Description: Expansion Module 6 key 32label

P61158  
EPM Default Value: \_\_exp232acct\_\_  
Description: Expansion Module 6 key 32account

P61159  
EPM Default Value: \_\_exp232pu\_\_  
Description: Expansion Module 6 key 32pickup up

P61160  
EPM Default Value: \_\_exp233type\_\_  
Description: Expansion Module 6 key 33type

P61161  
EPM Default Value: \_\_exp233value\_\_  
Description: Expansion Module 6 key 33value

P61162  
EPM Default Value: \_\_exp233label\_\_  
Description: Expansion Module 6 key 33label

P61163  
EPM Default Value: \_\_exp233acct\_\_  
Description: Expansion Module 6 key 33account

P61164  
EPM Default Value: \_\_exp233pu\_\_  
Description: Expansion Module 6 key 33pickup up

P61165  
EPM Default Value: \_\_exp234type\_\_  
Description: Expansion Module 6 key 34type

P61166  
EPM Default Value: \_\_exp234value\_\_  
Description: Expansion Module 6 key 34value

P61167  
EPM Default Value: \_\_exp234label\_\_  
Description: Expansion Module 6 key 34label

P61168  
EPM Default Value: \_\_exp234acct\_\_  
Description: Expansion Module 6 key 34account

P61169  
EPM Default Value: \_\_exp234pu\_\_  
Description: Expansion Module 6 key 34pickup up

P61170  
EPM Default Value: \_\_exp235type\_\_  
Description: Expansion Module 6 key 35type

P61171  
EPM Default Value: \_\_exp235value\_\_  
Description: Expansion Module 6 key 35value

P61172  
EPM Default Value: \_\_exp235label\_\_  
Description: Expansion Module 6 key 35label

P61173  
EPM Default Value: \_\_exp235acct\_\_  
Description: Expansion Module 6 key 35account

P61174  
EPM Default Value: \_\_exp235pu\_\_  
Description: Expansion Module 6 key 35pickup up

P61175  
EPM Default Value: \_\_exp236type\_\_  
Description: Expansion Module 6 key 36type

P61176  
EPM Default Value: \_\_exp236value\_\_  
Description: Expansion Module 6 key 36value

P61177  
EPM Default Value: \_\_exp236label\_\_  
Description: Expansion Module 6 key 36label

P61178  
EPM Default Value: \_\_exp236acct\_\_  
Description: Expansion Module 6 key 36account

P61179  
EPM Default Value: \_\_exp236pu\_\_  
Description: Expansion Module 6 key 36pickup up

P61180  
EPM Default Value: \_\_exp237type\_\_  
Description: Expansion Module 6 key 37type

P61181  
EPM Default Value: \_\_exp237value\_\_  
Description: Expansion Module 6 key 37value

P61182  
EPM Default Value: \_\_exp237label\_\_  
Description: Expansion Module 6 key 37label

P61183  
EPM Default Value: \_\_exp237acct\_\_  
Description: Expansion Module 6 key 37account

P61184  
EPM Default Value: \_\_exp237pu\_\_  
Description: Expansion Module 6 key 37pickup up

P61185  
EPM Default Value: \_\_exp238type\_\_  
Description: Expansion Module 6 key 38type

P61186  
EPM Default Value: \_\_exp238value\_\_  
Description: Expansion Module 6 key 38value

P61187  
EPM Default Value: \_\_exp238label\_\_  
Description: Expansion Module 6 key 38label

P61188  
EPM Default Value: \_\_exp238acct\_\_  
Description: Expansion Module 6 key 38account

P61189  
EPM Default Value: \_\_exp238pu\_\_  
Description: Expansion Module 6 key 38pickup up

P61190  
EPM Default Value: \_\_exp239type\_\_  
Description: Expansion Module 6 key 39type

P61191  
EPM Default Value: \_\_exp239value\_\_  
Description: Expansion Module 6 key 39value

P61192  
EPM Default Value: \_\_exp239label\_\_  
Description: Expansion Module 6 key 39label

P61193  
EPM Default Value: \_\_exp239acct\_\_  
Description: Expansion Module 6 key 39account

P61194  
EPM Default Value: \_\_exp239pu\_\_  
Description: Expansion Module 6 key 39pickup up

P61195  
EPM Default Value: \_\_exp240type\_\_  
Description: Expansion Module 6 key 40type

P61196  
EPM Default Value: \_\_exp240value\_\_  
Description: Expansion Module 6 key 40value

P61197  
EPM Default Value: \_\_exp240label\_\_  
Description: Expansion Module 6 key 40label

P61198  
EPM Default Value: \_\_exp240acct\_\_  
Description: Expansion Module 6 key 40account

P61199  
EPM Default Value: \_\_exp240pu\_\_  
Description: Expansion Module 6 key 40pickup up

P20052  
EPM Default Value: \_\_background\_\_  
Description: Background image url

P8660  
EPM Default Value: \_\_enableBackground\_\_  
Description: Enable background image

P20178  
EPM Default Value: \_\_vpnUrl\_\_  
Description: VPN config file

P20082  
EPM Default Value: \_\_voicemessageStatusEnable\_\_  
Description: Voice Message Status

P20073  
EPM Default Value: 1  
Description: Redial Mode

P20021  
EPM Default Value: \_\_multicastAddress1\_\_  
Description: Multicast Address

P20022  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20023  
EPM Default Value: \_\_multicastAddress2\_\_  
Description: Multicast Address

P20024  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20025  
EPM Default Value: \_\_multicastAddress3\_\_  
Description: Multicast Address



P20026  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20027  
EPM Default Value: \_\_multicastAddress4\_\_  
Description: Multicast Address

P20028  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20029  
EPM Default Value: \_\_multicastAddress5\_\_  
Description: Multicast Address

P20030  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20031  
EPM Default Value: \_\_multicastAddress6\_\_  
Description: Multicast Address

P20032  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20033  
EPM Default Value: \_\_multicastAddress7\_\_  
Description: Multicast Address

P20034  
EPM Default Value: Multicast 7  
Description: Multicast Label

P20035  
EPM Default Value: \_\_multicastAddress8\_\_  
Description: Multicast Address

P20036  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20037  
EPM Default Value: \_\_multicastAddress9\_\_  
Description: Multicast Address

P20038  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20039  
EPM Default Value: \_\_multicastAddress10\_\_  
Description: Multicast Address

P20040  
EPM Default Value: \_\_line1Name\_\_  
Description: Multicast Label

P20041  
EPM Default Value: 0  
Description: Multicast Barge

P20042  
EPM Default Value: 0  
Description: Multicast Priority

P20019  
EPM Default Value: \_\_headset\_\_  
Description: HeadSet Priority

P20020  
EPM Default Value: \_\_headsetRing\_\_  
Description: Ringer Device For HeadSet

P8850  
EPM Default Value: \_\_callwaiting\_\_  
Description: Call Waiting Tone Enable/Disable

P1399  
EPM Default Value: ring1  
Description: Preference.AlertInternalText

P1402  
EPM Default Value: 1  
Description: Preference.AlertInternalRinger

P1400  
EPM Default Value: ring2  
Description: Preference.AlertExternalText

P1403  
EPM Default Value: 2  
Description: Preference.AlertExternalText

P1401  
EPM Default Value: ring3  
Description: Preference.AlertGroupText

P1404  
EPM Default Value: 3  
Description: Preference.AlertGroupText

P20059  
EPM Default Value: ring4  
Description: Preference.AlertGroupText

P20066  
EPM Default Value: 4  
Description: Preference.AlertGroupText

P20060  
EPM Default Value: ring5  
Description: Preference.AlertGroupText

P20067  
EPM Default Value: 5  
Description: Preference.AlertGroupText

P20061  
EPM Default Value: ring6  
Description: Preference.AlertGroupText

P20068  
EPM Default Value: 6  
Description: Preference.AlertGroupText

P20062  
EPM Default Value: ring7  
Description: Preference.AlertGroupText

P20069  
EPM Default Value: 7  
Description: Preference.AlertGroupText

P20063  
EPM Default Value: ring8  
Description: Preference.AlertGroupText

P20070  
EPM Default Value: 8  
Description: Preference.AlertGroupText

P20064  
EPM Default Value: ring9  
Description: Preference.AlertGroupText

P20071  
EPM Default Value: 9  
Description: Preference.AlertGroupText

P20065  
EPM Default Value: ring10  
Description: Preference.AlertGroupText

P20072  
EPM Default Value: 10  
Description: Preference.AlertGroupText

P8751  
EPM Default Value: 1  
Description: SoftKeyLayout.CustomSoftkey

P20991  
EPM Default Value: \_\_provisionAddress\_\_/cfg\_\_ext\_\_-states.xml  
Description: Softkey Layout url

P20043  
EPM Default Value: \_\_sk1label\_\_  
Description: ProgrammableKey1.Label

P20044  
EPM Default Value: \_\_sk2label\_\_  
Description: ProgrammableKey2.Label

P20045  
EPM Default Value: \_\_sk3label\_\_  
Description: ProgrammableKey3.Label

P20046  
EPM Default Value: \_\_sk4label\_\_  
Description: ProgrammableKey4.Label

P43213  
EPM Default Value: 0  
Description: TranKey.Type

P20118  
EPM Default Value: 1  
Description: VoiceMailTone

P20051  
EPM Default Value: \_\_sslimage\_\_  
Description: ScreenSaverUpgradeUrl

P20058  
EPM Default Value: \_\_countryTone\_\_  
Description: Country tone selection

P967  
EPM Default Value: \_\_backupDestination\_\_  
Description: Account1.FailoverSipserver

P48  
EPM Default Value: \_\_outboundDestination\_\_  
Description: Account1.OutboundProxy

P20047  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account1.BackUpOutboundProxy

P8683  
EPM Default Value: \_\_backlightTimeout\_\_  
Description: Backlight Time

P20157

EPM Default Value: 3

Description: Caller Display Source

P20643

EPM Default Value: \_\_backlightActive\_\_

Description: Backlight Active Level

P20642

EPM Default Value: \_\_backlightInActive\_\_

Description: Backlight In-Active Level

P23253

EPM Default Value: \_\_labelScroll\_\_

Description: Enable line key label scrolling

P20934

EPM Default Value: 1

Description: Enable EHS version number

P8684

EPM Default Value: \_\_dhcpVlan\_\_

Description: DHCP on VLAN

P23259

EPM Default Value: \_\_visualAlert\_\_

Description: BLF Visual Alert keys

P23260

EPM Default Value: \_\_audioAlert\_\_

Description: BLF Audio Alert Keys

P5430

EPM Default Value: \_\_ldapNameFilter\_\_

Description: LDAP Name Filter

P5431

EPM Default Value: \_\_ldapNumberFilter\_\_

Description: LDAP Number Filter

P5432

EPM Default Value: \_\_ldapServerAddress\_\_

Description: LDAP Server Address

P5433

EPM Default Value: \_\_ldapPort\_\_

Description: LDAP Port

P5434

EPM Default Value: \_\_ldapBase\_\_

Description: LDAP Base

P5435

EPM Default Value: \_\_ldapUsername\_\_

Description: LDAP User Name

P5436

EPM Default Value: \_\_ldapPassword\_\_

Description: LDAP Password

P5437

EPM Default Value: \_\_ldapMaxHits\_\_

Description: LDAP Max Hits

P5440

EPM Default Value: \_\_ldapDisplayName\_\_

Description: LDAP Display Name

P5442

EPM Default Value: \_\_ldapSearchDelay\_\_

Description: LDAP Search Delay

P5441

EPM Default Value: \_\_ldapProtocol\_\_

Description: LDAP Protocol

P5443

EPM Default Value: \_\_ldapLookupCall\_\_

Description: LDAP Lookup For Incoming Call

P5444

EPM Default Value: \_\_ldapSort\_\_

Description: LDAP Sorting Results

P23136

EPM Default Value: \_\_ldapNameAttributes\_\_

Description: LDAP Name Attributes

P23137

EPM Default Value: \_\_ldapNumberAttributes\_\_

Description: LDAP Number Attributes

P23254

EPM Default Value: \_\_shortPressIdleState\_\_

Description: BLF Press Setting Short Press Idle

P23255

EPM Default Value: \_\_shortPressInUseState\_\_

Description: BLF Press Setting Short Press In Use

P23256

EPM Default Value: \_\_longPressIdleState\_\_

Description: BLF Press Setting Long Press Idle

P23257

EPM Default Value: \_\_longPressInUseState\_\_

Description: BLF Press Setting Long Press In Use

P23258

EPM Default Value: \_\_longPressRingState\_\_

Description: BLF Press Setting Long Press Ring

P20018

EPM Default Value: \_\_dialFirstDigit\_\_

Description: Dial First Digit

P23263

EPM Default Value: \_\_logoled\_\_

Description: Logo LED status - 0 tie to backlight, 1 always on, 2 always off

P23261

EPM Default Value: \_\_voicemailkey\_\_

Description: Voicemail key type - 0 Feature Code, 1 XML

P23262

EPM Default Value: \_\_voicemailkeyValue\_\_

Description: Voicemail key value - based on voicemail key type

P23274

EPM Default Value: \_\_activecallStatusEnable\_\_

Description: LEDStatus Active Call Status

P23264

EPM Default Value: \_\_ringingStatusSpeed\_\_

Description: LED Status Ringing Speed

P23265

EPM Default Value: \_\_ringingStatusColor\_\_

Description: LED Status Ringing Light Color

P23266

EPM Default Value: \_\_voicemailStatusSpeed\_\_

Description: LED Status Voice Msg Speed

P23267  
EPM Default Value: \_\_voicemailStatusColor\_\_  
Description: LED Status Voice Msg Light Color

P23268  
EPM Default Value: \_\_misscallsStatusSpeed\_\_  
Description: LED Status Miss Call Speed

P23269  
EPM Default Value: \_\_misscallsStatusColor\_\_  
Description: LED Status Miss Call Light Color

P23270  
EPM Default Value: \_\_powerStatusSpeed\_\_  
Description: LED Status Power Speed

P23271  
EPM Default Value: \_\_powerStatusColor\_\_  
Description: LED Status Power Light Color

P23272  
EPM Default Value: \_\_activecallStatusSpeed\_\_  
Description: LED Status Active Call Speed

P23273  
EPM Default Value: \_\_activecallStatusColor\_\_  
Description: LED Status Active Call Light Color

P20935  
EPM Default Value: \_\_confCallRelease\_\_  
Description: Three way call release type.

P43206  
EPM Default Value: 49  
Description: Left arrow key type.

P43207  
EPM Default Value: 50  
Description: Right arrow key type.

P43208  
EPM Default Value: 40  
Description: OK key type.

P43204  
EPM Default Value: 36  
Description: Up arrow key type.

P43205  
EPM Default Value: 37  
Description: Down arrow key type.

P43209  
EPM Default Value: 0  
Description: Cancel key type.

P43210  
EPM Default Value: 0  
Description: Conference key type.

P43211  
EPM Default Value: 0  
Description: Hold key type.

P43212  
EPM Default Value: 0  
Description: Mute key type.

P43213  
EPM Default Value: 0  
Description: Transfer key type.

P43214  
EPM Default Value: 1  
Description: Speaker key type.

P43215  
EPM Default Value: 1  
Description: Headset key type.

P43216  
EPM Default Value: 1  
Description: Voicemail key type.

P43217  
EPM Default Value: \_\_menukey\_\_  
Description: Menu key type.

P43418  
EPM Default Value: \_\_menupin\_\_  
Description: Menu PIN.

P43218  
EPM Default Value: 1  
Description: Volume Up key type.

P43219  
EPM Default Value: 1  
Description: Volume Down key type.

P20360  
EPM Default Value: \_\_line5Enable\_\_  
Description: Account 5 Active

P20362  
EPM Default Value: \_\_line5Dest\_\_:\_\_line5ServerPort\_\_  
Description: Account 5 Sipserver

P20364  
EPM Default Value: \_\_backupDestination\_\_  
Description: Account 5 Failover Sipserver

P20366  
EPM Default Value:  
Description: Account 5 Second Failover Sipserver

P20368  
EPM Default Value: 0  
Description: Account 5 Prefer Primary Server

P20370  
EPM Default Value: \_\_outboundDestination\_\_  
Description: Account 5 Outbound Proxy

P20372  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account 5 Back Up Outbound Proxy

P20374  
EPM Default Value: \_\_transport5\_\_  
Description: Account 5 Sip Transport

P20376  
EPM Default Value: 2  
Description: Account 5 Nat Traversal

P20378  
EPM Default Value: \_\_line5Name\_\_  
Description: Account 5 Label

P1704  
EPM Default Value: \_\_line5Ext\_\_  
Description: Account 5 Sip User Id

P1705  
EPM Default Value: \_\_line5Ext\_\_  
Description: Account 5 Authenticate ID

P1706  
EPM Default Value: \_\_line5Pass\_\_  
Description: Account 5 Authenticate Password

P1707  
EPM Default Value: \_\_line5Name\_\_  
Description: Account 5 Display Name

P20380  
EPM Default Value: 0  
Description: Account 5 Dns Mode

P20382  
EPM Default Value: 0  
Description: Account 5 User Id Is Phone Number

P20384  
EPM Default Value: \_\_line5Enable\_\_  
Description: Account 5 Sip Registration

P20386  
EPM Default Value: 0  
Description: Account 5 Unregister On Reboot

P20388  
EPM Default Value: 15  
Description: Account 5 Register Expiration

P1113  
EPM Default Value: 1  
Description: Account 5 Out Call Without Reg

P1713  
EPM Default Value: \_\_line5extPort\_\_  
Description: Account 5 Local Sip Port

P20390  
EPM Default Value: 0  
Description: Account 5 Use Random Port

P1726  
EPM Default Value: \_\_voicemail\_\_  
Description: Account 5 Voice Mail Id

P140  
EPM Default Value: 0  
Description: Account 5 RPort

P1104  
EPM Default Value: 1  
Description: Account 5 RFC2543 Hold

P20476  
EPM Default Value: 0  
Description: Account 5 Connect Mode

P20392  
EPM Default Value: \_\_line5Codec1\_\_  
Description: Account 5 Choice 1

P20394  
EPM Default Value: \_\_line5Codec2\_\_  
Description: Account 5 Choice 2

P20396  
EPM Default Value: \_\_line5Codec3\_\_  
Description: Account 5 Choice 3



P20398  
EPM Default Value: \_\_line5Codec4\_\_  
Description: Account 5 Choice 4

P20400  
EPM Default Value: \_\_line5Codec5\_\_  
Description: Account 5 Choice 5

P20402  
EPM Default Value: \_\_line5Codec6\_\_  
Description: Account 5 Choice 6

P20408  
EPM Default Value: 2  
Description: Account 5 Voice Frames Per TX

P20410  
EPM Default Value: 0  
Description: Account 5 G723 Rate

P20412  
EPM Default Value: 97  
Description: Account 5 iLBC Payload Type

P20414  
EPM Default Value: 0  
Description: Account 5 iLBC Frame Size

P20416  
EPM Default Value: 101  
Description: Account 5 Dtmf Payload Type

P20170  
EPM Default Value: 0  
Description: Account 5 Dtmf Mode

P20424  
EPM Default Value: 0  
Description: Account 5 Send Flash Event

P20426  
EPM Default Value: 0  
Description: Account 5 Enable Call Features

P20428  
EPM Default Value:  
Description: Account 5 Proxy Require

P20430  
EPM Default Value:  
Description: Account 5 Use Nat IP

P20432  
EPM Default Value: \_\_srtpMode5\_\_  
Description: Account 5 SRtp Mode

P20434  
EPM Default Value: 0  
Description: Account 5 VAD

P20436  
EPM Default Value: 0  
Description: Account 5 Symmetric RTP

P20438  
EPM Default Value: 1  
Description: Account 5 Jitter Buffer Type

P20440  
EPM Default Value: 1  
Description: Account 5 Jitter Buffer Length

P1723  
EPM Default Value: \_\_ringtone\_\_  
Description: Account 5 Account Ring Tone

P20442  
EPM Default Value: 60  
Description: Account 5 Ring Timeout

P20444  
EPM Default Value: 1  
Description: Account 5 Use # As Dial Key

P4204  
EPM Default Value: \_\_dialpattern\_\_  
Description: Account 5 Dial Plan

P1715  
EPM Default Value: 0  
Description: Account 5 Subscribe For MWI

P1721  
EPM Default Value: 0  
Description: Account 5 Send Anonymous

P20446  
EPM Default Value: \_\_acr\_\_  
Description: Account 5 Anonymous Call Rejection

P1767  
EPM Default Value: 0  
Description: Account 5 Check SIP User ID

P1725  
EPM Default Value: 0  
Description: Account 5 Auto Answer

P1738  
EPM Default Value: 1  
Description: Account 5 Answer Via Call Info

P1739  
EPM Default Value: 1  
Description: Account 5 Off Speaker Disconnect

P1734  
EPM Default Value: 180  
Description: Account 5 Session Expiration

P1727  
EPM Default Value: 90  
Description: Account 5 Min SE

P1728  
EPM Default Value: 0  
Description: Account 5 Caller Request Timer

P1729  
EPM Default Value: 0  
Description: Account 5 Callee Request Timer

P1730  
EPM Default Value: 0  
Description: Account 5 Force Timer

P1732  
EPM Default Value: 0  
Description: Account 5 UAC Specify Refresher

P1733  
EPM Default Value: 1  
Description: Account 5 UAS Specify Refresher

P1731  
EPM Default Value: 0  
Description: Account 5 Force INVITE

P20448  
EPM Default Value: 50  
Description: Account 5 Hook Flash Min Timing

P20450  
EPM Default Value: 100  
Description: Account 5 Hook Flash Max Timing

P20452  
EPM Default Value: 100  
Description: Account 5 Special Feature

P1744  
EPM Default Value:  
Description: Account 5 Eventlist Blf Url

P20454  
EPM Default Value: 0  
Description: Account 5 Share Line

P20456  
EPM Default Value: 0  
Description: Account 5 SIP Server Type

P20458  
EPM Default Value: 0  
Description: Account 5 100rel

P20460  
EPM Default Value: 0  
Description: Account 5 Early Session

P20462  
EPM Default Value: 0  
Description: Account 5 Refuse Return Code

P20464  
EPM Default Value: \_\_directedCallPickup\_\_  
Description: Account 5 Direct Call Pickup Code

P20466  
EPM Default Value:  
Description: Account 5 Group Call Pickup Code

P20468  
EPM Default Value: 0  
Description: Account 5 Feature Key Syn

P20472  
EPM Default Value: 0  
Description: Account 5 Conference Type

P20470  
EPM Default Value:  
Description: Account 5 Conference URI

P20474  
EPM Default Value: 0  
Description: Account 5 Sip Send Mac

P20161  
EPM Default Value: 0  
Description: Account 5 Caller Display Source

P20659  
EPM Default Value: 0  
Description: Account 5 Enable ACD

P20665  
EPM Default Value: 0  
Description: Account 5 ACD Show Available

P20671  
EPM Default Value: 0  
Description: Account 5 ACD Initial State

P20677  
EPM Default Value: 0  
Description: Account 5 ACD Show Unavailable Reason

P20920  
EPM Default Value:  
Description: Account 5 ACD Un Available Name 1

P20921  
EPM Default Value:  
Description: Account 5 ACD Un Available Name 2

P20922  
EPM Default Value:  
Description: Account 5 ACD Un Available Name 3

P20923  
EPM Default Value:  
Description: Account 5 ACD Un Available Name 4

P20924  
EPM Default Value:  
Description: Account 5 ACD Un Available Name 5

P20699  
EPM Default Value:  
Description: Account 5 ACD Un Available Code 1

P20700  
EPM Default Value:  
Description: Account 5 ACD Un Available Code 2

P20701  
EPM Default Value:  
Description: Account 5 ACD Un Available Code 3

P20702  
EPM Default Value:  
Description: Account 5 ACD Un Available Code 4

P20703  
EPM Default Value:  
Description: Account 5 ACD Un Available Code 5

P20713  
EPM Default Value: 0  
Description: Account 5 Enable Hoteling

P20719  
EPM Default Value: 0  
Description: Account 5 Hoteling Auto Login

P20725  
EPM Default Value:  
Description: Account 5 Hoteling User Id

P20731  
EPM Default Value:  
Description: Account 5 Hoteling Password

P20737  
EPM Default Value: 0  
Description: Account 5 Enable Call Center Status

P20743  
EPM Default Value: 0  
Description: Account 5 Enable Call Center Trace

P20749  
EPM Default Value: 0  
Description: Account 5 Enable Call Center Emergency Escalation

P20775  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Code 1

P20776  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Code 2

P20777  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Code 3

P20778  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Code 4

P20779  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Code 5

P20811  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Name 1

P20812  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Name 2

P20813  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Name 3

P20814  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Name 4

P20815  
EPM Default Value:  
Description: Account 5 Call Center Supervisor Name 5

P20827  
EPM Default Value: 0  
Description: Account 5 Enable Call Center Disp Code

P20853  
EPM Default Value:  
Description: Account 5 CC Disp Code 1

P20854  
EPM Default Value:  
Description: Account 5 CC Disp Code 2

P20855  
EPM Default Value:  
Description: Account 5 CC Disp Code 3

P20856  
EPM Default Value:  
Description: Account 5 CC Disp Code 4

P20857  
EPM Default Value:  
Description: Account 5 CC Disp Code 5

P20889  
EPM Default Value:  
Description: Account 5 CC Disp Name 1

P20890  
EPM Default Value:  
Description: Account 5 CC Disp Name 2

P20891  
EPM Default Value:  
Description: Account 5 CC Disp Name 3

P20892  
EPM Default Value:  
Description: Account 5 CC Disp Name 4

P20893  
EPM Default Value:  
Description: Account 5 CC Disp Name 5

P20974  
EPM Default Value: 300  
Description: Account 5 Subscribe Expires

P20980  
EPM Default Value: 0  
Description: Account 5 SCA Barge In

P20361  
EPM Default Value: \_\_line6Enable\_\_  
Description: Account 6 Active

P20363  
EPM Default Value: \_\_line6Dest\_\_:\_\_line6ServerPort\_\_  
Description: Account 6 Sip server

P20365  
EPM Default Value: \_\_backupDestination\_\_  
Description: Account 6 Failover Sip server

P20367  
EPM Default Value:  
Description: Account 6 Second Failover Sip server

P20369  
EPM Default Value: 0  
Description: Account 6 Prefer Primary Server

P20371  
EPM Default Value: \_\_outboundDestination\_\_  
Description: Account 6 Outbound Proxy

P20373  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account 6 Back Up Outbound Proxy

P20375  
EPM Default Value: \_\_transport6\_\_  
Description: Account 6 Sip Transport

P20377  
EPM Default Value: 2  
Description: Account 6 Nat Traversal

P20379  
EPM Default Value: \_\_line6Name\_\_  
Description: Account 6 Label

P1804  
EPM Default Value: \_\_line6Ext\_\_  
Description: Account 6 Sip User Id

P1805  
EPM Default Value: \_\_line6Ext\_\_  
Description: Account 6 Authenticate ID

P1806  
EPM Default Value: \_\_line6Pass\_\_  
Description: Account 6 Authenticate Password

P1807  
EPM Default Value: \_\_line6Name\_\_  
Description: Account 6 Display Name

P20381  
EPM Default Value: 0  
Description: Account 6 Dns Mode

P20383  
EPM Default Value: 0  
Description: Account 6 User Id Is Phone Number

P20385  
EPM Default Value: \_\_line6Enable\_\_  
Description: Account 6 Sip Registration

P20387  
EPM Default Value: 0  
Description: Account 6 Unregister On Reboot

P20389  
EPM Default Value: 15  
Description: Account 6 Register Expiration

P1213  
EPM Default Value: 1  
Description: Account 6 Out Call Without Reg

P1813  
EPM Default Value: \_\_line6extPort\_\_  
Description: Account 6 Local Sip Port

P20391  
EPM Default Value: 0  
Description: Account 6 Use Random Port

P1826  
EPM Default Value: \_\_voicemail\_\_  
Description: Account 6 Voice Mail Id

P141  
EPM Default Value: 0  
Description: Account 6 RPort

P1105  
EPM Default Value: 1  
Description: Account 6 RFC2543 Hold

P20477  
EPM Default Value: 0  
Description: Account 6 Connect Mode

P20393  
EPM Default Value: \_\_line6Codec1\_\_  
Description: Account 6 Choice 1

P20395  
EPM Default Value: \_\_line6Codec2\_\_  
Description: Account 6 Choice 2

P20397  
EPM Default Value: \_\_line6Codec3\_\_  
Description: Account 6 Choice 3

P20399  
EPM Default Value: \_\_line6Codec4\_\_  
Description: Account 6 Choice 4

P20401  
EPM Default Value: \_\_line6Codec5\_\_  
Description: Account 6 Choice 5

P20403  
EPM Default Value: \_\_line6Codec6\_\_  
Description: Account 6 Choice 6

P20409  
EPM Default Value: 2  
Description: Account 6 Voice Frames Per TX

P20411  
EPM Default Value: 0  
Description: Account 6 G723 Rate

P20413  
EPM Default Value: 97  
Description: Account 6 iLBC Payload Type

P20415  
EPM Default Value: 0  
Description: Account 6 iLBC Frame Size

P20417  
EPM Default Value: 101  
Description: Account 6 Dtmf Payload Type

P20171  
EPM Default Value: 0  
Description: Account 6 Dtmf Mode

P20425  
EPM Default Value: 0  
Description: Account 6 Send Flash Event

P20427  
EPM Default Value: 0  
Description: Account 6 Enable Call Features

P20429  
EPM Default Value:  
Description: Account 6 Proxy Require

P20431  
EPM Default Value:  
Description: Account 6 Use Nat IP

P20433  
EPM Default Value: \_\_srtpMode6\_\_  
Description: Account 6 SRtp Mode

P20435  
EPM Default Value: 0  
Description: Account 6 VAD

P20437  
EPM Default Value: 0  
Description: Account 6 Symmetric RTP

P20439  
EPM Default Value: 1  
Description: Account 6 Jitter Buffer Type

P20441  
EPM Default Value: 1  
Description: Account 6 Jitter Buffer Length



P1823  
EPM Default Value: \_\_ringtone\_\_  
Description: Account 6 Account Ring Tone

P20443  
EPM Default Value: 60  
Description: Account 6 Ring Timeout

P20445  
EPM Default Value: 1  
Description: Account 6 Use # As Dial Key

P4205  
EPM Default Value: \_\_dialpattern\_\_  
Description: Account 6 Dial Plan

P1815  
EPM Default Value: 0  
Description: Account 6 Subscribe For MWI

P1821  
EPM Default Value: 0  
Description: Account 6 Send Anonymous

P20447  
EPM Default Value: \_\_acr\_\_  
Description: Account 6 Anonymous Call Rejection

P1867  
EPM Default Value: 0  
Description: Account 6 Check SIP User ID

P1825  
EPM Default Value: 0  
Description: Account 6 Auto Answer

P1838  
EPM Default Value: 1  
Description: Account 6 Answer Via Call Info

P1839  
EPM Default Value: 1  
Description: Account 6 Off Speaker Disconnect

P1834  
EPM Default Value: 180  
Description: Account 6 Session Expiration

P1827  
EPM Default Value: 90  
Description: Account 6 Min SE

P1828  
EPM Default Value: 0  
Description: Account 6 Caller Request Timer

P1829  
EPM Default Value: 0  
Description: Account 6 Callee Request Timer

P1830  
EPM Default Value: 0  
Description: Account 6 Force Timer

P1832  
EPM Default Value: 0  
Description: Account 6 UAC Specify Refresher

P1833  
EPM Default Value: 1  
Description: Account 6 UAS Specify Refresher

P1831  
EPM Default Value: 0  
Description: Account 6 Force INVITE

P20449  
EPM Default Value: 50  
Description: Account 6 Hook Flash Min Timing

P20451  
EPM Default Value: 100  
Description: Account 6 Hook Flash Max Timing

P20453  
EPM Default Value: 100  
Description: Account 6 Special Feature

P1844  
EPM Default Value:  
Description: Account 6 Eventlist Blf Url

P20455  
EPM Default Value: 0  
Description: Account 6 Share Line

P20457  
EPM Default Value: 0  
Description: Account 6 SIP Server Type

P20459  
EPM Default Value: 0  
Description: Account 6 100rel

P20461  
EPM Default Value: 0  
Description: Account 6 Early Session

P20463  
EPM Default Value: 0  
Description: Account 6 Refuse Return Code

P20465  
EPM Default Value: \_\_directedCallPickup\_\_  
Description: Account 6 Direct Call Pickup Code

P20467  
EPM Default Value:  
Description: Account 6 Group Call Pickup Code

P20469  
EPM Default Value: 0  
Description: Account 6 Feature Key Syn

P20473  
EPM Default Value: 0  
Description: Account 6 Conference Type

P20471  
EPM Default Value:  
Description: Account 6 Conference URI

P20475  
EPM Default Value: 0  
Description: Account 6 Sip Send Mac

P20162  
EPM Default Value: 0  
Description: Account 6 Caller Display Source

P20660  
EPM Default Value: 0  
Description: Account 6 Enable ACD

P20666  
EPM Default Value: 0  
Description: Account 6 ACD Show Available

P20672  
EPM Default Value: 0  
Description: Account 6 ACD Initial State

P20678  
EPM Default Value: 0  
Description: Account 6 ACD Show Unavailable Reason

P20925  
EPM Default Value:  
Description: Account 6 ACD Un Available Name 1

P20926  
EPM Default Value:  
Description: Account 6 ACD Un Available Name 2

P20927  
EPM Default Value:  
Description: Account 6 ACD Un Available Name 3

P20928  
EPM Default Value:  
Description: Account 6 ACD Un Available Name 4

P20929  
EPM Default Value:  
Description: Account 6 ACD Un Available Name 5

P20704  
EPM Default Value:  
Description: Account 6 ACD Un Available Code 1

P20705  
EPM Default Value:  
Description: Account 6 ACD Un Available Code 2

P20706  
EPM Default Value:  
Description: Account 6 ACD Un Available Code 3

P20707  
EPM Default Value:  
Description: Account 6 ACD Un Available Code 4

P20708  
EPM Default Value:  
Description: Account 6 ACD Un Available Code 5

P20714  
EPM Default Value: 0  
Description: Account 6 Enable Hoteling

P20720  
EPM Default Value: 0  
Description: Account 6 Hoteling Auto Login

P20726  
EPM Default Value:  
Description: Account 6 Hoteling User Id

P20732  
EPM Default Value:  
Description: Account 6 Hoteling Password

P20738  
EPM Default Value: 0  
Description: Account 6 Enable Call Center Status

P20744  
EPM Default Value: 0  
Description: Account 6 Enable Call Center Trace

P20750  
EPM Default Value: 0  
Description: Account 6 Enable Call Center Emergency Escalation

P20781  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Code 1

P20782  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Code 2

P20783  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Code 3

P20784  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Code 4

P20785  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Code 5

P20817  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Name 1

P20818  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Name 2

P20819  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Name 3

P20820  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Name 4

P20821  
EPM Default Value:  
Description: Account 6 Call Center Supervisor Name 5

P20828  
EPM Default Value: 0  
Description: Account 6 Enable Call Center Disp Code

P20859  
EPM Default Value:  
Description: Account 6 CC Disp Code 1

P20860  
EPM Default Value:  
Description: Account 6 CC Disp Code 2

P20861  
EPM Default Value:  
Description: Account 6 CC Disp Code 3

P20862  
EPM Default Value:  
Description: Account 6 CC Disp Code 4

P20863  
EPM Default Value:  
Description: Account 6 CC Disp Code 5

P20895  
EPM Default Value:  
Description: Account 6 CC Disp Name 1

P20896  
EPM Default Value:  
Description: Account 6 CC Disp Name 2

P20897  
EPM Default Value:  
Description: Account 6 CC Disp Name 3

P20898  
EPM Default Value:  
Description: Account 6 CC Disp Name 4

P20899  
EPM Default Value:  
Description: Account 6 CC Disp Name 5

P20975  
EPM Default Value: 300  
Description: Account 6 Subscribe Expires

P20981  
EPM Default Value: 0  
Description: Account 6 SCA Barge In

P8951  
EPM Default Value: \_\_textLogo\_\_  
Description: Logo Screen Saver Text

P20000  
EPM Default Value: \_\_line1Name\_\_  
Description: Account 1 Label

P20001  
EPM Default Value: \_\_line2Name\_\_  
Description: Account 2 Label

P20002  
EPM Default Value: \_\_line3Name\_\_  
Description: Account 3 Label

P20003  
EPM Default Value: \_\_line4Name\_\_  
Description: Account 4 Label

P23279  
EPM Default Value: \_\_guiOverride\_\_  
Description: Web Setting High Priority

P39  
EPM Default Value: 12100  
Description: MinRtpPort

P40  
EPM Default Value: \_\_line1extPort\_\_  
Description: Account1 LocalSipPort

P113  
EPM Default Value:  
Description: DMZIpAddr

P136  
EPM Default Value: 0  
Description: Account1 RPort

P137  
EPM Default Value: 0  
Description: Account2 RPort

P138  
EPM Default Value: 0  
Description: Account3 RPort

P139  
EPM Default Value: 0  
Description: Account4 RPort

P150  
EPM Default Value: 0  
Description: PortMap WanPort1

P152  
EPM Default Value: 0  
Description: PortMap WanPort3

P153  
EPM Default Value: 0  
Description: PortMap WanPort4

P154  
EPM Default Value: 0  
Description: PortMap WanPort5

P155  
EPM Default Value: 0  
Description: PortMap WanPort6

P156  
EPM Default Value: 0  
Description: PortMap WanPort7

P157  
EPM Default Value: 0  
Description: PortMap WanPort8

P158  
EPM Default Value:  
Description: PortMap LanIp1

P159  
EPM Default Value:  
Description: PortMap LanIp2

P160  
EPM Default Value:  
Description: PortMap LanIp3

P161  
EPM Default Value:  
Description: PortMap LanIp4

P162  
EPM Default Value:  
Description: PortMap LanIp5

P163  
EPM Default Value:  
Description: PortMap LanIp6

P164  
EPM Default Value:  
Description: PortMap LanIp7

P165  
EPM Default Value:  
Description: PortMap LanIp8

P166  
EPM Default Value: 0  
Description: PortMap LanPort1

P167  
EPM Default Value: 0  
Description: PortMap LanPort2

P168  
EPM Default Value: 0  
Description: PortMap LanPort3

P169  
EPM Default Value: 0  
Description: PortMap LanPort4

P170  
EPM Default Value: 0  
Description: PortMap LanPort5

P171  
EPM Default Value: 0  
Description: PortMap LanPort6

P172  
EPM Default Value: 0  
Description: PortMap LanPort7

P173  
EPM Default Value: 0  
Description: PortMap LanPort8

P174  
EPM Default Value: 0  
Description: PortMap Protocol1

P175  
EPM Default Value: 0  
Description: PortMap Protocol2

P176  
EPM Default Value: 0  
Description: PortMap Protocol3

P177  
EPM Default Value: 0  
Description: PortMap Protocol4

P178  
EPM Default Value: 0  
Description: PortMap Protocol5

P179  
EPM Default Value: 0  
Description: PortMap Protocol6

P180  
EPM Default Value: 0  
Description: PortMap Protocol7

P181  
EPM Default Value: 0  
Description: PortMap Protocol8

P196  
EPM Default Value: \_\_userPass\_\_  
Description: UserPassword

P232  
EPM Default Value:  
Description: FirmwareUpgrade FilePrefix

P233  
EPM Default Value:  
Description: FirmwareUpgrade FilePostfix

P390  
EPM Default Value: 97  
Description: Account1 LibcPayloadType

P391  
EPM Default Value: 97  
Description: Account2 LibcPayloadType

P392  
EPM Default Value: 97  
Description: Account3 LibcPayloadType

P393  
EPM Default Value: 97  
Description: Account4 LibcPayloadType

P394  
EPM Default Value: 0  
Description: Account1 LibcMode

P395  
EPM Default Value: 0  
Description: Account2 LibcMode

P396  
EPM Default Value: 0  
Description: Account3 LibcMode

P397  
EPM Default Value: 0  
Description: Account4 LibcMode

P513  
EPM Default Value: \_\_line3extPort\_\_  
Description: Account3 LocalSipPort

P613  
EPM Default Value: \_\_line4extPort\_\_  
Description: Account4 LocalSipPort

P739  
EPM Default Value: 12200  
Description: MaxRtpPort

P740  
EPM Default Value: \_\_line2extPort\_\_  
Description: Account2 LocalSipPort

P751  
EPM Default Value: 0  
Description: Account2 EnableCallFeatures

P775  
EPM Default Value: 0  
Description: Account3 SendFlashEvent

P776  
EPM Default Value: 0  
Description: Account4 SendFlashEvent

P792  
EPM Default Value:  
Description: Account2 ProxyRequire

P1085  
EPM Default Value: \_\_dialNow\_\_  
Description: DialNow-TimeOut

P1100  
EPM Default Value: 1  
Description: Account1 RFC2543Hold



P1101  
EPM Default Value: 1  
Description: Account2 RFC2543Hold

P1102  
EPM Default Value: 1  
Description: Account3 RFC2543Hold

P1103  
EPM Default Value: 1  
Description: Account4 RFC2543Hold

P2532  
EPM Default Value: 0  
Description: Preference DisplayMode

P3207  
EPM Default Value: 0  
Description: Transfer HoldTransferOnHook

P3312  
EPM Default Value:  
Description: RemotePhoneBook2 Name

P3313  
EPM Default Value:  
Description: RemotePhoneBook3 Name

P3314  
EPM Default Value:  
Description: RemotePhoneBook4 Name

P3315  
EPM Default Value:  
Description: RemotePhoneBook5 Name

P3316  
EPM Default Value:  
Description: RemotePhoneBook1 Name

P4203  
EPM Default Value: \_\_dialpattern\_\_  
Description: Account4 DialPlan

P4401  
EPM Default Value:  
Description: RemotePhoneBook1 Url

P4402  
EPM Default Value:  
Description: RemotePhoneBook2 Url

P4403  
EPM Default Value:  
Description: RemotePhoneBook3 Url

P4404  
EPM Default Value:  
Description: RemotePhoneBook4 Url

P4405  
EPM Default Value:  
Description: RemotePhoneBook5 Url

P8519  
EPM Default Value:  
Description: BroadSoftItem

P8520  
EPM Default Value:  
Description: BroadSoft1 DisplayName

P8521  
EPM Default Value:  
Description: BroadSoft1 Server

P8522  
EPM Default Value: 0  
Description: BroadSoft1 Port

P8523  
EPM Default Value:  
Description: BroadSoft1 User

P8524  
EPM Default Value:  
Description: BroadSoft1 PassWord

P8530  
EPM Default Value:  
Description: BroadSoft2 DisplayName

P8531  
EPM Default Value:  
Description: BroadSoft2 Server

P8532  
EPM Default Value: 0  
Description: BroadSoft2 Port

P8533  
EPM Default Value:  
Description: BroadSoft2 User

P8534  
EPM Default Value:  
Description: BroadSoft2 PassWord

P8540  
EPM Default Value:  
Description: BroadSoft3 DisplayName

P8541  
EPM Default Value:  
Description: BroadSoft3 Server

P8542  
EPM Default Value: 0  
Description: BroadSoft3 Port

P8543  
EPM Default Value:  
Description: BroadSoft3 User

P8544  
EPM Default Value:  
Description: BroadSoft3 PassWord

P8550  
EPM Default Value:  
Description: BroadSoft4 DisplayName

P8551  
EPM Default Value:  
Description: BroadSoft4 Server

P8552  
EPM Default Value: 0  
Description: BroadSoft4 Port

P8553  
EPM Default Value:  
Description: BroadSoft4 User

P8554  
EPM Default Value:  
Description: BroadSoft4 PassWord

P8560  
EPM Default Value:  
Description: BroadSoft5 DisplayName

P8561  
EPM Default Value:  
Description: BroadSoft5 Server

P8562  
EPM Default Value: 0  
Description: BroadSoft5 Port

P8563  
EPM Default Value:  
Description: BroadSoft5 User

P8564  
EPM Default Value:  
Description: BroadSoft5 PassWord

P8570  
EPM Default Value:  
Description: BroadSoft6 DisplayName

P8571  
EPM Default Value:  
Description: BroadSoft6 Server

P8572  
EPM Default Value: 0  
Description: BroadSoft6 Port

P8573  
EPM Default Value:  
Description: BroadSoft6 User

P8574  
EPM Default Value:  
Description: BroadSoft6 PassWord

P8579  
EPM Default Value:  
Description: CallLogItem

P8580  
EPM Default Value:  
Description: CallLog1 DisplayName

P8581  
EPM Default Value:  
Description: CallLog1 Server

P8582  
EPM Default Value: 0  
Description: CallLog1 Port

P8583  
EPM Default Value:  
Description: CallLog1 User

P8584  
EPM Default Value:  
Description: CallLog1 PassWord

P8585  
EPM Default Value:  
Description: CallLog2 DisplayName

P8586  
EPM Default Value:  
Description: CallLog2 Server

P8587  
EPM Default Value: 0  
Description: CallLog2 Port

P8588  
EPM Default Value:  
Description: CallLog2 User

P8589  
EPM Default Value:  
Description: CallLog2 PassWord

P8590  
EPM Default Value:  
Description: CallLog3 DisplayName

P8591  
EPM Default Value:  
Description: CallLog3 Server

P8592  
EPM Default Value: 0  
Description: CallLog3 Port

P8593  
EPM Default Value:  
Description: CallLog3 User

P8594  
EPM Default Value:  
Description: CallLog3 PassWord

P8620  
EPM Default Value: 0  
Description: Preference HistoryRecord

P8621  
EPM Default Value: \_\_lcdLanguage\_\_  
Description: Preference LcdLanguage

P8622  
EPM Default Value:  
Description: DateTime BackUpNTPServer

P8631  
EPM Default Value:  
Description: FirmwareUpGrade SetCommonAESKey

P8633  
EPM Default Value: 0  
Description: Account1 FeatureKeySyn

P8634  
EPM Default Value: 0  
Description: Account2 FeatureKeySyn

P8635  
EPM Default Value: 0  
Description: Account3 FeatureKeySyn

P8639  
EPM Default Value: 0  
Description: DhcpServerFlag

P8656  
EPM Default Value: 0  
Description: Account4 FeatureKeySyn

P8672  
EPM Default Value: 1  
Description: Preference IncomingCallShowMode

P8678  
EPM Default Value: 1  
Description: Preference PhoneFontHeightSize

P8680  
EPM Default Value: 1  
Description: Preference WatchDogEnable

P8681  
EPM Default Value: admin  
Description: LogUser Admin

P8682  
EPM Default Value: user  
Description: LogUser User

P8685  
EPM Default Value:  
Description: GlobalConfig CopyRight

P8686  
EPM Default Value: SANGOMA  
Description: GlobalConfig OEMTag

P8775  
EPM Default Value: \_\_vpnMode\_\_  
Description: Account1 ConnectMode

P8776  
EPM Default Value: \_\_vpnMode\_\_  
Description: Account2 ConnectMode

P8777  
EPM Default Value: \_\_vpnMode\_\_  
Description: Account3 ConnectMode

P8778  
EPM Default Value: \_\_vpnMode\_\_  
Description: Account4 ConnectMode

P8845  
EPM Default Value: 0  
Description: Account1 RefuseReturnCode

P8846  
EPM Default Value: 0  
Description: Account2 RefuseReturnCode

P8847  
EPM Default Value: 0  
Description: Account3 RefuseReturnCode

P8848  
EPM Default Value: 0  
Description: Account4 RefuseReturnCode

P8849  
EPM Default Value: 1  
Description: CallWaiting OnOff

P8851  
EPM Default Value:  
Description: Account1 SecondFailoverSipserver

P8852  
EPM Default Value:  
Description: Account2 SecondFailoverSipserver

P8853  
EPM Default Value:  
Description: Account3 SecondFailoverSipserver

P8854  
EPM Default Value:  
Description: Account4 SecondFailoverSipserver

P20004  
EPM Default Value: 0  
Description: Account1 ConferenceType

P20005  
EPM Default Value: 0  
Description: Account2 ConferenceType

P20006  
EPM Default Value: 0  
Description: Account3 ConferenceType

P20007  
EPM Default Value: 0  
Description: Account4 ConferenceType

P20008  
EPM Default Value:  
Description: Account1 ConferenceURI

P20009  
EPM Default Value:  
Description: Account2 ConferenceURI

P20010  
EPM Default Value:  
Description: Account3 ConferenceURI

P20011  
EPM Default Value:  
Description: Account4 ConferenceURI

P20017  
EPM Default Value: 0  
Description: Preference RefreshCallerIdViaContact

P20048  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account2 BackUpOutboundProxy

P20049  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account3 BackUpOutboundProxy

P20050  
EPM Default Value: \_\_backupOutboundDestination\_\_  
Description: Account4 BackUpOutboundProxy

P20053  
EPM Default Value: 0  
Description: Account1 SipSendMac

P20054  
EPM Default Value: 0  
Description: Account2 SipSendMac

P20055  
EPM Default Value: 0  
Description: Account3 SipSendMac

P20056  
EPM Default Value: 0  
Description: Account4 SipSendMac

P20074  
EPM Default Value: 0  
Description: InterComBarge

P20075  
EPM Default Value: 0  
Description: LcdShowMissCall

P20076  
EPM Default Value: 3  
Description: DSTStartTime-Month

P20077  
EPM Default Value: 12  
Description: DSTStartTime-Day

P20078  
EPM Default Value: 2  
Description: DSTStartTime-Hour

P20079  
EPM Default Value: 11  
Description: DSTEndTime-Month

P20080  
EPM Default Value: 5  
Description: DSTEndTime-Day

P20081  
EPM Default Value: 1  
Description: DSTEndTime-Hour

P20083  
EPM Default Value: 0  
Description: HandSetSendVolume

P20084  
EPM Default Value: 0  
Description: HeadSetSendVolume

P20085  
EPM Default Value: 0  
Description: BLFSelectType

P20086  
EPM Default Value: 0  
Description: CurrentCallStatus-1

P20087  
EPM Default Value: 1  
Description: CurrentCallStatus-2

P20088  
EPM Default Value: 2  
Description: CurrentCallStatus-3

P20089  
EPM Default Value: 3  
Description: CurrentCallStatus-4

P20090  
EPM Default Value: 4  
Description: CurrentCallStatus-5

P20091  
EPM Default Value: 5  
Description: CurrentCallStatus-6

P20092  
EPM Default Value: 6  
Description: CurrentCallStatus-7

P20093  
EPM Default Value: 0  
Description: CurrentCallStatus-8

P20094  
EPM Default Value: 0  
Description: CurrentCallStatus-9

P20095  
EPM Default Value: 0  
Description: CurrentCallStatus-10

P20096  
EPM Default Value: terminated  
Description: BlfStatusText-1

P20097  
EPM Default Value: early  
Description: BlfStatusText-2

P20098  
EPM Default Value: confirmed  
Description: BlfStatusText-3

P20099  
EPM Default Value: confirmed  
Description: BlfStatusText-4

P20100  
EPM Default Value: confirmed  
Description: BlfStatusText-5

P20101  
EPM Default Value: confirmed  
Description: BlfStatusText-6

P20102  
EPM Default Value: unknown  
Description: BlfStatusText-7

P20103  
EPM Default Value: BlfStatusText-8  
Description: BlfStatusText-8

P20104  
EPM Default Value: BlfStatusText-9  
Description: BlfStatusText-9

P20105  
EPM Default Value: BlfStatusText-10  
Description: BlfStatusText-10

P20106  
EPM Default Value: 2  
Description: BlfLedMode-1

P20107  
EPM Default Value: 6  
Description: BlfLedMode-2

P20108  
EPM Default Value: 1  
Description: BlfLedMode-3

P20109  
EPM Default Value: 1  
Description: BlfLedMode-4

P20110  
EPM Default Value: 1  
Description: BlfLedMode-5



P20111  
EPM Default Value: 1  
Description: BifLedMode-6

P20112  
EPM Default Value: 0  
Description: BifLedMode-7

P20113  
EPM Default Value: 0  
Description: BifLedMode-8

P20114  
EPM Default Value: 0  
Description: BifLedMode-9

P20115  
EPM Default Value: 0  
Description: BifLedMode-10

P20116  
EPM Default Value: 1  
Description: SuppressDTMF

P20117  
EPM Default Value: 1  
Description: SuppressDTMFDelay

P20119  
EPM Default Value: 0  
Description: RTCPReportFlag

P20120  
EPM Default Value: RTCPReportCollector  
Description: RTCPReportCollector

P20121  
EPM Default Value: RTCPReportFormat  
Description: RTCPReportFormat

P20155  
EPM Default Value: 0  
Description: ServerCaType

P20156  
EPM Default Value: 2  
Description: TrustedCaType

P20158  
EPM Default Value: 0  
Description: Account2 CallerDisplaySource

P20159  
EPM Default Value: 0  
Description: Account3 CallerDisplaySource

P20160  
EPM Default Value: 0  
Description: Account4 CallerDisplaySource

P20163  
EPM Default Value: 0  
Description: NetWork StaticDNS

P20164  
EPM Default Value: 0  
Description: MulticastPaging MulticatCodec

P20165  
EPM Default Value: 1  
Description: FirmwareUpGrade PnPActive

P20166  
EPM Default Value: 0  
Description: Account1 DtmfMode

P20167  
EPM Default Value: 0  
Description: Account2 DtmfMode

P20168  
EPM Default Value: 0  
Description: Account3 DtmfMode

P20169  
EPM Default Value: 0  
Description: Account4 DtmfMode

P20172  
EPM Default Value: 0  
Description: Preference VmTransfer

P20173  
EPM Default Value:  
Description: Preference VmTransferCode

P20174  
EPM Default Value: \_\_ringtoneUrl\_\_  
Description: FirmwareUpgrade RingUrl

P20175  
EPM Default Value:  
Description: FirmwareUpgrade LanguageUrl

P20176  
EPM Default Value:  
Description: FirmwareUpgrade HlpresUrl

P20177  
EPM Default Value:  
Description: FirmwareUpgrade ExpPresUrl

P20179  
EPM Default Value:  
Description: FirmwareUpgrade TCAUrl

P20180  
EPM Default Value:  
Description: FirmwareUpgrade SCAUrl

P20600  
EPM Default Value: 0  
Description: LineKey1 Mode

P20601  
EPM Default Value: 0  
Description: LineKey2 Mode

P20602  
EPM Default Value: 0  
Description: LineKey3 Mode

P20603  
EPM Default Value: 0  
Description: LineKey4 Mode

P20655  
EPM Default Value: 0  
Description: Account1 EnableACD

P20656  
EPM Default Value: 0  
Description: Account2 EnableACD

P20657  
EPM Default Value: 0  
Description: Account3 EnableACD

P20658  
EPM Default Value: 0  
Description: Account4 EnableACD

P20661  
EPM Default Value: 0  
Description: Account1 ACDSHowAvailable

P20662  
EPM Default Value: 0  
Description: Account2 ACDSHowAvailable

P20663  
EPM Default Value: 0  
Description: Account3 ACDSHowAvailable

P20664  
EPM Default Value: 0  
Description: Account4 ACDSHowAvailable

P20667  
EPM Default Value: 0  
Description: Account1 ACDInitialState

P20668  
EPM Default Value: 0  
Description: Account2 ACDInitialState

P20669  
EPM Default Value: 0  
Description: Account3 ACDInitialState

P20670  
EPM Default Value: 0  
Description: Account4 ACDInitialState

P20673  
EPM Default Value: 0  
Description: Account1 ACDSHowUnavailableReason

P20674  
EPM Default Value: 0  
Description: Account2 ACDSHowUnavailableReason

P20675  
EPM Default Value: 0  
Description: Account3 ACDSHowUnavailableReason

P20676  
EPM Default Value: 0  
Description: Account4 ACDSHowUnavailableReason

P20679  
EPM Default Value:  
Description: Account1 ACDSUnAvailableCode1

P20680  
EPM Default Value:  
Description: Account1 ACDSUnAvailableCode2

P20681  
EPM Default Value:  
Description: Account1 ACDSUnAvailableCode3

P20682  
EPM Default Value:  
Description: Account1 ACDSUnAvailableCode4

P20683  
EPM Default Value:  
Description: Account1 ACUnAvailableCode5

P20684  
EPM Default Value:  
Description: Account2 ACUnAvailableCode1

P20685  
EPM Default Value:  
Description: Account2 ACUnAvailableCode2

P20686  
EPM Default Value:  
Description: Account2 ACUnAvailableCode3

P20687  
EPM Default Value:  
Description: Account2 ACUnAvailableCode4

P20688  
EPM Default Value:  
Description: Account2 ACUnAvailableCode5

P20689  
EPM Default Value:  
Description: Account3 ACUnAvailableCode1

P20690  
EPM Default Value:  
Description: Account3 ACUnAvailableCode2

P20691  
EPM Default Value:  
Description: Account3 ACUnAvailableCode3

P20692  
EPM Default Value:  
Description: Account3 ACUnAvailableCode4

P20693  
EPM Default Value:  
Description: Account3 ACUnAvailableCode5

P20694  
EPM Default Value:  
Description: Account4 ACUnAvailableCode1

P20695  
EPM Default Value:  
Description: Account4 ACUnAvailableCode2

P20696  
EPM Default Value:  
Description: Account4 ACUnAvailableCode3

P20697  
EPM Default Value:  
Description: Account4 ACUnAvailableCode4

P20698  
EPM Default Value:  
Description: Account4 ACUnAvailableCode5

P20709  
EPM Default Value: 0  
Description: Account1 EnableHoteling

P20710  
EPM Default Value: 0  
Description: Account2 EnableHoteling

P20711  
EPM Default Value: 0  
Description: Account3 EnableHoteling

P20712  
EPM Default Value: 0  
Description: Account4 EnableHoteling

P20715  
EPM Default Value: 0  
Description: Account1 HotelingAutoLogin

P20716  
EPM Default Value: 0  
Description: Account2 HotelingAutoLogin

P20717  
EPM Default Value: 0  
Description: Account3 HotelingAutoLogin

P20718  
EPM Default Value: 0  
Description: Account4 HotelingAutoLogin

P20721  
EPM Default Value:  
Description: Account1 HotelingUserId

P20722  
EPM Default Value:  
Description: Account2 HotelingUserId

P20723  
EPM Default Value:  
Description: Account3 HotelingUserId

P20724  
EPM Default Value:  
Description: Account4 HotelingUserId

P20727  
EPM Default Value:  
Description: Account1 HotelingPassWord

P20728  
EPM Default Value:  
Description: Account2 HotelingPassWord

P20729  
EPM Default Value:  
Description: Account3 HotelingPassWord

P20730  
EPM Default Value:  
Description: Account4 HotelingPassWord

P20733  
EPM Default Value: 0  
Description: Account1 EnableCallCenterStatus

P20734  
EPM Default Value: 0  
Description: Account2 EnableCallCenterStatus

P20735  
EPM Default Value: 0  
Description: Account3 EnableCallCenterStatus

P20736  
EPM Default Value: 0  
Description: Account4 EnableCallCenterStatus

P20739  
EPM Default Value: 0  
Description: Account1 EnableCallCenterTrace

P20740  
EPM Default Value: 0  
Description: Account2 EnableCallCenterTrace

P20741  
EPM Default Value: 0  
Description: Account3 EnableCallCenterTrace

P20742  
EPM Default Value: 0  
Description: Account4 EnableCallCenterTrace

P20745  
EPM Default Value: 0  
Description: Account1 EnableCallCenterEmergencyEscalation

P20746  
EPM Default Value: 0  
Description: Account2 EnableCallCenterEmergencyEscalation

P20747  
EPM Default Value: 0  
Description: Account3 EnableCallCenterEmergencyEscalation

P20748  
EPM Default Value: 0  
Description: Account4 EnableCallCenterEmergencyEscalation

P20751  
EPM Default Value:  
Description: Account1 CallCenterSupervisorCode1

P20752  
EPM Default Value:  
Description: Account1 CallCenterSupervisorCode2

P20753  
EPM Default Value:  
Description: Account1 CallCenterSupervisorCode3

P20754  
EPM Default Value:  
Description: Account1 CallCenterSupervisorCode4

P20755  
EPM Default Value:  
Description: Account1 CallCenterSupervisorCode5

P20757  
EPM Default Value:  
Description: Account2 CallCenterSupervisorCode1

P20758  
EPM Default Value:  
Description: Account2 CallCenterSupervisorCode2

P20759  
EPM Default Value:  
Description: Account2 CallCenterSupervisorCode3

P20760  
EPM Default Value:  
Description: Account2 CallCenterSupervisorCode4

P20761  
EPM Default Value:  
Description: Account2 CallCenterSupervisorCode5

P20763  
EPM Default Value:  
Description: Account3 CallCenterSupervisorCode1

P20764  
EPM Default Value:  
Description: Account3 CallCenterSupervisorCode2

P20765  
EPM Default Value:  
Description: Account3 CallCenterSupervisorCode3

P20766  
EPM Default Value:  
Description: Account3 CallCenterSupervisorCode4

P20767  
EPM Default Value:  
Description: Account3 CallCenterSupervisorCode5

P20769  
EPM Default Value:  
Description: Account4 CallCenterSupervisorCode1

P20770  
EPM Default Value:  
Description: Account4 CallCenterSupervisorCode2

P20771  
EPM Default Value:  
Description: Account4 CallCenterSupervisorCode3

P20772  
EPM Default Value:  
Description: Account4 CallCenterSupervisorCode4

P20773  
EPM Default Value:  
Description: Account4 CallCenterSupervisorCode5

P20787  
EPM Default Value:  
Description: Account1 CallCenterSupervisorName1

P20788  
EPM Default Value:  
Description: Account1 CallCenterSupervisorName2

P20789  
EPM Default Value:  
Description: Account1 CallCenterSupervisorName3

P20790  
EPM Default Value:  
Description: Account1 CallCenterSupervisorName4

P20791  
EPM Default Value:  
Description: Account1 CallCenterSupervisorName5

P20793  
EPM Default Value:  
Description: Account2 CallCenterSupervisorName1

P20794  
EPM Default Value:  
Description: Account2 CallCenterSupervisorName2

P20795  
EPM Default Value:  
Description: Account2 CallCenterSupervisorName3

P20796  
EPM Default Value:  
Description: Account2 CallCenterSupervisorName4

P20797  
EPM Default Value:  
Description: Account2 CallCenterSupervisorName5

P20799  
EPM Default Value:  
Description: Account3 CallCenterSupervisorName1

P20800  
EPM Default Value:  
Description: Account3 CallCenterSupervisorName2

P20801  
EPM Default Value:  
Description: Account3 CallCenterSupervisorName3

P20802  
EPM Default Value:  
Description: Account3 CallCenterSupervisorName4

P20803  
EPM Default Value:  
Description: Account3 CallCenterSupervisorName5

P20805  
EPM Default Value:  
Description: Account4 CallCenterSupervisorName1

P20806  
EPM Default Value:  
Description: Account4 CallCenterSupervisorName2

P20807  
EPM Default Value:  
Description: Account4 CallCenterSupervisorName3

P20808  
EPM Default Value:  
Description: Account4 CallCenterSupervisorName4

P20809  
EPM Default Value:  
Description: Account4 CallCenterSupervisorName5

P20823  
EPM Default Value: 0  
Description: Account1 EnableCallCenterDispCode

P20824  
EPM Default Value: 0  
Description: Account2 EnableCallCenterDispCode

P20825  
EPM Default Value: 0  
Description: Account3 EnableCallCenterDispCode

P20826  
EPM Default Value: 0  
Description: Account4 EnableCallCenterDispCode

P20829  
EPM Default Value:  
Description: Account1 CCDispCode1

P20830  
EPM Default Value:  
Description: Account1 CCDispCode2



P20831  
EPM Default Value:  
Description: Account1 CCDispCode3

P20832  
EPM Default Value:  
Description: Account1 CCDispCode4

P20833  
EPM Default Value:  
Description: Account1 CCDispCode5

P20835  
EPM Default Value:  
Description: Account2 CCDispCode1

P20836  
EPM Default Value:  
Description: Account2 CCDispCode2

P20837  
EPM Default Value:  
Description: Account2 CCDispCode3

P20838  
EPM Default Value:  
Description: Account2 CCDispCode4

P20839  
EPM Default Value:  
Description: Account2 CCDispCode5

P20841  
EPM Default Value:  
Description: Account3 CCDispCode1

P20842  
EPM Default Value:  
Description: Account3 CCDispCode2

P20843  
EPM Default Value:  
Description: Account3 CCDispCode3

P20844  
EPM Default Value:  
Description: Account3 CCDispCode4

P20845  
EPM Default Value:  
Description: Account3 CCDispCode5

P20847  
EPM Default Value:  
Description: Account4 CCDispCode1

P20848  
EPM Default Value:  
Description: Account4 CCDispCode2

P20849  
EPM Default Value:  
Description: Account4 CCDispCode3

P20850  
EPM Default Value:  
Description: Account4 CCDispCode4

P20851  
EPM Default Value:  
Description: Account4 CCDispCode5

P20865  
EPM Default Value:  
Description: Account1 CCDispName1

P20866  
EPM Default Value:  
Description: Account1 CCDispName2

P20867  
EPM Default Value:  
Description: Account1 CCDispName3

P20868  
EPM Default Value:  
Description: Account1 CCDispName4

P20869  
EPM Default Value:  
Description: Account1 CCDispName5

P20871  
EPM Default Value:  
Description: Account2 CCDispName1

P20872  
EPM Default Value:  
Description: Account2 CCDispName2

P20873  
EPM Default Value:  
Description: Account2 CCDispName3

P20874  
EPM Default Value:  
Description: Account2 CCDispName4

P20875  
EPM Default Value:  
Description: Account2 CCDispName5

P20877  
EPM Default Value:  
Description: Account3 CCDispName1

P20878  
EPM Default Value:  
Description: Account3 CCDispName2

P20879  
EPM Default Value:  
Description: Account3 CCDispName3

P20880  
EPM Default Value:  
Description: Account3 CCDispName4

P20881  
EPM Default Value:  
Description: Account3 CCDispName5

P20883  
EPM Default Value:  
Description: Account4 CCDispName1

P20884  
EPM Default Value:  
Description: Account4 CCDispName2

P20885  
EPM Default Value:  
Description: Account4 CCDispName3

P20886  
EPM Default Value:  
Description: Account4 CCDispName4

P20887  
EPM Default Value:  
Description: Account4 CCDispName5

P20900  
EPM Default Value:  
Description: Account1 ACDUnAvailableName1

P20901  
EPM Default Value:  
Description: Account1 ACDUnAvailableName2

P20902  
EPM Default Value:  
Description: Account1 ACDUnAvailableName3

P20903  
EPM Default Value:  
Description: Account1 ACDUnAvailableName4

P20904  
EPM Default Value:  
Description: Account1 ACDUnAvailableName5

P20905  
EPM Default Value:  
Description: Account2 ACDUnAvailableName1

P20906  
EPM Default Value:  
Description: Account2 ACDUnAvailableName2

P20907  
EPM Default Value:  
Description: Account2 ACDUnAvailableName3

P20908  
EPM Default Value:  
Description: Account2 ACDUnAvailableName4

P20909  
EPM Default Value:  
Description: Account2 ACDUnAvailableName5

P20910  
EPM Default Value:  
Description: Account3 ACDUnAvailableName1

P20911  
EPM Default Value:  
Description: Account3 ACDUnAvailableName2

P20912  
EPM Default Value:  
Description: Account3 ACDUnAvailableName3

P20913  
EPM Default Value:  
Description: Account3 ACDUnAvailableName4

P20914  
EPM Default Value:  
Description: Account3 ACDUnAvailableName5

P20915  
EPM Default Value:  
Description: Account4 ACDUnAvailableName1

P20916  
EPM Default Value:  
Description: Account4 ACUnAvailableName2

P20917  
EPM Default Value:  
Description: Account4 ACUnAvailableName3

P20918  
EPM Default Value:  
Description: Account4 ACUnAvailableName4

P20919  
EPM Default Value:  
Description: Account4 ACUnAvailableName5

P20930  
EPM Default Value: 0  
Description: CallPark Flag

P20931  
EPM Default Value:  
Description: CallPark Code

P20932  
EPM Default Value: 5  
Description: FirmwareUpgrade ZeroTouchTime

P20933  
EPM Default Value: 0  
Description: FirmwareUpgrade ZeroTouchEnable

P20943  
EPM Default Value: 1  
Description: Preference DetectIPConflict

P20944  
EPM Default Value: 0  
Description: BwXsiDir AllowSipAuthForXsi

P20945  
EPM Default Value:  
Description: BwXsiDir Host

P20946  
EPM Default Value: 80  
Description: BwXsiDir Port

P20947  
EPM Default Value: 0  
Description: BwXsiDir ServerType

P20948  
EPM Default Value:  
Description: BwXsiDir UserId

P20949  
EPM Default Value:  
Description: BwXsiDir PassWord

P20950  
EPM Default Value:  
Description: BwXsiDir UCUser

P20951  
EPM Default Value:  
Description: BwXsiDir UCPassWord

P20952  
EPM Default Value: 0  
Description: LcdItemLevelEnable

P20953  
EPM Default Value: 1  
Description: BwXsiDir Group

P20954  
EPM Default Value: 1  
Description: BwXsiDir GroupCommon

P20955  
EPM Default Value: 1  
Description: BwXsiDir Enterprise

P20956  
EPM Default Value: 1  
Description: BwXsiDir EnterpriseCommon

P20957  
EPM Default Value: 1  
Description: BwXsiDir Personal

P20958  
EPM Default Value: 1  
Description: BwXsiDir CustomDir

P20959  
EPM Default Value: 1  
Description: BwXsiDir CallLogs

P20960  
EPM Default Value:  
Description: BwXsiDir GroupName

P20961  
EPM Default Value:  
Description: BwXsiDir GroupCName

P20962  
EPM Default Value:  
Description: BwXsiDir EnterpriseName

P20963  
EPM Default Value:  
Description: BwXsiDir EnterpriseCName

P20964  
EPM Default Value:  
Description: BwXsiDir PersonalName

P20970  
EPM Default Value: 300  
Description: Account1 SubscribeExpires

P20971  
EPM Default Value: 300  
Description: Account2 SubscribeExpires

P20972  
EPM Default Value: 300  
Description: Account3 SubscribeExpires

P20973  
EPM Default Value: 300  
Description: Account4 SubscribeExpires

P20976  
EPM Default Value: 0  
Description: Account1 SCABargeln

P20977  
EPM Default Value: 0  
Description: Account2 SCABargeln

P20978  
EPM Default Value: 0  
Description: Account3 SCABargeln

P20979  
EPM Default Value: 0  
Description: Account4 SCABargeln

P20982  
EPM Default Value: 1  
Description: Preference SpeedDialDetectDigitMap

P20983  
EPM Default Value: 0  
Description: Preference CheckSyncWithAuth

P20984  
EPM Default Value:  
Description: Features CallBackCode

P20992  
EPM Default Value: 1  
Description: Preference OpenSideTone

P20994  
EPM Default Value:  
Description: FirmwareUpGrade SoftKeyXmlUrl

P23132  
EPM Default Value: 1  
Description: FirmwareUpGrade UpgradeEXPRom

P40000  
EPM Default Value:  
Description: GlobalConfig UserAgent

P40002  
EPM Default Value:  
Description: FirmwareUpGrade ExpServer

P56203  
EPM Default Value: 4  
Description: Preference BusyToneTimer

P56204  
EPM Default Value: 0  
Description: AutoRedial OnOff

P56205  
EPM Default Value: 3  
Description: AutoRedial Interval

P56206  
EPM Default Value: 3  
Description: AutoRedial Times

P58101  
EPM Default Value:  
Description: SMS Number

P58102  
EPM Default Value:  
Description: SMS Message

P62000  
EPM Default Value: \_\_exp31type\_\_  
Description: EXP3\_1\_1 Type

P62001  
EPM Default Value: \_\_exp31value\_\_  
Description: Exp3\_1\_1 Value

P62002  
EPM Default Value: \_\_exp31label\_\_  
Description: Exp3\_1\_1 Label

P62003  
EPM Default Value: \_\_exp31acct\_\_  
Description: Exp3\_1\_1 Account

P62004  
EPM Default Value: \_\_exp31pu\_\_  
Description: Exp3\_1\_1 PickupCode

P62005  
EPM Default Value: \_\_exp32type\_\_  
Description: Exp3\_1\_2 KeyType

P62006  
EPM Default Value: \_\_exp32value\_\_  
Description: Exp3\_1\_2 Value

P62007  
EPM Default Value: \_\_exp32label\_\_  
Description: Exp3\_1\_2 Label

P62008  
EPM Default Value: \_\_exp32acct\_\_  
Description: Exp3\_1\_2 Account

P62009  
EPM Default Value: \_\_exp32pu\_\_  
Description: Exp3\_1\_2 PickupCode

P62010  
EPM Default Value: \_\_exp33type\_\_  
Description: Exp3\_1\_3 KeyType

P62011  
EPM Default Value: \_\_exp33value\_\_  
Description: Exp3\_1\_3 Value

P62012  
EPM Default Value: \_\_exp33label\_\_  
Description: Exp3\_1\_3 Label

P62013  
EPM Default Value: \_\_exp33acct\_\_  
Description: Exp3\_1\_3 Account

P62014  
EPM Default Value: \_\_exp33pu\_\_  
Description: Exp3\_1\_3 PickupCode

P62015  
EPM Default Value: \_\_exp34type\_\_  
Description: Exp3\_1\_4 KeyType

P62016  
EPM Default Value: \_\_exp34value\_\_  
Description: Exp3\_1\_4 Value

P62017  
EPM Default Value: \_\_exp34label\_\_  
Description: Exp3\_1\_4 Label

P62018  
EPM Default Value: \_\_exp34acct\_\_  
Description: Exp3\_1\_4 Account

P62019  
EPM Default Value: \_\_exp34pu\_\_  
Description: Exp3\_1\_4 PickupCode

P62020  
EPM Default Value: \_\_exp35type\_\_  
Description: Exp3\_1\_5 KeyType

P62021  
EPM Default Value: \_\_exp35value\_\_  
Description: Exp3\_1\_5 Value

P62022  
EPM Default Value: \_\_exp35label\_\_  
Description: Exp3\_1\_5 Label

P62023  
EPM Default Value: \_\_exp35acct\_\_  
Description: Exp3\_1\_5 Account

P62024  
EPM Default Value: \_\_exp35pu\_\_  
Description: Exp3\_1\_5 PickupCode

P62025  
EPM Default Value: \_\_exp36type\_\_  
Description: Exp3\_1\_6 KeyType

P62026  
EPM Default Value: \_\_exp36value\_\_  
Description: Exp3\_1\_6 Value

P62027  
EPM Default Value: \_\_exp36label\_\_  
Description: Exp3\_1\_6 Label

P62028  
EPM Default Value: \_\_exp36acct\_\_  
Description: Exp3\_1\_6 Account

P62029  
EPM Default Value: \_\_exp36pu\_\_  
Description: Exp3\_1\_6 PickupCode

P62030  
EPM Default Value: \_\_exp37type\_\_  
Description: Exp3\_1\_7 KeyType

P62031  
EPM Default Value: \_\_exp37value\_\_  
Description: Exp3\_1\_7 Value

P62032  
EPM Default Value: \_\_exp37label\_\_  
Description: Exp3\_1\_7 Label

P62033  
EPM Default Value: \_\_exp37acct\_\_  
Description: Exp3\_1\_7 Account

P62034  
EPM Default Value: \_\_exp37pu\_\_  
Description: Exp3\_1\_7 PickupCode

P62035  
EPM Default Value: \_\_exp38type\_\_  
Description: Exp3\_1\_8 KeyType

P62036  
EPM Default Value: \_\_exp38value\_\_  
Description: Exp3\_1\_8 Value

P62037  
EPM Default Value: \_\_exp38label\_\_  
Description: Exp3\_1\_8 Label



P62038  
EPM Default Value: \_\_exp38acct\_\_  
Description: Exp3\_1\_8 Account

P62039  
EPM Default Value: \_\_exp38pu\_\_  
Description: Exp3\_1\_8 PickupCode

P62040  
EPM Default Value: \_\_exp39type\_\_  
Description: Exp3\_1\_9 KeyType

P62041  
EPM Default Value: \_\_exp39value\_\_  
Description: Exp3\_1\_9 Value

P62042  
EPM Default Value: \_\_exp39label\_\_  
Description: Exp3\_1\_9 Label

P62043  
EPM Default Value: \_\_exp39acct\_\_  
Description: Exp3\_1\_9 Account

P62044  
EPM Default Value: \_\_exp39pu\_\_  
Description: Exp3\_1\_9 PickupCode

P62045  
EPM Default Value: \_\_exp310type\_\_  
Description: Exp3\_1\_10 KeyType

P62046  
EPM Default Value: \_\_exp310value\_\_  
Description: Exp3\_1\_10 Value

P62047  
EPM Default Value: \_\_exp310label\_\_  
Description: Exp3\_1\_10 Label

P62048  
EPM Default Value: \_\_exp310acct\_\_  
Description: Exp3\_1\_10 Account

P62049  
EPM Default Value: \_\_exp310pu\_\_  
Description: Exp3\_1\_10 PickupCode

P62050  
EPM Default Value: \_\_exp311type\_\_  
Description: Exp3\_1\_11 KeyType

P62051  
EPM Default Value: \_\_exp311value\_\_  
Description: Exp3\_1\_11 Value

P62052  
EPM Default Value: \_\_exp311label\_\_  
Description: Exp3\_1\_11 Label

P62053  
EPM Default Value: \_\_exp311acct\_\_  
Description: Exp3\_1\_11 Account

P62054  
EPM Default Value: \_\_exp311pu\_\_  
Description: Exp3\_1\_11 PickupCode

P62055  
EPM Default Value: \_\_exp312type\_\_  
Description: Exp3\_1\_12 KeyType

P62056  
EPM Default Value: \_\_exp312value\_\_  
Description: Exp3\_1\_12 Value

P62057  
EPM Default Value: \_\_exp312label\_\_  
Description: Exp3\_1\_12 Label

P62058  
EPM Default Value: \_\_exp312acct\_\_  
Description: Exp3\_1\_12 Account

P62059  
EPM Default Value: \_\_exp312pu\_\_  
Description: Exp3\_1\_12 PickupCode

P62060  
EPM Default Value: \_\_exp313type\_\_  
Description: Exp3\_1\_13 KeyType

P62061  
EPM Default Value: \_\_exp313value\_\_  
Description: Exp3\_1\_13 Value

P62062  
EPM Default Value: \_\_exp313label\_\_  
Description: Exp3\_1\_13 Label

P62063  
EPM Default Value: \_\_exp313acct\_\_  
Description: Exp3\_1\_13 Account

P62064  
EPM Default Value: \_\_exp313pu\_\_  
Description: Exp3\_1\_13 PickupCode

P62065  
EPM Default Value: \_\_exp314type\_\_  
Description: Exp3\_1\_14 KeyType

P62066  
EPM Default Value: \_\_exp314value\_\_  
Description: Exp3\_1\_14 Value

P62067  
EPM Default Value: \_\_exp314label\_\_  
Description: Exp3\_1\_14 Label

P62068  
EPM Default Value: \_\_exp314acct\_\_  
Description: Exp3\_1\_14 Account

P62069  
EPM Default Value: \_\_exp314pu\_\_  
Description: Exp3\_1\_14 PickupCode

P62070  
EPM Default Value: \_\_exp315type\_\_  
Description: Exp3\_1\_15 KeyType

P62071  
EPM Default Value: \_\_exp315value\_\_  
Description: Exp3\_1\_15 Value

P62072  
EPM Default Value: \_\_exp315label\_\_  
Description: Exp3\_1\_15 Label

P62073  
EPM Default Value: \_\_exp315acct\_\_  
Description: Exp3\_1\_15 Account

P62074  
EPM Default Value: \_\_exp315pu\_\_  
Description: Exp3\_1\_15 PickupCode

P62075  
EPM Default Value: \_\_exp316type\_\_  
Description: Exp3\_1\_16 KeyType

P62076  
EPM Default Value: \_\_exp316value\_\_  
Description: Exp3\_1\_16 Value

P62077  
EPM Default Value: \_\_exp316label\_\_  
Description: Exp3\_1\_16 Label

P62078  
EPM Default Value: \_\_exp316acct\_\_  
Description: Exp3\_1\_16 Account

P62079  
EPM Default Value: \_\_exp316pu\_\_  
Description: Exp3\_1\_16 PickupCode

P62080  
EPM Default Value: \_\_exp317type\_\_  
Description: Exp3\_1\_17 KeyType

P62081  
EPM Default Value: \_\_exp317value\_\_  
Description: Exp3\_1\_17 Value

P62082  
EPM Default Value: \_\_exp317label\_\_  
Description: Exp3\_1\_17 Label

P62083  
EPM Default Value: \_\_exp317acct\_\_  
Description: Exp3\_1\_17 Account

P62084  
EPM Default Value: \_\_exp317pu\_\_  
Description: Exp3\_1\_17 PickupCode

P62085  
EPM Default Value: \_\_exp318type\_\_  
Description: Exp3\_1\_18 KeyType

P62086  
EPM Default Value: \_\_exp318value\_\_  
Description: Exp3\_1\_18 Value

P62087  
EPM Default Value: \_\_exp318label\_\_  
Description: Exp3\_1\_18 Label

P62088  
EPM Default Value: \_\_exp318acct\_\_  
Description: Exp3\_1\_18 Account

P62089  
EPM Default Value: \_\_exp318pu\_\_  
Description: Exp3\_1\_18 PickupCode

P62090  
EPM Default Value: \_\_exp319type\_\_  
Description: Exp3\_1\_19 KeyType

P62091  
EPM Default Value: \_\_exp319value\_\_  
Description: Exp3\_1\_19 Value

P62092  
EPM Default Value: \_\_exp319label\_\_  
Description: Exp3\_1\_19 Label

P62093  
EPM Default Value: \_\_exp319acct\_\_  
Description: Exp3\_1\_19 Account

P62094  
EPM Default Value: \_\_exp319pu\_\_  
Description: Exp3\_1\_19 PickupCode

P62095  
EPM Default Value: \_\_exp320type\_\_  
Description: Exp3\_1\_20 KeyType

P62096  
EPM Default Value: \_\_exp320value\_\_  
Description: Exp3\_1\_20 Value

P62097  
EPM Default Value: \_\_exp320label\_\_  
Description: Exp3\_1\_20 Label

P62098  
EPM Default Value: \_\_exp320acct\_\_  
Description: Exp3\_1\_20 Account

P62099  
EPM Default Value: \_\_exp320pu\_\_  
Description: Exp3\_1\_20 PickupCode

P62100  
EPM Default Value: \_\_exp321type\_\_  
Description: Exp3\_2\_1 KeyType

P62101  
EPM Default Value: \_\_exp321value\_\_  
Description: Exp3\_2\_1 Value

P62102  
EPM Default Value: \_\_exp321label\_\_  
Description: Exp3\_2\_1 Label

P62103  
EPM Default Value: \_\_exp321acct\_\_  
Description: Exp3\_2\_1 Account

P62104  
EPM Default Value: \_\_exp321pu\_\_  
Description: Exp3\_2\_1 PickupCode

P62105  
EPM Default Value: \_\_exp322type\_\_  
Description: Exp3\_2\_2 KeyType

P62106  
EPM Default Value: \_\_exp322value\_\_  
Description: Exp3\_2\_2 Value

P62107  
EPM Default Value: \_\_exp322label\_\_  
Description: Exp3\_2\_2 Label

P62108  
EPM Default Value: \_\_exp322acct\_\_  
Description: Exp3\_2\_2 Account

P62109  
EPM Default Value: \_\_exp322pu\_\_  
Description: Exp3\_2\_2 PickupCode

P62110  
EPM Default Value: \_\_exp323type\_\_  
Description: Exp3\_2\_3 KeyType

P62111  
EPM Default Value: \_\_exp323value\_\_  
Description: Exp3\_2\_3 Value

P62112  
EPM Default Value: \_\_exp323label\_\_  
Description: Exp3\_2\_3 Label

P62113  
EPM Default Value: \_\_exp323acct\_\_  
Description: Exp3\_2\_3 Account

P62114  
EPM Default Value: \_\_exp323pu\_\_  
Description: Exp3\_2\_3 PickupCode

P62115  
EPM Default Value: \_\_exp324type\_\_  
Description: Exp3\_2\_4 KeyType

P62116  
EPM Default Value: \_\_exp324value\_\_  
Description: Exp3\_2\_4 Value

P62117  
EPM Default Value: \_\_exp324label\_\_  
Description: Exp3\_2\_4 Label

P62118  
EPM Default Value: \_\_exp324acct\_\_  
Description: Exp3\_2\_4 Account

P62119  
EPM Default Value: \_\_exp324pu\_\_  
Description: Exp3\_2\_4 PickupCode

P62120  
EPM Default Value: \_\_exp324type\_\_  
Description: Exp3\_2\_5 KeyType

P62121  
EPM Default Value: \_\_exp325value\_\_  
Description: Exp3\_2\_5 Value

P62122  
EPM Default Value: \_\_exp325label\_\_  
Description: Exp3\_2\_5 Label

P62123  
EPM Default Value: \_\_exp325acct\_\_  
Description: Exp3\_2\_5 Account

P62124  
EPM Default Value: \_\_exp325pu\_\_  
Description: Exp3\_2\_5 PickupCode

P62125  
EPM Default Value: \_\_exp326type\_\_  
Description: Exp3\_2\_6 KeyType

P62126  
EPM Default Value: \_\_exp326value\_\_  
Description: Exp3\_2\_6 Value

P62127  
EPM Default Value: \_\_exp326label\_\_  
Description: Exp3\_2\_6 Label

P62128  
EPM Default Value: \_\_exp326acct\_\_  
Description: Exp3\_2\_6 Account

P62129  
EPM Default Value: \_\_exp326pu\_\_  
Description: Exp3\_2\_6 PickupCode

P62130  
EPM Default Value: \_\_exp327type\_\_  
Description: Exp3\_2\_7 KeyType

P62131  
EPM Default Value: \_\_exp327value\_\_  
Description: Exp3\_2\_7 Value

P62132  
EPM Default Value: \_\_exp327label\_\_  
Description: Exp3\_2\_7 Label

P62133  
EPM Default Value: \_\_exp327acct\_\_  
Description: Exp3\_2\_7 Account

P62134  
EPM Default Value: \_\_exp327pu\_\_  
Description: Exp3\_2\_7 PickupCode

P62135  
EPM Default Value: \_\_exp328type\_\_  
Description: Exp3\_2\_8 KeyType

P62136  
EPM Default Value: \_\_exp328value\_\_  
Description: Exp3\_2\_8 Value

P62137  
EPM Default Value: \_\_exp328label\_\_  
Description: Exp3\_2\_8 Label

P62138  
EPM Default Value: \_\_exp328acct\_\_  
Description: Exp3\_2\_8 Account

P62139  
EPM Default Value: \_\_exp328pu\_\_  
Description: Exp3\_2\_8 PickupCode

P62140  
EPM Default Value: \_\_exp329type\_\_  
Description: Exp3\_2\_9 KeyType

P62141  
EPM Default Value: \_\_exp329value\_\_  
Description: Exp3\_2\_9 Value

P62142  
EPM Default Value: \_\_exp329label\_\_  
Description: Exp3\_2\_9 Label

P62143  
EPM Default Value: \_\_exp329acct\_\_  
Description: Exp3\_2\_9 Account

P62144  
EPM Default Value: \_\_exp329pu\_\_  
Description: Exp3\_2\_9 PickupCode

P62145  
EPM Default Value: \_\_exp330type\_\_  
Description: Exp3\_2\_10 KeyType

P62146  
EPM Default Value: \_\_exp330value\_\_  
Description: Exp3\_2\_10 Value

P62147  
EPM Default Value: \_\_exp330label\_\_  
Description: Exp3\_2\_10 Label

P62148  
EPM Default Value: \_\_exp330acct\_\_  
Description: Exp3\_2\_10 Account

P62149  
EPM Default Value: \_\_exp330pu\_\_  
Description: Exp3\_2\_10 PickupCode

P62150  
EPM Default Value: \_\_exp331type\_\_  
Description: Exp3\_2\_11 KeyType

P62151  
EPM Default Value: \_\_exp331value\_\_  
Description: Exp3\_2\_11 Value

P62152  
EPM Default Value: \_\_exp331label\_\_  
Description: Exp3\_2\_11 Label

P62153  
EPM Default Value: \_\_exp331acct\_\_  
Description: Exp3\_2\_11 Account

P62154  
EPM Default Value: \_\_exp331pu\_\_  
Description: Exp3\_2\_11 PickupCode

P62155  
EPM Default Value: \_\_exp332type\_\_  
Description: Exp3\_2\_12 KeyType

P62156  
EPM Default Value: \_\_exp332value\_\_  
Description: Exp3\_2\_12 Value

P62157  
EPM Default Value: \_\_exp332label\_\_  
Description: Exp3\_2\_12 Label

P62158  
EPM Default Value: \_\_exp332acct\_\_  
Description: Exp3\_2\_12 Account

P62159  
EPM Default Value: \_\_exp332pu\_\_  
Description: Exp3\_2\_12 PickupCode

P62160  
EPM Default Value: \_\_exp333type\_\_  
Description: Exp3\_2\_13 KeyType

P62161  
EPM Default Value: \_\_exp333value\_\_  
Description: Exp3\_2\_13 Value

P62162  
EPM Default Value: \_\_exp333label\_\_  
Description: Exp3\_2\_13 Label

P62163  
EPM Default Value: \_\_exp333acct\_\_  
Description: Exp3\_2\_13 Account

P62164  
EPM Default Value: \_\_exp333pu\_\_  
Description: Exp3\_2\_13 PickupCode

P62165  
EPM Default Value: \_\_exp334type\_\_  
Description: Exp3\_2\_14 KeyType

P62166  
EPM Default Value: \_\_exp334value\_\_  
Description: Exp3\_2\_14 Value

P62167  
EPM Default Value: \_\_exp334label\_\_  
Description: Exp3\_2\_14 Label

P62168  
EPM Default Value: \_\_exp334acct\_\_  
Description: Exp3\_2\_14 Account

P62169  
EPM Default Value: \_\_exp334pu\_\_  
Description: Exp3\_2\_14 PickupCode

P62170  
EPM Default Value: \_\_exp335type\_\_  
Description: Exp3\_2\_15 KeyType

P62171  
EPM Default Value: \_\_exp335value\_\_  
Description: Exp3\_2\_15 Value

P62172  
EPM Default Value: \_\_exp335label\_\_  
Description: Exp3\_2\_15 Label

P62173  
EPM Default Value: \_\_exp335acct\_\_  
Description: Exp3\_2\_15 Account

P62174  
EPM Default Value: \_\_exp335pu\_\_  
Description: Exp3\_2\_15 PickupCode

P62175  
EPM Default Value: \_\_exp336type\_\_  
Description: Exp3\_2\_16 KeyType

P62176  
EPM Default Value: \_\_exp336value\_\_  
Description: Exp3\_2\_16 Value

P62177  
EPM Default Value: \_\_exp336label\_\_  
Description: Exp3\_2\_16 Label

P62178  
EPM Default Value: \_\_exp336acct\_\_  
Description: Exp3\_2\_16 Account

P62179  
EPM Default Value: \_\_exp336pu\_\_  
Description: Exp3\_2\_16 PickupCode

P62180  
EPM Default Value: \_\_exp337type\_\_  
Description: Exp3\_2\_17 KeyType

P62181  
EPM Default Value: \_\_exp337value\_\_  
Description: Exp3\_2\_17 Value



P62182  
EPM Default Value: \_\_exp337label\_\_  
Description: Exp3\_2\_17 Label

P62183  
EPM Default Value: \_\_exp337acct\_\_  
Description: Exp3\_2\_17 Account

P62184  
EPM Default Value: \_\_exp337pu\_\_  
Description: Exp3\_2\_17 PickupCode

P62185  
EPM Default Value: \_\_exp338type\_\_  
Description: Exp3\_2\_18 KeyType

P62186  
EPM Default Value: \_\_exp338value\_\_  
Description: Exp3\_2\_18 Value

P62187  
EPM Default Value: \_\_exp338label\_\_  
Description: Exp3\_2\_18 Label

P62188  
EPM Default Value: \_\_exp338acct\_\_  
Description: Exp3\_2\_18 Account

P62189  
EPM Default Value: \_\_exp338pu\_\_  
Description: Exp3\_2\_18 PickupCode

P62190  
EPM Default Value: \_\_exp339type\_\_  
Description: Exp3\_2\_19 KeyType

P62191  
EPM Default Value: \_\_exp339value\_\_  
Description: Exp3\_2\_19 Value

P62192  
EPM Default Value: \_\_exp339label\_\_  
Description: Exp3\_2\_19 Label

P62193  
EPM Default Value: \_\_exp339acct\_\_  
Description: Exp3\_2\_19 Account

P62194  
EPM Default Value: \_\_exp339pu\_\_  
Description: Exp3\_2\_19 PickupCode

P62195  
EPM Default Value: \_\_exp340type\_\_  
Description: Exp3\_2\_20 KeyType

P62196  
EPM Default Value: \_\_exp340value\_\_  
Description: Exp3\_2\_20 Value

P62197  
EPM Default Value: \_\_exp340label\_\_  
Description: Exp3\_2\_20 Label

P62198  
EPM Default Value: \_\_exp340acct\_\_  
Description: Exp3\_2\_20 Account

P62199  
EPM Default Value: \_\_exp340pu\_\_  
Description: Exp3\_2\_20 PickupCode

P63000  
EPM Default Value: \_\_exp41type\_\_  
Description: Exp4\_1\_1 KeyType

P63001  
EPM Default Value: \_\_exp41value\_\_  
Description: Exp4\_1\_1 Value

P63002  
EPM Default Value: \_\_exp41label\_\_  
Description: Exp4\_1\_1 Label

P63003  
EPM Default Value: \_\_exp41acct\_\_  
Description: Exp4\_1\_1 Account

P63004  
EPM Default Value: \_\_exp41pu\_\_  
Description: Exp4\_1\_1 PickupCode

P63005  
EPM Default Value: \_\_exp42type\_\_  
Description: Exp4\_1\_2 KeyType

P63006  
EPM Default Value: \_\_exp42value\_\_  
Description: Exp4\_1\_2 Value

P63007  
EPM Default Value: \_\_exp42label\_\_  
Description: Exp4\_1\_2 Label

P63008  
EPM Default Value: \_\_exp42acct\_\_  
Description: Exp4\_1\_2 Account

P63009  
EPM Default Value: \_\_exp42pu\_\_  
Description: Exp4\_1\_2 PickupCode

P63010  
EPM Default Value: \_\_exp43type\_\_  
Description: Exp4\_1\_3 KeyType

P63011  
EPM Default Value: \_\_exp43value\_\_  
Description: Exp4\_1\_3 Value

P63012  
EPM Default Value: \_\_exp43label\_\_  
Description: Exp4\_1\_3 Label

P63013  
EPM Default Value: \_\_exp43acct\_\_  
Description: Exp4\_1\_3 Account

P63014  
EPM Default Value: \_\_exp43pu\_\_  
Description: Exp4\_1\_3 PickupCode

P63015  
EPM Default Value: \_\_exp44type\_\_  
Description: Exp4\_1\_4 KeyType

P63016  
EPM Default Value: \_\_exp44value\_\_  
Description: Exp4\_1\_4 Value

P63017  
EPM Default Value: \_\_exp44label\_\_  
Description: Exp4\_1\_4 Label

P63018  
EPM Default Value: \_\_exp44acct\_\_  
Description: Exp4\_1\_4 Account

P63019  
EPM Default Value: \_\_exp44pu\_\_  
Description: Exp4\_1\_4 PickupCode

P63020  
EPM Default Value: \_\_exp45type\_\_  
Description: Exp4\_1\_5 KeyType

P63021  
EPM Default Value: \_\_exp45value\_\_  
Description: Exp4\_1\_5 Value

P63022  
EPM Default Value: \_\_exp45label\_\_  
Description: Exp4\_1\_5 Label

P63023  
EPM Default Value: \_\_exp45acct\_\_  
Description: Exp4\_1\_5 Account

P63024  
EPM Default Value: \_\_exp45pu\_\_  
Description: Exp4\_1\_5 PickupCode

P63025  
EPM Default Value: \_\_exp46type\_\_  
Description: Exp4\_1\_6 KeyType

P63026  
EPM Default Value: \_\_exp46value\_\_  
Description: Exp4\_1\_6 Value

P63027  
EPM Default Value: \_\_exp46label\_\_  
Description: Exp4\_1\_6 Label

P63028  
EPM Default Value: \_\_exp46acct\_\_  
Description: Exp4\_1\_6 Account

P63029  
EPM Default Value: \_\_exp46pu\_\_  
Description: Exp4\_1\_6 PickupCode

P63030  
EPM Default Value: \_\_exp47type\_\_  
Description: Exp4\_1\_7 KeyType

P63031  
EPM Default Value: \_\_exp47value\_\_  
Description: Exp4\_1\_7 Value

P63032  
EPM Default Value: \_\_exp47label\_\_  
Description: Exp4\_1\_7 Label

P63033  
EPM Default Value: \_\_exp47acct\_\_  
Description: Exp4\_1\_7 Account

P63034  
EPM Default Value: \_\_exp47pu\_\_  
Description: Exp4\_1\_7 PickupCode

P63035  
EPM Default Value: \_\_exp48type\_\_  
Description: Exp4\_1\_8 KeyType

P63036  
EPM Default Value: \_\_exp48value\_\_  
Description: Exp4\_1\_8 Value

P63037  
EPM Default Value: \_\_exp48label\_\_  
Description: Exp4\_1\_8 Label

P63038  
EPM Default Value: \_\_exp48acct\_\_  
Description: Exp4\_1\_8 Account

P63039  
EPM Default Value: \_\_exp48pu\_\_  
Description: Exp4\_1\_8 PickupCode

P63040  
EPM Default Value: \_\_exp49type\_\_  
Description: Exp4\_1\_9 KeyType

P63041  
EPM Default Value: \_\_exp49value\_\_  
Description: Exp4\_1\_9 Value

P63042  
EPM Default Value: \_\_exp49label\_\_  
Description: Exp4\_1\_9 Label

P63043  
EPM Default Value: \_\_exp49acct\_\_  
Description: Exp4\_1\_9 Account

P63044  
EPM Default Value: \_\_exp49pu\_\_  
Description: Exp4\_1\_9 PickupCode

P63045  
EPM Default Value: \_\_exp410type\_\_  
Description: Exp4\_1\_10 KeyType

P63046  
EPM Default Value: \_\_exp410value\_\_  
Description: Exp4\_1\_10 Value

P63047  
EPM Default Value: \_\_exp410label\_\_  
Description: Exp4\_1\_10 Label

P63048  
EPM Default Value: \_\_exp410acct\_\_  
Description: Exp4\_1\_10 Account

P63049  
EPM Default Value: \_\_exp410pu\_\_  
Description: Exp4\_1\_10 PickupCode

P63050  
EPM Default Value: \_\_exp411type\_\_  
Description: Exp4\_1\_11 KeyType

P63051  
EPM Default Value: \_\_exp411value\_\_  
Description: Exp4\_1\_11 Value

P63052  
EPM Default Value: \_\_exp411label\_\_  
Description: Exp4\_1\_11 Label

P63053  
EPM Default Value: \_\_exp411acct\_\_  
Description: Exp4\_1\_11 Account

P63054  
EPM Default Value: \_\_exp411pu\_\_  
Description: Exp4\_1\_11 PickupCode

P63055  
EPM Default Value: \_\_exp412type\_\_  
Description: Exp4\_1\_12 KeyType

P63056  
EPM Default Value: \_\_exp412value\_\_  
Description: Exp4\_1\_12 Value

P63057  
EPM Default Value: \_\_exp412label\_\_  
Description: Exp4\_1\_12 Label

P63058  
EPM Default Value: \_\_exp412acct\_\_  
Description: Exp4\_1\_12 Account

P63059  
EPM Default Value: \_\_exp412pu\_\_  
Description: Exp4\_1\_12 PickupCode

P63060  
EPM Default Value: \_\_exp413type\_\_  
Description: Exp4\_1\_13 KeyType

P63061  
EPM Default Value: \_\_exp413value\_\_  
Description: Exp4\_1\_13 Value

P63062  
EPM Default Value: \_\_exp413label\_\_  
Description: Exp4\_1\_13 Label

P63063  
EPM Default Value: \_\_exp413acct\_\_  
Description: Exp4\_1\_13 Account

P63064  
EPM Default Value: \_\_exp413pu\_\_  
Description: Exp4\_1\_13 PickupCode

P63065  
EPM Default Value: \_\_exp414type\_\_  
Description: Exp4\_1\_14 KeyType

P63066  
EPM Default Value: \_\_exp414value\_\_  
Description: Exp4\_1\_14 Value

P63067  
EPM Default Value: \_\_exp414label\_\_  
Description: Exp4\_1\_14 Label

P63068  
EPM Default Value: \_\_exp414acct\_\_  
Description: Exp4\_1\_14 Account

P63069  
EPM Default Value: \_\_exp414pu\_\_  
Description: Exp4\_1\_14 PickupCode

P63070  
EPM Default Value: \_\_exp415type\_\_  
Description: Exp4\_1\_15 KeyType

P63071  
EPM Default Value: \_\_exp415value\_\_  
Description: Exp4\_1\_15 Value

P63072  
EPM Default Value: \_\_exp415label\_\_  
Description: Exp4\_1\_15 Label

P63073  
EPM Default Value: \_\_exp415acct\_\_  
Description: Exp4\_1\_15 Account

P63074  
EPM Default Value: \_\_exp415pu\_\_  
Description: Exp4\_1\_15 PickupCode

P63075  
EPM Default Value: \_\_exp416type\_\_  
Description: Exp4\_1\_16 KeyType

P63076  
EPM Default Value: \_\_exp416value\_\_  
Description: Exp4\_1\_16 Value

P63077  
EPM Default Value: \_\_exp416label\_\_  
Description: Exp4\_1\_16 Label

P63078  
EPM Default Value: \_\_exp416acct\_\_  
Description: Exp4\_1\_16 Account

P63079  
EPM Default Value: \_\_exp416pu\_\_  
Description: Exp4\_1\_16 PickupCode

P63080  
EPM Default Value: \_\_exp417type\_\_  
Description: Exp4\_1\_17 KeyType

P63081  
EPM Default Value: \_\_exp417value\_\_  
Description: Exp4\_1\_17 Value

P63082  
EPM Default Value: \_\_exp417label\_\_  
Description: Exp4\_1\_17 Label

P63083  
EPM Default Value: \_\_exp417acct\_\_  
Description: Exp4\_1\_17 Account

P63084  
EPM Default Value: \_\_exp417pu\_\_  
Description: Exp4\_1\_17 PickupCode

P63085  
EPM Default Value: \_\_exp418type\_\_  
Description: Exp4\_1\_18 KeyType

P63086  
EPM Default Value: \_\_exp418value\_\_  
Description: Exp4\_1\_18 Value

P63087  
EPM Default Value: \_\_exp418label\_\_  
Description: Exp4\_1\_18 Label

P63088  
EPM Default Value: \_\_exp418acct\_\_  
Description: Exp4\_1\_18 Account

P63089  
EPM Default Value: \_\_exp418pu\_\_  
Description: Exp4\_1\_18 PickupCode

P63090  
EPM Default Value: \_\_exp419type\_\_  
Description: Exp4\_1\_19 KeyType

P63091  
EPM Default Value: \_\_exp419value\_\_  
Description: Exp4\_1\_19 Value

P63092  
EPM Default Value: \_\_exp419label\_\_  
Description: Exp4\_1\_19 Label

P63093  
EPM Default Value: \_\_exp419acct\_\_  
Description: Exp4\_1\_19 Account

P63094  
EPM Default Value: \_\_exp419pu\_\_  
Description: Exp4\_1\_19 PickupCode

P63095  
EPM Default Value: \_\_exp420type\_\_  
Description: Exp4\_1\_20 KeyType

P63096  
EPM Default Value: \_\_exp420value\_\_  
Description: Exp4\_1\_20 Value

P63097  
EPM Default Value: \_\_exp420label\_\_  
Description: Exp4\_1\_20 Label

P63098  
EPM Default Value: \_\_exp420acct\_\_  
Description: Exp4\_1\_20 Account

P63099  
EPM Default Value: \_\_exp420pu\_\_  
Description: Exp4\_1\_20 PickupCode

P63100  
EPM Default Value: \_\_exp421type\_\_  
Description: Exp4\_2\_1 KeyType

P63101  
EPM Default Value: \_\_exp421value\_\_  
Description: Exp4\_2\_1 Value

P63102  
EPM Default Value: \_\_exp421label\_\_  
Description: Exp4\_2\_1 Label

P63103  
EPM Default Value: \_\_exp421acct\_\_  
Description: Exp4\_2\_1 Account

P63104  
EPM Default Value: \_\_exp421pu\_\_  
Description: Exp4\_2\_1 PickupCode

P63105  
EPM Default Value: \_\_exp422type\_\_  
Description: Exp4\_2\_2 KeyType

P63106  
EPM Default Value: \_\_exp422value\_\_  
Description: Exp4\_2\_2 Value

P63107  
EPM Default Value: \_\_exp422label\_\_  
Description: Exp4\_2\_2 Label

P63108  
EPM Default Value: \_\_exp422acct\_\_  
Description: Exp4\_2\_2 Account

P63109  
EPM Default Value: \_\_exp422pu\_\_  
Description: Exp4\_2\_2 PickupCode

P63110  
EPM Default Value: \_\_exp423type\_\_  
Description: Exp4\_2\_3 KeyType

P63111  
EPM Default Value: \_\_exp423value\_\_  
Description: Exp4\_2\_3 Value

P63112  
EPM Default Value: \_\_exp423label\_\_  
Description: Exp4\_2\_3 Label

P63113  
EPM Default Value: \_\_exp423acct\_\_  
Description: Exp4\_2\_3 Account

P63114  
EPM Default Value: \_\_exp423pu\_\_  
Description: Exp4\_2\_3 PickupCode

P63115  
EPM Default Value: \_\_exp424type\_\_  
Description: Exp4\_2\_4 KeyType

P63116  
EPM Default Value: \_\_exp424value\_\_  
Description: Exp4\_2\_4 Value

P63117  
EPM Default Value: \_\_exp424label\_\_  
Description: Exp4\_2\_4 Label

P63118  
EPM Default Value: \_\_exp424acct\_\_  
Description: Exp4\_2\_4 Account

P63119  
EPM Default Value: \_\_exp424pu\_\_  
Description: Exp4\_2\_4 PickupCode

P63120  
EPM Default Value: \_\_exp425type\_\_  
Description: Exp4\_2\_5 KeyType

P63121  
EPM Default Value: \_\_exp425value\_\_  
Description: Exp4\_2\_5 Value

P63122  
EPM Default Value: \_\_exp425label\_\_  
Description: Exp4\_2\_5 Label

P63123  
EPM Default Value: \_\_exp425acct\_\_  
Description: Exp4\_2\_5 Account

P63124  
EPM Default Value: \_\_exp425pu\_\_  
Description: Exp4\_2\_5 PickupCode

P63125  
EPM Default Value: \_\_exp426type\_\_  
Description: Exp4\_2\_6 KeyType



P63126  
EPM Default Value: \_\_exp426value\_\_  
Description: Exp4\_2\_6 Value

P63127  
EPM Default Value: \_\_exp426label\_\_  
Description: Exp4\_2\_6 Label

P63128  
EPM Default Value: \_\_exp426acct\_\_  
Description: Exp4\_2\_6 Account

P63129  
EPM Default Value: \_\_exp426pu\_\_  
Description: Exp4\_2\_6 PickupCode

P63130  
EPM Default Value: \_\_exp427type\_\_  
Description: Exp4\_2\_7 KeyType

P63131  
EPM Default Value: \_\_exp427value\_\_  
Description: Exp4\_2\_7 Value

P63132  
EPM Default Value: \_\_exp427label\_\_  
Description: Exp4\_2\_7 Label

P63133  
EPM Default Value: \_\_exp427acct\_\_  
Description: Exp4\_2\_7 Account

P63134  
EPM Default Value: \_\_exp427pu\_\_  
Description: Exp4\_2\_7 PickupCode

P63135  
EPM Default Value: \_\_exp428type\_\_  
Description: Exp4\_2\_8 KeyType

P63136  
EPM Default Value: \_\_exp428value\_\_  
Description: Exp4\_2\_8 Value

P63137  
EPM Default Value: \_\_exp428label\_\_  
Description: Exp4\_2\_8 Label

P63138  
EPM Default Value: \_\_exp428acct\_\_  
Description: Exp4\_2\_8 Account

P63139  
EPM Default Value: \_\_exp428pu\_\_  
Description: Exp4\_2\_8 PickupCode

P63140  
EPM Default Value: \_\_exp429type\_\_  
Description: Exp4\_2\_9 KeyType

P63141  
EPM Default Value: \_\_exp429value\_\_  
Description: Exp4\_2\_9 Value

P63142  
EPM Default Value: \_\_exp429label\_\_  
Description: Exp4\_2\_9 Label

P63143  
EPM Default Value: \_\_exp429acct\_\_  
Description: Exp4\_2\_9 Account

P63144  
EPM Default Value: \_\_exp429pu\_\_  
Description: Exp4\_2\_9 PickupCode

P63145  
EPM Default Value: \_\_exp430type\_\_  
Description: Exp4\_2\_10 KeyType

P63146  
EPM Default Value: \_\_exp431value\_\_  
Description: Exp4\_2\_10 Value

P63147  
EPM Default Value: \_\_exp431label\_\_  
Description: Exp4\_2\_10 Label

P63148  
EPM Default Value: \_\_exp431acct\_\_  
Description: Exp4\_2\_10 Account

P63149  
EPM Default Value: \_\_exp431pu\_\_  
Description: Exp4\_2\_10 PickupCode

P63150  
EPM Default Value: \_\_exp431type\_\_  
Description: Exp4\_2\_11 KeyType

P63151  
EPM Default Value: \_\_exp431value\_\_  
Description: Exp4\_2\_11 Value

P63152  
EPM Default Value: \_\_exp431label\_\_  
Description: Exp4\_2\_11 Label

P63153  
EPM Default Value: \_\_exp431acct\_\_  
Description: Exp4\_2\_11 Account

P63154  
EPM Default Value: \_\_exp431pu\_\_  
Description: Exp4\_2\_11 PickupCode

P63155  
EPM Default Value: \_\_exp432type\_\_  
Description: Exp4\_2\_12 KeyType

P63156  
EPM Default Value: \_\_exp432value\_\_  
Description: Exp4\_2\_12 Value

P63157  
EPM Default Value: \_\_exp432label\_\_  
Description: Exp4\_2\_12 Label

P63158  
EPM Default Value: \_\_exp432acct\_\_  
Description: Exp4\_2\_12 Account

P63159  
EPM Default Value: \_\_exp432pu\_\_  
Description: Exp4\_2\_12 PickupCode

P63160  
EPM Default Value: \_\_exp433type\_\_  
Description: Exp4\_2\_13 KeyType

P63161  
EPM Default Value: \_\_exp433value\_\_  
Description: Exp4\_2\_13 Value

P63162  
EPM Default Value: \_\_exp433label\_\_  
Description: Exp4\_2\_13 Label

P63163  
EPM Default Value: \_\_exp433acct\_\_  
Description: Exp4\_2\_13 Account

P63164  
EPM Default Value: \_\_exp433pu\_\_  
Description: Exp4\_2\_13 PickupCode

P63165  
EPM Default Value: \_\_exp434type\_\_  
Description: Exp4\_2\_14 KeyType

P63166  
EPM Default Value: \_\_exp434value\_\_  
Description: Exp4\_2\_14 Value

P63167  
EPM Default Value: \_\_exp434label\_\_  
Description: Exp4\_2\_14 Label

P63168  
EPM Default Value: \_\_exp434acct\_\_  
Description: Exp4\_2\_14 Account

P63169  
EPM Default Value: \_\_exp434pu\_\_  
Description: Exp4\_2\_14 PickupCode

P63170  
EPM Default Value: \_\_exp435type\_\_  
Description: Exp4\_2\_15 KeyType

P63171  
EPM Default Value: \_\_exp435value\_\_  
Description: Exp4\_2\_15 Value

P63172  
EPM Default Value: \_\_exp435label\_\_  
Description: Exp4\_2\_15 Label

P63173  
EPM Default Value: \_\_exp435acct\_\_  
Description: Exp4\_2\_15 Account

P63174  
EPM Default Value: \_\_exp435pu\_\_  
Description: Exp4\_2\_15 PickupCode

P63175  
EPM Default Value: \_\_exp436type\_\_  
Description: Exp4\_2\_16 KeyType

P63176  
EPM Default Value: \_\_exp436value\_\_  
Description: Exp4\_2\_16 Value

P63177  
EPM Default Value: \_\_exp436label\_\_  
Description: Exp4\_2\_16 Label

P63178  
EPM Default Value: \_\_exp436acct\_\_  
Description: Exp4\_2\_16 Account

P63179  
EPM Default Value: \_\_exp436pu\_\_  
Description: Exp4\_2\_16 PickupCode

P63180  
EPM Default Value: \_\_exp437type\_\_  
Description: Exp4\_2\_17 KeyType

P63181  
EPM Default Value: \_\_exp437value\_\_  
Description: Exp4\_2\_17 Value

P63182  
EPM Default Value: \_\_exp437label\_\_  
Description: Exp4\_2\_17 Label

P63183  
EPM Default Value: \_\_exp437acct\_\_  
Description: Exp4\_2\_17 Account

P63184  
EPM Default Value: \_\_exp437pu\_\_  
Description: Exp4\_2\_17 PickupCode

P63185  
EPM Default Value: \_\_exp438type\_\_  
Description: Exp4\_2\_18 KeyType

P63186  
EPM Default Value: \_\_exp438value\_\_  
Description: Exp4\_2\_18 Value

P63187  
EPM Default Value: \_\_exp438label\_\_  
Description: Exp4\_2\_18 Label

P63188  
EPM Default Value: \_\_exp438acct\_\_  
Description: Exp4\_2\_18 Account

P63189  
EPM Default Value: \_\_exp438pu\_\_  
Description: Exp4\_2\_18 PickupCode

P63190  
EPM Default Value: \_\_exp439type\_\_  
Description: Exp4\_2\_19 KeyType

P63191  
EPM Default Value: \_\_exp439value\_\_  
Description: Exp4\_2\_19 Value

P63192  
EPM Default Value: \_\_exp439label\_\_  
Description: Exp4\_2\_19 Label

P63193  
EPM Default Value: \_\_exp439acct\_\_  
Description: Exp4\_2\_19 Account

P63194  
EPM Default Value: \_\_exp439pu\_\_  
Description: Exp4\_2\_19 PickupCode

P63195  
EPM Default Value: \_\_exp440type\_\_  
Description: Exp4\_2\_20 KeyType

P63196  
EPM Default Value: \_\_exp440value\_\_  
Description: Exp4\_2\_20 Value

P63197  
EPM Default Value: \_\_exp440label\_\_  
Description: Exp4\_2\_20 Label

P63198  
EPM Default Value: \_\_exp440acct\_\_  
Description: Exp4\_2\_20 Account

P63199  
EPM Default Value: \_\_exp440pu\_\_  
Description: Exp4\_2\_20 PickupCode

P64000  
EPM Default Value: \_\_exp51type\_\_  
Description: Exp5\_1\_1 KeyType

P64001  
EPM Default Value: \_\_exp51value\_\_  
Description: Exp5\_1\_1 Value

P64002  
EPM Default Value: \_\_exp51label\_\_  
Description: Exp5\_1\_1 Label

P64003  
EPM Default Value: \_\_exp51acct\_\_  
Description: Exp5\_1\_1 Account

P64004  
EPM Default Value: \_\_exp51pu\_\_  
Description: Exp5\_1\_1 PickupCode

P64005  
EPM Default Value: \_\_exp52type\_\_  
Description: Exp5\_1\_2 KeyType

P64006  
EPM Default Value: \_\_exp52value\_\_  
Description: Exp5\_1\_2 Value

P64007  
EPM Default Value: \_\_exp52label\_\_  
Description: Exp5\_1\_2 Label

P64008  
EPM Default Value: \_\_exp52acct\_\_  
Description: Exp5\_1\_2 Account

P64009  
EPM Default Value: \_\_exp52pu\_\_  
Description: Exp5\_1\_2 PickupCode

P64010  
EPM Default Value: \_\_exp53type\_\_  
Description: Exp5\_1\_3 KeyType

P64011  
EPM Default Value: \_\_exp53value\_\_  
Description: Exp5\_1\_3 Value

P64012  
EPM Default Value: \_\_exp53label\_\_  
Description: Exp5\_1\_3 Label

P64013  
EPM Default Value: \_\_exp53acct\_\_  
Description: Exp5\_1\_3 Account

P64014  
EPM Default Value: \_\_exp53pu\_\_  
Description: Exp5\_1\_3 PickupCode

P64015  
EPM Default Value: \_\_exp54type\_\_  
Description: Exp5\_1\_4 KeyType

P64016  
EPM Default Value: \_\_exp54value\_\_  
Description: Exp5\_1\_4 Value

P64017  
EPM Default Value: \_\_exp54label\_\_  
Description: Exp5\_1\_4 Label

P64018  
EPM Default Value: \_\_exp54acct\_\_  
Description: Exp5\_1\_4 Account

P64019  
EPM Default Value: \_\_exp54pu\_\_  
Description: Exp5\_1\_4 PickupCode

P64020  
EPM Default Value: \_\_exp55type\_\_  
Description: Exp5\_1\_5 KeyType

P64021  
EPM Default Value: \_\_exp55value\_\_  
Description: Exp5\_1\_5 Value

P64022  
EPM Default Value: \_\_exp55label\_\_  
Description: Exp5\_1\_5 Label

P64023  
EPM Default Value: \_\_exp55acct\_\_  
Description: Exp5\_1\_5 Account

P64024  
EPM Default Value: \_\_exp55pu\_\_  
Description: Exp5\_1\_5 PickupCode

P64025  
EPM Default Value: \_\_exp56type\_\_  
Description: Exp5\_1\_6 KeyType

P64026  
EPM Default Value: \_\_exp56value\_\_  
Description: Exp5\_1\_6 Value

P64027  
EPM Default Value: \_\_exp56label\_\_  
Description: Exp5\_1\_6 Label

P64028  
EPM Default Value: \_\_exp56acct\_\_  
Description: Exp5\_1\_6 Account

P64029  
EPM Default Value: \_\_exp56pu\_\_  
Description: Exp5\_1\_6 PickupCode

P64030  
EPM Default Value: \_\_exp57type\_\_  
Description: Exp5\_1\_7 KeyType

P64031  
EPM Default Value: \_\_exp57value\_\_  
Description: Exp5\_1\_7 Value

P64032  
EPM Default Value: \_\_exp57label\_\_  
Description: Exp5\_1\_7 Label

P64033  
EPM Default Value: \_\_exp57acct\_\_  
Description: Exp5\_1\_7 Account

P64034  
EPM Default Value: \_\_exp57pu\_\_  
Description: Exp5\_1\_7 PickupCode

P64035  
EPM Default Value: \_\_exp58type\_\_  
Description: Exp5\_1\_8 KeyType

P64036  
EPM Default Value: \_\_exp58value\_\_  
Description: Exp5\_1\_8 Value

P64037  
EPM Default Value: \_\_exp58label\_\_  
Description: Exp5\_1\_8 Label

P64038  
EPM Default Value: \_\_exp58acct\_\_  
Description: Exp5\_1\_8 Account

P64039  
EPM Default Value: \_\_exp58pu\_\_  
Description: Exp5\_1\_8 PickupCode

P64040  
EPM Default Value: \_\_exp59type\_\_  
Description: Exp5\_1\_9 KeyType

P64041  
EPM Default Value: \_\_exp59value\_\_  
Description: Exp5\_1\_9 Value

P64042  
EPM Default Value: \_\_exp59label\_\_  
Description: Exp5\_1\_9 Label

P64043  
EPM Default Value: \_\_exp59acct\_\_  
Description: Exp5\_1\_9 Account

P64044  
EPM Default Value: \_\_exp59pu\_\_  
Description: Exp5\_1\_9 PickupCode

P64045  
EPM Default Value: \_\_exp510type\_\_  
Description: Exp5\_1\_10 KeyType

P64046  
EPM Default Value: \_\_exp510value\_\_  
Description: Exp5\_1\_10 Value

P64047  
EPM Default Value: \_\_exp510label\_\_  
Description: Exp5\_1\_10 Label

P64048  
EPM Default Value: \_\_exp510acct\_\_  
Description: Exp5\_1\_10 Account

P64049  
EPM Default Value: \_\_exp510pu\_\_  
Description: Exp5\_1\_10 PickupCode

P64050  
EPM Default Value: \_\_exp511type\_\_  
Description: Exp5\_1\_11 KeyType

P64051  
EPM Default Value: \_\_exp511value\_\_  
Description: Exp5\_1\_11 Value

P64052  
EPM Default Value: \_\_exp511label\_\_  
Description: Exp5\_1\_11 Label

P64053  
EPM Default Value: \_\_exp511acct\_\_  
Description: Exp5\_1\_11 Account

P64054  
EPM Default Value: \_\_exp511pu\_\_  
Description: Exp5\_1\_11 PickupCode

P64055  
EPM Default Value: \_\_exp512type\_\_  
Description: Exp5\_1\_12 KeyType

P64056  
EPM Default Value: \_\_exp512value\_\_  
Description: Exp5\_1\_12 Value

P64057  
EPM Default Value: \_\_exp512label\_\_  
Description: Exp5\_1\_12 Label

P64058  
EPM Default Value: \_\_exp512acct\_\_  
Description: Exp5\_1\_12 Account

P64059  
EPM Default Value: \_\_exp512pu\_\_  
Description: Exp5\_1\_12 PickupCode

P64060  
EPM Default Value: \_\_exp513type\_\_  
Description: Exp5\_1\_13 KeyType

P64061  
EPM Default Value: \_\_exp513value\_\_  
Description: Exp5\_1\_13 Value

P64062  
EPM Default Value: \_\_exp513label\_\_  
Description: Exp5\_1\_13 Label

P64063  
EPM Default Value: \_\_exp513acct\_\_  
Description: Exp5\_1\_13 Account

P64064  
EPM Default Value: \_\_exp513pu\_\_  
Description: Exp5\_1\_13 PickupCode

P64065  
EPM Default Value: \_\_exp514type\_\_  
Description: Exp5\_1\_14 KeyType

P64066  
EPM Default Value: \_\_exp514value\_\_  
Description: Exp5\_1\_14 Value

P64067  
EPM Default Value: \_\_exp514label\_\_  
Description: Exp5\_1\_14 Label

P64068  
EPM Default Value: \_\_exp514acct\_\_  
Description: Exp5\_1\_14 Account

P64069  
EPM Default Value: \_\_exp514pu\_\_  
Description: Exp5\_1\_14 PickupCode



P64070  
EPM Default Value: \_\_exp515type\_\_  
Description: Exp5\_1\_15 KeyType

P64071  
EPM Default Value: \_\_exp515value\_\_  
Description: Exp5\_1\_15 Value

P64072  
EPM Default Value: \_\_exp515label\_\_  
Description: Exp5\_1\_15 Label

P64073  
EPM Default Value: \_\_exp515acct\_\_  
Description: Exp5\_1\_15 Account

P64074  
EPM Default Value: \_\_exp515pu\_\_  
Description: Exp5\_1\_15 PickupCode

P64075  
EPM Default Value: \_\_exp516type\_\_  
Description: Exp5\_1\_16 KeyType

P64076  
EPM Default Value: \_\_exp516value\_\_  
Description: Exp5\_1\_16 Value

P64077  
EPM Default Value: \_\_exp516label\_\_  
Description: Exp5\_1\_16 Label

P64078  
EPM Default Value: \_\_exp516acct\_\_  
Description: Exp5\_1\_16 Account

P64079  
EPM Default Value: \_\_exp516pu\_\_  
Description: Exp5\_1\_16 PickupCode

P64080  
EPM Default Value: \_\_exp517type\_\_  
Description: Exp5\_1\_17 KeyType

P64081  
EPM Default Value: \_\_exp517value\_\_  
Description: Exp5\_1\_17 Value

P64082  
EPM Default Value: \_\_exp517label\_\_  
Description: Exp5\_1\_17 Label

P64083  
EPM Default Value: \_\_exp517acct\_\_  
Description: Exp5\_1\_17 Account

P64084  
EPM Default Value: \_\_exp517pu\_\_  
Description: Exp5\_1\_17 PickupCode

P64085  
EPM Default Value: \_\_exp518type\_\_  
Description: Exp5\_1\_18 KeyType

P64086  
EPM Default Value: \_\_exp518value\_\_  
Description: Exp5\_1\_18 Value

P64087  
EPM Default Value: \_\_exp518label\_\_  
Description: Exp5\_1\_18 Label

P64088  
EPM Default Value: \_\_exp518acct\_\_  
Description: Exp5\_1\_18 Account

P64089  
EPM Default Value: \_\_exp518pu\_\_  
Description: Exp5\_1\_18 PickupCode

P64090  
EPM Default Value: \_\_exp519type\_\_  
Description: Exp5\_1\_19 KeyType

P64091  
EPM Default Value: \_\_exp519value\_\_  
Description: Exp5\_1\_19 Value

P64092  
EPM Default Value: \_\_exp519label\_\_  
Description: Exp5\_1\_19 Label

P64093  
EPM Default Value: \_\_exp519acct\_\_  
Description: Exp5\_1\_19 Account

P64094  
EPM Default Value: \_\_exp519pu\_\_  
Description: Exp5\_1\_19 PickupCode

P64095  
EPM Default Value: \_\_exp520type\_\_  
Description: Exp5\_1\_20 KeyType

P64096  
EPM Default Value: \_\_exp520value\_\_  
Description: Exp5\_1\_20 Value

P64097  
EPM Default Value: \_\_exp520label\_\_  
Description: Exp5\_1\_20 Label

P64098  
EPM Default Value: \_\_exp520acct\_\_  
Description: Exp5\_1\_20 Account

P64099  
EPM Default Value: \_\_exp520pu\_\_  
Description: Exp5\_1\_20 PickupCode

P64100  
EPM Default Value: \_\_exp521type\_\_  
Description: Exp5\_2\_1 KeyType

P64101  
EPM Default Value: \_\_exp521value\_\_  
Description: Exp5\_2\_1 Value

P64102  
EPM Default Value: \_\_exp521label\_\_  
Description: Exp5\_2\_1 Label

P64103  
EPM Default Value: \_\_exp521acct\_\_  
Description: Exp5\_2\_1 Account

P64104  
EPM Default Value: \_\_exp521pu\_\_  
Description: Exp5\_2\_1 PickupCode

P64105  
EPM Default Value: \_\_exp522type\_\_  
Description: Exp5\_2\_2 KeyType

P64106  
EPM Default Value: \_\_exp522value\_\_  
Description: Exp5\_2\_2 Value

P64107  
EPM Default Value: \_\_exp522label\_\_  
Description: Exp5\_2\_2 Label

P64108  
EPM Default Value: \_\_exp522acct\_\_  
Description: Exp5\_2\_2 Account

P64109  
EPM Default Value: \_\_exp522pu\_\_  
Description: Exp5\_2\_2 PickupCode

P64110  
EPM Default Value: \_\_exp523type\_\_  
Description: Exp5\_2\_3 KeyType

P64111  
EPM Default Value: \_\_exp523value\_\_  
Description: Exp5\_2\_3 Value

P64112  
EPM Default Value: \_\_exp523label\_\_  
Description: Exp5\_2\_3 Label

P64113  
EPM Default Value: \_\_exp523acct\_\_  
Description: Exp5\_2\_3 Account

P64114  
EPM Default Value: \_\_exp523pu\_\_  
Description: Exp5\_2\_3 PickupCode

P64115  
EPM Default Value: \_\_exp524type\_\_  
Description: Exp5\_2\_4 KeyType

P64116  
EPM Default Value: \_\_exp524value\_\_  
Description: Exp5\_2\_4 Value

P64117  
EPM Default Value: \_\_exp524label\_\_  
Description: Exp5\_2\_4 Label

P64118  
EPM Default Value: \_\_exp524acct\_\_  
Description: Exp5\_2\_4 Account

P64119  
EPM Default Value: \_\_exp524pu\_\_  
Description: Exp5\_2\_4 PickupCode

P64120  
EPM Default Value: \_\_exp525type\_\_  
Description: Exp5\_2\_5 KeyType

P64121  
EPM Default Value: \_\_exp525value\_\_  
Description: Exp5\_2\_5 Value

P64122  
EPM Default Value: \_\_exp525label\_\_  
Description: Exp5\_2\_5 Label

P64123  
EPM Default Value: \_\_exp525acct\_\_  
Description: Exp5\_2\_5 Account

P64124  
EPM Default Value: \_\_exp525pu\_\_  
Description: Exp5\_2\_5 PickupCode

P64125  
EPM Default Value: \_\_exp526type\_\_  
Description: Exp5\_2\_6 KeyType

P64126  
EPM Default Value: \_\_exp526value\_\_  
Description: Exp5\_2\_6 Value

P64127  
EPM Default Value: \_\_exp526label\_\_  
Description: Exp5\_2\_6 Label

P64128  
EPM Default Value: \_\_exp526acct\_\_  
Description: Exp5\_2\_6 Account

P64129  
EPM Default Value: \_\_exp526pu\_\_  
Description: Exp5\_2\_6 PickupCode

P64130  
EPM Default Value: \_\_exp527type\_\_  
Description: Exp5\_2\_7 KeyType

P64131  
EPM Default Value: \_\_exp527value\_\_  
Description: Exp5\_2\_7 Value

P64132  
EPM Default Value: \_\_exp527label\_\_  
Description: Exp5\_2\_7 Label

P64133  
EPM Default Value: \_\_exp527acct\_\_  
Description: Exp5\_2\_7 Account

P64134  
EPM Default Value: \_\_exp527pu\_\_  
Description: Exp5\_2\_7 PickupCode

P64135  
EPM Default Value: \_\_exp528type\_\_  
Description: Exp5\_2\_8 KeyType

P64136  
EPM Default Value: \_\_exp528value\_\_  
Description: Exp5\_2\_8 Value

P64137  
EPM Default Value: \_\_exp528label\_\_  
Description: Exp5\_2\_8 Label

P64138  
EPM Default Value: \_\_exp528acct\_\_  
Description: Exp5\_2\_8 Account

P64139  
EPM Default Value: \_\_exp528pu\_\_  
Description: Exp5\_2\_8 PickupCode

P64140  
EPM Default Value: \_\_exp529type\_\_  
Description: Exp5\_2\_9 KeyType

P64141  
EPM Default Value: \_\_exp529value\_\_  
Description: Exp5\_2\_9 Value

P64142  
EPM Default Value: \_\_exp529label\_\_  
Description: Exp5\_2\_9 Label

P64143  
EPM Default Value: \_\_exp529acct\_\_  
Description: Exp5\_2\_9 Account

P64144  
EPM Default Value: \_\_exp529pu\_\_  
Description: Exp5\_2\_9 PickupCode

P64145  
EPM Default Value: \_\_exp530type\_\_  
Description: Exp5\_2\_10 KeyType

P64146  
EPM Default Value: \_\_exp530value\_\_  
Description: Exp5\_2\_10 Value

P64147  
EPM Default Value: \_\_exp530label\_\_  
Description: Exp5\_2\_10 Label

P64148  
EPM Default Value: \_\_exp530acct\_\_  
Description: Exp5\_2\_10 Account

P64149  
EPM Default Value: \_\_exp530pu\_\_  
Description: Exp5\_2\_10 PickupCode

P64150  
EPM Default Value: \_\_exp531type\_\_  
Description: Exp5\_2\_11 KeyType

P64151  
EPM Default Value: \_\_exp531value\_\_  
Description: Exp5\_2\_11 Value

P64152  
EPM Default Value: \_\_exp531label\_\_  
Description: Exp5\_2\_11 Label

P64153  
EPM Default Value: \_\_exp531acct\_\_  
Description: Exp5\_2\_11 Account

P64154  
EPM Default Value: \_\_exp531pu\_\_  
Description: Exp5\_2\_11 PickupCode

P64155  
EPM Default Value: \_\_exp532type\_\_  
Description: Exp5\_2\_12 KeyType

P64156  
EPM Default Value: \_\_exp532value\_\_  
Description: Exp5\_2\_12 Value

P64157  
EPM Default Value: \_\_exp532label\_\_  
Description: Exp5\_2\_12 Label

P64158  
EPM Default Value: \_\_exp532acct\_\_  
Description: Exp5\_2\_12 Account

P64159  
EPM Default Value: \_\_exp532pu\_\_  
Description: Exp5\_2\_12 PickupCode

P64160  
EPM Default Value: \_\_exp533type\_\_  
Description: Exp5\_2\_13 KeyType

P64161  
EPM Default Value: \_\_exp533value\_\_  
Description: Exp5\_2\_13 Value

P64162  
EPM Default Value: \_\_exp533label\_\_  
Description: Exp5\_2\_13 Label

P64163  
EPM Default Value: \_\_exp533acct\_\_  
Description: Exp5\_2\_13 Account

P64164  
EPM Default Value: \_\_exp533pu\_\_  
Description: Exp5\_2\_13 PickupCode

P64165  
EPM Default Value: \_\_exp534type\_\_  
Description: Exp5\_2\_14 KeyType

P64166  
EPM Default Value: \_\_exp534value\_\_  
Description: Exp5\_2\_14 Value

P64167  
EPM Default Value: \_\_exp534label\_\_  
Description: Exp5\_2\_14 Label

P64168  
EPM Default Value: \_\_exp534acct\_\_  
Description: Exp5\_2\_14 Account

P64169  
EPM Default Value: \_\_exp534pu\_\_  
Description: Exp5\_2\_14 PickupCode

P64170  
EPM Default Value: \_\_exp535type\_\_  
Description: Exp5\_2\_15 KeyType

P64171  
EPM Default Value: \_\_exp535value\_\_  
Description: Exp5\_2\_15 Value

P64172  
EPM Default Value: \_\_exp535label\_\_  
Description: Exp5\_2\_15 Label

P64173  
EPM Default Value: \_\_exp535acct\_\_  
Description: Exp5\_2\_15 Account

P64174  
EPM Default Value: \_\_exp535pu\_\_  
Description: Exp5\_2\_15 PickupCode

P64175  
EPM Default Value: \_\_exp536type\_\_  
Description: Exp5\_2\_16 KeyType

P64176  
EPM Default Value: \_\_exp536value\_\_  
Description: Exp5\_2\_16 Value

P64177  
EPM Default Value: \_\_exp536label\_\_  
Description: Exp5\_2\_16 Label

P64178  
EPM Default Value: \_\_exp536acct\_\_  
Description: Exp5\_2\_16 Account

P64179  
EPM Default Value: \_\_exp536pu\_\_  
Description: Exp5\_2\_16 PickupCode

P64180  
EPM Default Value: \_\_exp537type\_\_  
Description: Exp5\_2\_17 KeyType

P64181  
EPM Default Value: \_\_exp537value\_\_  
Description: Exp5\_2\_17 Value

P64182  
EPM Default Value: \_\_exp537label\_\_  
Description: Exp5\_2\_17 Label

P64183  
EPM Default Value: \_\_exp537acct\_\_  
Description: Exp5\_2\_17 Account

P64184  
EPM Default Value: \_\_exp537pu\_\_  
Description: Exp5\_2\_17 PickupCode

P64185  
EPM Default Value: \_\_exp538type\_\_  
Description: Exp5\_2\_18 KeyType

P64186  
EPM Default Value: \_\_exp538value\_\_  
Description: Exp5\_2\_18 Value

P64187  
EPM Default Value: \_\_exp538label\_\_  
Description: Exp5\_2\_18 Label

P64188  
EPM Default Value: \_\_exp538acct\_\_  
Description: Exp5\_2\_18 Account

P64189  
EPM Default Value: \_\_exp538pu\_\_  
Description: Exp5\_2\_18 PickupCode

P64190  
EPM Default Value: \_\_exp539type\_\_  
Description: Exp5\_2\_19 KeyType

P64191  
EPM Default Value: \_\_exp539value\_\_  
Description: Exp5\_2\_19 Value

P64192  
EPM Default Value: \_\_exp539label\_\_  
Description: Exp5\_2\_19 Label

P64193  
EPM Default Value: \_\_exp539acct\_\_  
Description: Exp5\_2\_19 Account

P64194  
EPM Default Value: \_\_exp539pu\_\_  
Description: Exp5\_2\_19 PickupCode

P64195  
EPM Default Value: \_\_exp540type\_\_  
Description: Exp5\_2\_20 KeyType

P64196  
EPM Default Value: \_\_exp540value\_\_  
Description: Exp5\_2\_20 Value

P64197  
EPM Default Value: \_\_exp540label\_\_  
Description: Exp5\_2\_20 Label

P64198  
EPM Default Value: \_\_exp540acct\_\_  
Description: Exp5\_2\_20 Account

P64199  
EPM Default Value: \_\_exp540pu\_\_  
Description: Exp5\_2\_20 PickupCode

P65000  
EPM Default Value: \_\_exp61type\_\_  
Description: Exp6\_1\_1 KeyType

P65001  
EPM Default Value: \_\_exp61value\_\_  
Description: Exp6\_1\_1 Value

P65002  
EPM Default Value: \_\_exp61label\_\_  
Description: Exp6\_1\_1 Label

P65003  
EPM Default Value: \_\_exp61acct\_\_  
Description: Exp6\_1\_1 Account

P65004  
EPM Default Value: \_\_exp61pu\_\_  
Description: Exp6\_1\_1 PickupCode

P65005  
EPM Default Value: \_\_exp62type\_\_  
Description: Exp6\_1\_2 KeyType

P65006  
EPM Default Value: \_\_exp62value\_\_  
Description: Exp6\_1\_2 Value

P65007  
EPM Default Value: \_\_exp62label\_\_  
Description: Exp6\_1\_2 Label

P65008  
EPM Default Value: \_\_exp62acct\_\_  
Description: Exp6\_1\_2 Account

P65009  
EPM Default Value: \_\_exp62pu\_\_  
Description: Exp6\_1\_2 PickupCode

P65010  
EPM Default Value: \_\_exp63type\_\_  
Description: Exp6\_1\_3 KeyType

P65011  
EPM Default Value: \_\_exp63value\_\_  
Description: Exp6\_1\_3 Value

P65012  
EPM Default Value: \_\_exp63label\_\_  
Description: Exp6\_1\_3 Label

P65013  
EPM Default Value: \_\_exp63acct\_\_  
Description: Exp6\_1\_3 Account



P65014  
EPM Default Value: \_\_exp63pu\_\_  
Description: Exp6\_1\_3 PickupCode

P65015  
EPM Default Value: \_\_exp64type\_\_  
Description: Exp6\_1\_4 KeyType

P65016  
EPM Default Value: \_\_exp64value\_\_  
Description: Exp6\_1\_4 Value

P65017  
EPM Default Value: \_\_exp64label\_\_  
Description: Exp6\_1\_4 Label

P65018  
EPM Default Value: \_\_exp64acct\_\_  
Description: Exp6\_1\_4 Account

P65019  
EPM Default Value: \_\_exp64pu\_\_  
Description: Exp6\_1\_4 PickupCode

P65020  
EPM Default Value: \_\_exp65type\_\_  
Description: Exp6\_1\_5 KeyType

P65021  
EPM Default Value: \_\_exp65value\_\_  
Description: Exp6\_1\_5 Value

P65022  
EPM Default Value: \_\_exp65label\_\_  
Description: Exp6\_1\_5 Label

P65023  
EPM Default Value: \_\_exp65acct\_\_  
Description: Exp6\_1\_5 Account

P65024  
EPM Default Value: \_\_exp65pu\_\_  
Description: Exp6\_1\_5 PickupCode

P65025  
EPM Default Value: \_\_exp66type\_\_  
Description: Exp6\_1\_6 KeyType

P65026  
EPM Default Value: \_\_exp66value\_\_  
Description: Exp6\_1\_6 Value

P65027  
EPM Default Value: \_\_exp66label\_\_  
Description: Exp6\_1\_6 Label

P65028  
EPM Default Value: \_\_exp66acct\_\_  
Description: Exp6\_1\_6 Account

P65029  
EPM Default Value: \_\_exp66pu\_\_  
Description: Exp6\_1\_6 PickupCode

P65030  
EPM Default Value: \_\_exp67type\_\_  
Description: Exp6\_1\_7 KeyType

P65031  
EPM Default Value: \_\_exp67value\_\_  
Description: Exp6\_1\_7 Value

P65032  
EPM Default Value: \_\_exp67label\_\_  
Description: Exp6\_1\_7 Label

P65033  
EPM Default Value: \_\_exp67acct\_\_  
Description: Exp6\_1\_7 Account

P65034  
EPM Default Value: \_\_exp67pu\_\_  
Description: Exp6\_1\_7 PickupCode

P65035  
EPM Default Value: \_\_exp67type\_\_  
Description: Exp6\_1\_8 KeyType

P65036  
EPM Default Value: \_\_exp68value\_\_  
Description: Exp6\_1\_8 Value

P65037  
EPM Default Value: \_\_exp68label\_\_  
Description: Exp6\_1\_8 Label

P65038  
EPM Default Value: \_\_exp68acct\_\_  
Description: Exp6\_1\_8 Account

P65039  
EPM Default Value: \_\_exp68pu\_\_  
Description: Exp6\_1\_8 PickupCode

P65040  
EPM Default Value: \_\_exp69type\_\_  
Description: Exp6\_1\_9 KeyType

P65041  
EPM Default Value: \_\_exp69value\_\_  
Description: Exp6\_1\_9 Value

P65042  
EPM Default Value: \_\_exp69label\_\_  
Description: Exp6\_1\_9 Label

P65043  
EPM Default Value: \_\_exp69acct\_\_  
Description: Exp6\_1\_9 Account

P65044  
EPM Default Value: \_\_exp69pu\_\_  
Description: Exp6\_1\_9 PickupCode

P65045  
EPM Default Value: \_\_exp610type\_\_  
Description: Exp6\_1\_10 KeyType

P65046  
EPM Default Value: \_\_exp610value\_\_  
Description: Exp6\_1\_10 Value

P65047  
EPM Default Value: \_\_exp610label\_\_  
Description: Exp6\_1\_10 Label

P65048  
EPM Default Value: \_\_exp610acct\_\_  
Description: Exp6\_1\_10 Account

P65049  
EPM Default Value: \_\_exp610pu\_\_  
Description: Exp6\_1\_10 PickupCode

P65050  
EPM Default Value: \_\_exp611type\_\_  
Description: Exp6\_1\_11 KeyType

P65051  
EPM Default Value: \_\_exp611value\_\_  
Description: Exp6\_1\_11 Value

P65052  
EPM Default Value: \_\_exp611label\_\_  
Description: Exp6\_1\_11 Label

P65053  
EPM Default Value: \_\_exp611acct\_\_  
Description: Exp6\_1\_11 Account

P65054  
EPM Default Value: \_\_exp611pu\_\_  
Description: Exp6\_1\_11 PickupCode

P65055  
EPM Default Value: \_\_exp612type\_\_  
Description: Exp6\_1\_12 KeyType

P65056  
EPM Default Value: \_\_exp612value\_\_  
Description: Exp6\_1\_12 Value

P65057  
EPM Default Value: \_\_exp612label\_\_  
Description: Exp6\_1\_12 Label

P65058  
EPM Default Value: \_\_exp612acct\_\_  
Description: Exp6\_1\_12 Account

P65059  
EPM Default Value: \_\_exp612pu\_\_  
Description: Exp6\_1\_12 PickupCode

P65060  
EPM Default Value: \_\_exp613type\_\_  
Description: Exp6\_1\_13 KeyType

P65061  
EPM Default Value: \_\_exp613value\_\_  
Description: Exp6\_1\_13 Value

P65062  
EPM Default Value: \_\_exp613label\_\_  
Description: Exp6\_1\_13 Label

P65063  
EPM Default Value: \_\_exp613acct\_\_  
Description: Exp6\_1\_13 Account

P65064  
EPM Default Value: \_\_exp613pu\_\_  
Description: Exp6\_1\_13 PickupCode

P65065  
EPM Default Value: \_\_exp614type\_\_  
Description: Exp6\_1\_14 KeyType

P65066  
EPM Default Value: \_\_exp614value\_\_  
Description: Exp6\_1\_14 Value

P65067  
EPM Default Value: \_\_exp614label\_\_  
Description: Exp6\_1\_14 Label

P65068  
EPM Default Value: \_\_exp614acct\_\_  
Description: Exp6\_1\_14 Account

P65069  
EPM Default Value: \_\_exp614pu\_\_  
Description: Exp6\_1\_14 PickupCode

P65070  
EPM Default Value: \_\_exp615type\_\_  
Description: Exp6\_1\_15 KeyType

P65071  
EPM Default Value: \_\_exp615value\_\_  
Description: Exp6\_1\_15 Value

P65072  
EPM Default Value: \_\_exp615label\_\_  
Description: Exp6\_1\_15 Label

P65073  
EPM Default Value: \_\_exp615acct\_\_  
Description: Exp6\_1\_15 Account

P65074  
EPM Default Value: \_\_exp615pu\_\_  
Description: Exp6\_1\_15 PickupCode

P65075  
EPM Default Value: \_\_exp616type\_\_  
Description: Exp6\_1\_16 KeyType

P65076  
EPM Default Value: \_\_exp616value\_\_  
Description: Exp6\_1\_16 Value

P65077  
EPM Default Value: \_\_exp616label\_\_  
Description: Exp6\_1\_16 Label

P65078  
EPM Default Value: \_\_exp616acct\_\_  
Description: Exp6\_1\_16 Account

P65079  
EPM Default Value: \_\_exp616pu\_\_  
Description: Exp6\_1\_16 PickupCode

P65080  
EPM Default Value: \_\_exp617type\_\_  
Description: Exp6\_1\_17 KeyType

P65081  
EPM Default Value: \_\_exp617value\_\_  
Description: Exp6\_1\_17 Value

P65082  
EPM Default Value: \_\_exp617label\_\_  
Description: Exp6\_1\_17 Label

P65083  
EPM Default Value: \_\_exp617acct\_\_  
Description: Exp6\_1\_17 Account

P65084  
EPM Default Value: \_\_exp617pu\_\_  
Description: Exp6\_1\_17 PickupCode

P65085  
EPM Default Value: \_\_exp618type\_\_  
Description: Exp6\_1\_18 KeyType

P65086  
EPM Default Value: \_\_exp618value\_\_  
Description: Exp6\_1\_18 Value

P65087  
EPM Default Value: \_\_exp618label\_\_  
Description: Exp6\_1\_18 Label

P65088  
EPM Default Value: \_\_exp618acct\_\_  
Description: Exp6\_1\_18 Account

P65089  
EPM Default Value: \_\_exp618pu\_\_  
Description: Exp6\_1\_18 PickupCode

P65090  
EPM Default Value: \_\_exp619type\_\_  
Description: Exp6\_1\_19 KeyType

P65091  
EPM Default Value: \_\_exp619value\_\_  
Description: Exp6\_1\_19 Value

P65092  
EPM Default Value: \_\_exp619label\_\_  
Description: Exp6\_1\_19 Label

P65093  
EPM Default Value: \_\_exp619acct\_\_  
Description: Exp6\_1\_19 Account

P65094  
EPM Default Value: \_\_exp619pu\_\_  
Description: Exp6\_1\_19 PickupCode

P65095  
EPM Default Value: \_\_exp620type\_\_  
Description: Exp6\_1\_20 KeyType

P65096  
EPM Default Value: \_\_exp620value\_\_  
Description: Exp6\_1\_20 Value

P65097  
EPM Default Value: \_\_exp620label\_\_  
Description: Exp6\_1\_20 Label

P65098  
EPM Default Value: \_\_exp620acct\_\_  
Description: Exp6\_1\_20 Account

P65099  
EPM Default Value: \_\_exp620pu\_\_  
Description: Exp6\_1\_20 PickupCode

P65100  
EPM Default Value: \_\_exp621type\_\_  
Description: Exp6\_2\_1 KeyType

P65101  
EPM Default Value: \_\_exp621value\_\_  
Description: Exp6\_2\_1 Value

P65102  
EPM Default Value: \_\_exp621label\_\_  
Description: Exp6\_2\_1 Label

P65103  
EPM Default Value: \_\_exp621acct\_\_  
Description: Exp6\_2\_1 Account

P65104  
EPM Default Value: \_\_exp621pu\_\_  
Description: Exp6\_2\_1 PickupCode

P65105  
EPM Default Value: \_\_exp622type\_\_  
Description: Exp6\_2\_2 KeyType

P65106  
EPM Default Value: \_\_exp622value\_\_  
Description: Exp6\_2\_2 Value

P65107  
EPM Default Value: \_\_exp622label\_\_  
Description: Exp6\_2\_2 Label

P65108  
EPM Default Value: \_\_exp622acct\_\_  
Description: Exp6\_2\_2 Account

P65109  
EPM Default Value: \_\_exp622pu\_\_  
Description: Exp6\_2\_2 PickupCode

P65110  
EPM Default Value: \_\_exp623type\_\_  
Description: Exp6\_2\_3 KeyType

P65111  
EPM Default Value: \_\_exp623value\_\_  
Description: Exp6\_2\_3 Value

P65112  
EPM Default Value: \_\_exp623label\_\_  
Description: Exp6\_2\_3 Label

P65113  
EPM Default Value: \_\_exp623acct\_\_  
Description: Exp6\_2\_3 Account

P65114  
EPM Default Value: \_\_exp623pu\_\_  
Description: Exp6\_2\_3 PickupCode

P65115  
EPM Default Value: \_\_exp624type\_\_  
Description: Exp6\_2\_4 KeyType

P65116  
EPM Default Value: \_\_exp624value\_\_  
Description: Exp6\_2\_4 Value

P65117  
EPM Default Value: \_\_exp624label\_\_  
Description: Exp6\_2\_4 Label

P65118  
EPM Default Value: \_\_exp624acct\_\_  
Description: Exp6\_2\_4 Account

P65119  
EPM Default Value: \_\_exp624pu\_\_  
Description: Exp6\_2\_4 PickupCode

P65120  
EPM Default Value: \_\_exp625type\_\_  
Description: Exp6\_2\_5 KeyType

P65121  
EPM Default Value: \_\_exp625value\_\_  
Description: Exp6\_2\_5 Value

P65122  
EPM Default Value: \_\_exp625label\_\_  
Description: Exp6\_2\_5 Label

P65123  
EPM Default Value: \_\_exp625acct\_\_  
Description: Exp6\_2\_5 Account

P65124  
EPM Default Value: \_\_exp625pu\_\_  
Description: Exp6\_2\_5 PickupCode

P65125  
EPM Default Value: \_\_exp626type\_\_  
Description: Exp6\_2\_6 KeyType

P65126  
EPM Default Value: \_\_exp626value\_\_  
Description: Exp6\_2\_6 Value

P65127  
EPM Default Value: \_\_exp626label\_\_  
Description: Exp6\_2\_6 Label

P65128  
EPM Default Value: \_\_exp626acct\_\_  
Description: Exp6\_2\_6 Account

P65129  
EPM Default Value: \_\_exp626pu\_\_  
Description: Exp6\_2\_6 PickupCode

P65130  
EPM Default Value: \_\_exp627type\_\_  
Description: Exp6\_2\_7 KeyType

P65131  
EPM Default Value: \_\_exp627value\_\_  
Description: Exp6\_2\_7 Value

P65132  
EPM Default Value: \_\_exp627label\_\_  
Description: Exp6\_2\_7 Label

P65133  
EPM Default Value: \_\_exp627acct\_\_  
Description: Exp6\_2\_7 Account

P65134  
EPM Default Value: \_\_exp627pu\_\_  
Description: Exp6\_2\_7 PickupCode

P65135  
EPM Default Value: \_\_exp628type\_\_  
Description: Exp6\_2\_8 KeyType

P65136  
EPM Default Value: \_\_exp628value\_\_  
Description: Exp6\_2\_8 Value

P65137  
EPM Default Value: \_\_exp628label\_\_  
Description: Exp6\_2\_8 Label

P65138  
EPM Default Value: \_\_exp628acct\_\_  
Description: Exp6\_2\_8 Account

P65139  
EPM Default Value: \_\_exp628pu\_\_  
Description: Exp6\_2\_8 PickupCode

P65140  
EPM Default Value: \_\_exp629type\_\_  
Description: Exp6\_2\_9 KeyType

P65141  
EPM Default Value: \_\_exp629value\_\_  
Description: Exp6\_2\_9 Value

P65142  
EPM Default Value: \_\_exp629label\_\_  
Description: Exp6\_2\_9 Label

P65143  
EPM Default Value: \_\_exp629acct\_\_  
Description: Exp6\_2\_9 Account

P65144  
EPM Default Value: \_\_exp629pu\_\_  
Description: Exp6\_2\_9 PickupCode

P65145  
EPM Default Value: \_\_exp630type\_\_  
Description: Exp6\_2\_10 KeyType

P65146  
EPM Default Value: \_\_exp630value\_\_  
Description: Exp6\_2\_10 Value

P65147  
EPM Default Value: \_\_exp630label\_\_  
Description: Exp6\_2\_10 Label

P65148  
EPM Default Value: \_\_exp630acct\_\_  
Description: Exp6\_2\_10 Account

P65149  
EPM Default Value: \_\_exp630pu\_\_  
Description: Exp6\_2\_10 PickupCode

P65150  
EPM Default Value: \_\_exp631type\_\_  
Description: Exp6\_2\_11 KeyType

P65151  
EPM Default Value: \_\_exp631value\_\_  
Description: Exp6\_2\_11 Value

P65152  
EPM Default Value: \_\_exp631label\_\_  
Description: Exp6\_2\_11 Label

P65153  
EPM Default Value: \_\_exp631acct\_\_  
Description: Exp6\_2\_11 Account

P65154  
EPM Default Value: \_\_exp631pu\_\_  
Description: Exp6\_2\_11 PickupCode

P65155  
EPM Default Value: \_\_exp632type\_\_  
Description: Exp6\_2\_12 KeyType

P65156  
EPM Default Value: \_\_exp632value\_\_  
Description: Exp6\_2\_12 Value

P65157  
EPM Default Value: \_\_exp632label\_\_  
Description: Exp6\_2\_12 Label



P65158  
EPM Default Value: \_\_exp632acct\_\_  
Description: Exp6\_2\_12 Account

P65159  
EPM Default Value: \_\_exp632pu\_\_  
Description: Exp6\_2\_12 PickupCode

P65160  
EPM Default Value: \_\_exp633type\_\_  
Description: Exp6\_2\_13 KeyType

P65161  
EPM Default Value: \_\_exp633value\_\_  
Description: Exp6\_2\_13 Value

P65162  
EPM Default Value: \_\_exp633label\_\_  
Description: Exp6\_2\_13 Label

P65163  
EPM Default Value: \_\_exp633acct\_\_  
Description: Exp6\_2\_13 Account

P65164  
EPM Default Value: \_\_exp633pu\_\_  
Description: Exp6\_2\_13 PickupCode

P65165  
EPM Default Value: \_\_exp634type\_\_  
Description: Exp6\_2\_14 KeyType

P65166  
EPM Default Value: \_\_exp634value\_\_  
Description: Exp6\_2\_14 Value

P65167  
EPM Default Value: \_\_exp634label\_\_  
Description: Exp6\_2\_14 Label

P65168  
EPM Default Value: \_\_exp634acct\_\_  
Description: Exp6\_2\_14 Account

P65169  
EPM Default Value: \_\_exp634pu\_\_  
Description: Exp6\_2\_14 PickupCode

P65170  
EPM Default Value: \_\_exp635type\_\_  
Description: Exp6\_2\_15 KeyType

P65171  
EPM Default Value: \_\_exp635value\_\_  
Description: Exp6\_2\_15 Value

P65172  
EPM Default Value: \_\_exp635label\_\_  
Description: Exp6\_2\_15 Label

P65173  
EPM Default Value: \_\_exp635acct\_\_  
Description: Exp6\_2\_15 Account

P65174  
EPM Default Value: \_\_exp635pu\_\_  
Description: Exp6\_2\_15 PickupCode

P65175  
EPM Default Value: \_\_exp636type\_\_  
Description: Exp6\_2\_16 KeyType

P65176  
EPM Default Value: \_\_exp636value\_\_  
Description: Exp6\_2\_16 Value

P65177  
EPM Default Value: \_\_exp636label\_\_  
Description: Exp6\_2\_16 Label

P65178  
EPM Default Value: \_\_exp636acct\_\_  
Description: Exp6\_2\_16 Account

P65179  
EPM Default Value: \_\_exp636pu\_\_  
Description: Exp6\_2\_16 PickupCode

P65180  
EPM Default Value: \_\_exp637type\_\_  
Description: Exp6\_2\_17 KeyType

P65181  
EPM Default Value: \_\_exp637value\_\_  
Description: Exp6\_2\_17 Value

P65182  
EPM Default Value: \_\_exp637label\_\_  
Description: Exp6\_2\_17 Label

P65183  
EPM Default Value: \_\_exp637acct\_\_  
Description: Exp6\_2\_17 Account

P65184  
EPM Default Value: \_\_exp637pu\_\_  
Description: Exp6\_2\_17 PickupCode

P65185  
EPM Default Value: \_\_exp638type\_\_  
Description: Exp6\_2\_18 KeyType

P65186  
EPM Default Value: \_\_exp638value\_\_  
Description: Exp6\_2\_18 Value

P65187  
EPM Default Value: \_\_exp638label\_\_  
Description: Exp6\_2\_18 Label

P65188  
EPM Default Value: \_\_exp638acct\_\_  
Description: Exp6\_2\_18 Account

P65189  
EPM Default Value: \_\_exp638pu\_\_  
Description: Exp6\_2\_18 PickupCode

P65190  
EPM Default Value: \_\_exp639type\_\_  
Description: Exp6\_2\_19 KeyType

P65191  
EPM Default Value: \_\_exp639value\_\_  
Description: Exp6\_2\_19 Value

P65192  
EPM Default Value: \_\_exp639label\_\_  
Description: Exp6\_2\_19 Label

P65193  
EPM Default Value: \_\_exp639acct\_\_  
Description: Exp6\_2\_19 Account

P65194  
EPM Default Value: \_\_exp639pu\_\_  
Description: Exp6\_2\_19 PickupCode

P65195  
EPM Default Value: \_\_exp640type\_\_  
Description: Exp6\_2\_20 KeyType

P65196  
EPM Default Value: \_\_exp640value\_\_  
Description: Exp6\_2\_20 Value

P65197  
EPM Default Value: \_\_exp640label\_\_  
Description: Exp6\_2\_20 Label

P65198  
EPM Default Value: \_\_exp640acct\_\_  
Description: Exp6\_2\_20 Account

P65199  
EPM Default Value: \_\_exp640pu\_\_  
Description: Exp6\_2\_20 PickupCode

P20479  
EPM Default Value: \_\_labelWidth\_\_  
Description: Wide labels

P23280  
EPM Default Value: \_\_contactPhoto\_\_  
Description: Contact Images Path

P23283  
EPM Default Value: \_\_failoverXML\_\_  
Description: Failover XML Browser Server

P23284  
EPM Default Value:  
Description: Second Failover XML Browser Server

P23290  
EPM Default Value: \_\_failoverVPN\_\_  
Description: Failover VPN configuration address

P23289  
EPM Default Value: \_\_browserNote\_\_  
Description: Xml Browser Note Popup

P8678  
EPM Default Value: \_\_fontSize\_\_  
Description: Font size for phone and expansion modules

P23351  
EPM Default Value: \_\_sunStart\_\_  
Description: Sunday Start Time

P23352  
EPM Default Value: \_\_sunEnd\_\_  
Description: Sunday End Time

P23353  
EPM Default Value: \_\_monStart\_\_  
Description: Monday Start Time

P23354  
EPM Default Value: \_\_monEnd\_\_  
Description: Monday End Time

P23355  
EPM Default Value: \_\_tueStart\_\_  
Description: Tuesday Start Time

P23356

EPM Default Value: \_\_tueEnd\_\_

Description: Tuesday End Time

P23357

EPM Default Value: \_\_wedStart\_\_

Description: Wednesday Start Time

P23358

EPM Default Value: \_\_wedEnd\_\_

Description: Wednesday End Time

P23359

EPM Default Value: \_\_thrStart\_\_

Description: Thursday Start Time

P23360

EPM Default Value: \_\_thrEnd\_\_

Description: Thursday End Time

P23361

EPM Default Value: \_\_friStart\_\_

Description: Friday Start Time

P23362

EPM Default Value: \_\_friEnd\_\_

Description: Friday End Time

P23363

EPM Default Value: \_\_satStart\_\_

Description: Saturday Start Time

P23364

EPM Default Value: \_\_satEnd\_\_

Description: Saturday End Time

P23291

EPM Default Value: \_\_callHistory\_\_

Description: Flush call history 1 - Yes;0 - No

P23365

EPM Default Value:

Description: Log On (This message will be sent out when phone apps log on.)

P23366

EPM Default Value:

Description: Log Off (This message will be sent out when phone apps log off.)

P23367

EPM Default Value: \_\_explImagePath\_\_

Description: Expansion Module Contact Images Path

P23204

EPM Default Value: \_\_holdTone\_\_

Description: Hold Tone 1 - Yes, 0 - No

P23205

EPM Default Value: \_\_holdToneDelay\_\_

Description: Hold Tone Delay (Number of seconds between tones)

P23292

EPM Default Value: \_\_phoneLabel\_\_

Description: Toolbar Label

P23388

EPM Default Value: \_\_sipKeepAliveMode\_\_

Description: SIP KeepAlive Mode 0 - Disable, 1 - SIP OPTION

P23382

EPM Default Value: 15

Description: SIP KeepAlive Interval

P23500  
EPM Default Value: 0  
Description: PC Port Mirroring

P24001  
EPM Default Value: 0  
Description: PC Port Active 0 - Enable, 1 - Disable

P23400  
EPM Default Value: 1  
Description: Auto Answer Alert 0 - Disable, 1 - Enable

P24887  
EPM Default Value: 0  
Description: Call Pickup, Send Pickup Code on Refer 0 - Disable, 1 - Enable. Phone default is 1.

P24792  
EPM Default Value: 0  
Description: If enabled, causes incoming Intercom calls to be put to the loudspeaker, rather than the headset, if the phone is otherwise configured for headset mode. Defaults to 0. To enable, set to 1.

P23406  
EPM Default Value: 0  
Description: If enabled, while the phone is in the ringing state due to an inbound call, and the user presses a BLF or speed dial button, the phone will generate a new call to the BLF or speed dial. If disabled, the phone will blind transfer the incoming call to the BLF or speed dial destination. Defaults to 0. To enable, set to 1.

P24972  
EPM Default Value: 0  
Description: If enabled, the phone, if on non-primary pages of BLF keys, will return to the primary page following a timeout set by this option. The timeout is in seconds and is from 1-120. Defaults to 0 (disabled). Added in x.0.4.77.

P24953  
EPM Default Value: 0  
Description: If enabled, only send pickup prefix codes on BLF keypress while the phone is idle. If disabled, send always. Defaults to 0. To enable, set to 1. Added in x.0.4.76.