


Setting up Standard SIPStation with Toshiba

- Locating your SIP Username and Password
- Setting up your Trunks in the Toshiba GUI

Locating your SIP Username and Password

- Log into your SIPStation.com account.
- Click on **My Account** in the green navigation menu.



- You will find your SIP Username and SIP Password under the "Account Configuration" section. Take note of these, as you will need to use them when you set up trunks in Switchvox.

Setting up your Trunks in the Toshiba GUI