

Sangoma P Codes

Overview

Sangoma phone configs use "P Codes" or Programming Codes. Each P Code is assigned a number. The configs then use a standard XML layout, ie: <pcode>value</pcode>. Below is a list of all P Codes, the value that Endpoint Manager sets by default, and the description of the P Code including possible settings.

Sangoma Phone P Codes

P271

EPM Default Value: __line1Enable__

Description: Account Active (In Use). 0 - No, 1 - Yes

P47

EPM Default Value: __line1Dest__:__line1ServerPort__

Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P4567

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P130

EPM Default Value: __transport1__

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P52

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P35

EPM Default Value: __line1Ext__

Description: SIP User ID

P36

EPM Default Value: __line1Ext__

Description: Authenticate ID

P34

EPM Default Value: __line1Pass__

Description: Authenticate password

P3

EPM Default Value: __line1Name__

Description: Name

P103

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P63

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P31

EPM Default Value: __line1Enable__

Description: SIP Registration. 0 - No, 1 - Yes

P81

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P32

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P109
EPM Default Value: 1
Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P78
EPM Default Value: 0
Description: Use Random Port.0 - No, 1 - Yes

P33
EPM Default Value: __voicemail__
Description: Voice Mail UserID(UserID for voice mail system)

P57
EPM Default Value: __line1Codec1__
Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P58
EPM Default Value: __line1Codec2__
Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P59
EPM Default Value: __line1Codec3__
Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P60
EPM Default Value: __line1Codec4__
Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P61
EPM Default Value: __line1Codec5__
Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P62
EPM Default Value: __line1Codec6__
Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P37
EPM Default Value: 2
Description: Voice Frames Per TX

P49
EPM Default Value: 0
Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P79
EPM Default Value: 101
Description: DTMF Payload Type

P74
EPM Default Value: 0
Description: Send Flash Event.0 - no, 1 - yes

P191
EPM Default Value: 0
Description: Enable Call Features.0 - no, 1 - yes

P197
EPM Default Value:
Description: Proxy Require

P101
EPM Default Value:
Description: Use NAT IP(use in SIP/SDP message if specified)

P183
EPM Default Value: __srtpMode1__
Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P50
EPM Default Value: 0
Description: VAD.0 - no, 1 - yes

P291

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P133

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P132

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P104

EPM Default Value: __ringtone__

Description: Account Ring Tone

P185

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P72

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4200

EPM Default Value: __dialpattern__

Description: Dial Plan (dial plan prefix string).

P99

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P65

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P129

EPM Default Value: __acr__

Description: Anonymous Call Rejection.0 - no, 1 - yes

P258

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P90

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P298

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P299

EPM Default Value: __remoteDisconnect__

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P260

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P261

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P262

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P263

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P264
EPM Default Value: 0
Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P266
EPM Default Value: 0
Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P267
EPM Default Value: 1
Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P265
EPM Default Value: 0
Description: Force INVITE (Always refresh with INVITE instead of UPDATE) 0 - No, 1 - Yes

P251
EPM Default Value: 30
Description: Hook Flash Timing

P252
EPM Default Value: 100
Description: Hook Flash Timing

P198
EPM Default Value: 100
Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P134
EPM Default Value:
Description: Eventlist BLF URL

P8771
EPM Default Value: 0
Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8791
EPM Default Value: 0
Description: SIP Server Type

P8811
EPM Default Value: 0
Description: 100 reliable retransmission

P8841
EPM Default Value: 0
Description: Early-Session 0 - Disable, 1 - Enable

P4705
EPM Default Value: __directedCallPickup__
Description: Direct Call Pickup Code

P4706
EPM Default Value:
Description: Group Call Pickup Code

P401
EPM Default Value: __line2Enable__
Description: Account Active (In Use). 0 - No, 1 - Yes

P747
EPM Default Value: __line2Dest__:__line2ServerPort__
Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P987
EPM Default Value:
Description: Failover SIP Server(Optional, used when primary server no response)

P4568
EPM Default Value: 0
Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P748

EPM Default Value:

Description: Outbound Proxy(proxy.myprovider.com, or IP address, if any)

P830

EPM Default Value: __transport2__

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P730

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P735

EPM Default Value: __line2Ext__

Description: SIP User ID

P736

EPM Default Value: __line2Ext__

Description: Authenticate ID

P734

EPM Default Value: __line2Pass__

Description: Authenticate password

P703

EPM Default Value: __line2Name__

Description: Name

P702

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P763

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P731

EPM Default Value: __line2Enable__

Description: SIP Registration. 0 - No, 1 - Yes

P752

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P732

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P813

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P778

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P426

EPM Default Value: __line2Ext__

Description: Voice Mail UserID(UserID for voice mail system)

P757

EPM Default Value: __line2Codec1__

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P758

EPM Default Value: __line2Codec2__

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P759

EPM Default Value: __line2Codec3__

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P760

EPM Default Value: __line2Codec4__

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P761

EPM Default Value: __line2Codec5__

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P762

EPM Default Value: __line2Codec6__

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P737

EPM Default Value: 2

Description: Voice Frames Per TX

P749

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P779

EPM Default Value: 101

Description: DTMF Payload Type

P774

EPM Default Value: 0

Description: Send Flash Event.0 - no, 1 - yes

P151

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P866

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P443

EPM Default Value: __srtpMode2__

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P750

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P460

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P831

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P832

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P423

EPM Default Value: __ringtone__

Description: Account Ring Tone

P816

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P772

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4201

EPM Default Value: __dialpattern__

Description: Dial Plan (dial plan prefix string).

P709

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P421

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P446

EPM Default Value: __acr__

Description: Anonymous Call Rejection.0 - no, 1 - yes

P458

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P425

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P438

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P439

EPM Default Value: __remoteDisconnect__

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P434

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P427

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P428

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P429

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P430

EPM Default Value: 0

Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P432

EPM Default Value: 0

Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P433

EPM Default Value: 1

Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P431

EPM Default Value: 0

Description: Force INVITE (Always refresh with INVITE instead of UPDATE) 0 - No, 1 - Yes

P811

EPM Default Value: 30

Description: Hook Flash Timing

P812

EPM Default Value: 100

Description: Hook Flash Timing

P767

EPM Default Value: 100

Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P444

EPM Default Value:

Description: Eventlist BLF URL

P8772

EPM Default Value: 0

Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8792

EPM Default Value: 0

Description: SIP Server Type

P8812

EPM Default Value: 0

Description: 100 reliable retransmission

P8842

EPM Default Value: 0

Description: Early-Session 0 - Disable, 1 - Enable

P4715

EPM Default Value: __directedCallPickup__

Description: Direct Call Pickup Code

P4716

EPM Default Value:

Description: Group Call Pickup Code

P501

EPM Default Value: __line3Enable__

Description: Account Active (In Use). 0 - No, 1 - Yes

P502

EPM Default Value: __line3Dest__:__line3ServerPort__

Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P988

EPM Default Value:

Description: Failover SIP Server(Optional, used when primary server no response)

P4569

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P503

EPM Default Value:

Description: Outbound Proxy(proxy.myprovider.com, or IP address, if any)

P930

EPM Default Value: __transport3__

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P514

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P504

EPM Default Value: __line3Ext__

Description: SIP User ID

P505

EPM Default Value: __line3Ext__

Description: Authenticate ID

P506

EPM Default Value: __line3Pass__

Description: Authenticate password

P507

EPM Default Value: __line3Name__

Description: Name

P508

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P509

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P510

EPM Default Value: __line3Enable__

Description: SIP Registration. 0 - No, 1 - Yes

P511

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P512

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P913

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P578

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P526

EPM Default Value: __line3Ext__

Description: Voice Mail UserID(UserID for voice mail system)

P551

EPM Default Value: __line3Codec1__

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P552

EPM Default Value: __line3Codec2__

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P553

EPM Default Value: __line3Codec3__

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P554

EPM Default Value: __line3Codec4__

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P555

EPM Default Value: __line3Codec5__

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P556

EPM Default Value: __line3Codec6__

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P537

EPM Default Value: 2

Description: Voice Frames Per TX

P559

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P579

EPM Default Value: 101

Description: DTMF Payload Type

P1891

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P518

EPM Default Value:

Description: Proxy Require

P566

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P543

EPM Default Value: __srtpMode3__

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P550

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P591

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P1133

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P1132

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P523

EPM Default Value: __ringtone__

Description: Account Ring Tone

P1885

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P1672

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P4202

EPM Default Value: __dialpattern__

Description: Dial Plan (dial plan prefix string).

P515

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P521

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P1846

EPM Default Value: __acr__

Description: Anonymous Call Rejection.0 - no, 1 - yes

P567

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P525

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P538

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P539

EPM Default Value: __remoteDisconnect__

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P534

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P527

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P528

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P529
EPM Default Value: 0
Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P530
EPM Default Value: 0
Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P532
EPM Default Value: 0
Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P533
EPM Default Value: 1
Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P531
EPM Default Value: 0
Description: Force INVITE (Always refresh with INVITE instead of UPDATE) 0 - No, 1 - Yes

P1811
EPM Default Value: 30
Description: Hook Flash Timing

P1812
EPM Default Value: 100
Description: Hook Flash Timing

P524
EPM Default Value: 100
Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P544
EPM Default Value:
Description: Eventlist BLF URL

P8773
EPM Default Value: 0
Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8793
EPM Default Value: 0
Description: SIP Server Type

P8813
EPM Default Value: 0
Description: 100 reliable retransmission

P8843
EPM Default Value: 0
Description: Early-Session 0 - Disable, 1 - Enable

P4725
EPM Default Value: __directedCallPickup__
Description: Direct Call Pickup Code

P4726
EPM Default Value:
Description: Group Call Pickup Code

P601
EPM Default Value: __line4Enable__
Description: Account Active (In Use). 0 - No, 1 - Yes

P602
EPM Default Value: __line4Dest__:__line4ServerPort__
Description: Primary SIP Server(eg:sip.mycompany.com or IP address)

P989
EPM Default Value:
Description: Failover SIP Server(Optional, used when primary server no response)

P4570

EPM Default Value: 0

Description: Prefer Primary SIP Server (In Use). 0 - No, 1 - Yes

P603

EPM Default Value:

Description: Outbound Proxy(proxy.myprovider.com, or IP address, if any)

P1030

EPM Default Value: __transport4__

Description: SIP Transport 0 - UDP, 1 - TCP, 2 - TLS

P614

EPM Default Value: 2

Description: NAT Traversal. 0 - No, 1 - STUN 2 - No,but send keep alive

P604

EPM Default Value: __line4Ext__

Description: SIP User ID

P605

EPM Default Value: __line4Ext__

Description: Authenticate ID

P606

EPM Default Value: __line4Pass__

Description: Authenticate password

P607

EPM Default Value: __line4Name__

Description: Name

P608

EPM Default Value: 0

Description: DNS Mode. 0 - A Record, 1 - SRV, 2 - NAPTR/SRV

P609

EPM Default Value: 0

Description: User ID Is Phone Number.0 - No, 1 - Yes

P610

EPM Default Value: __line4Enable__

Description: SIP Registration. 0 - No, 1 - Yes

P611

EPM Default Value: 1

Description: Unregister On Reboot.0 - No, 1 - Yes

P612

EPM Default Value: 15

Description: Register Expiration(in minutes. default 1 hour, max 45 days)

P1013

EPM Default Value: 1

Description: Outgoing Call Without Registration.0 - No, 1 - Yes

P678

EPM Default Value: 0

Description: Use Random Port.0 - No, 1 - Yes

P626

EPM Default Value: __line4Ext__

Description: Voice Mail UserID(UserID for voice mail system)

P651

EPM Default Value: __line4Codec1__

Description: Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P652

EPM Default Value: __line4Codec2__

Description: Second Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P653

EPM Default Value: __line4Codec3__

Description: Third Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P654

EPM Default Value: __line4Codec4__

Description: Fourth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P655

EPM Default Value: __line4Codec5__

Description: Fifth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P656

EPM Default Value: __line4Codec6__

Description: Sixth Preferred Vocoder In listed order 0 - PCMU, 2 - G.726-32, 4 - G.723.1, 8 - PCMA, 9 - G.722, 18 - G.729A/B

P637

EPM Default Value: 2

Description: Voice Frames Per TX

P659

EPM Default Value: 0

Description: G723 Rate.0 - 6.3kbps encoding rate, 1 - 5.3kbps encoding rate

P679

EPM Default Value: 101

Description: DTMF Payload Type

P1991

EPM Default Value: 0

Description: Enable Call Features.0 - no, 1 - yes

P618

EPM Default Value:

Description: Proxy Require

P666

EPM Default Value:

Description: Use NAT IP(use in SIP/SDP message if specified)

P643

EPM Default Value: __srtpMode4__

Description: SRTP Mode 0, Disabled, 1, Enabled but not forced, 2, Enabled and forced

P695

EPM Default Value: 0

Description: VAD.0 - no, 1 - yes

P691

EPM Default Value: 0

Description: Symmetric RTP.0 - no, 1 - yes

P1233

EPM Default Value: 1

Description: Jitter Buffer Type.0 - fixed, 1 - adaptive

P1232

EPM Default Value: 1

Description: Jitter Buffer Length.0 - low, 1 - medium, 2 - high

P623

EPM Default Value: __ringtone__

Description: Account Ring Tone

P1886

EPM Default Value: 60

Description: Ring Timeout(10-300 seconds,default is 60 seconds)

P1772

EPM Default Value: 1

Description: Use # As Dial Key.0 - no, 1 - yes

P42033

EPM Default Value: __dialpattern__

Description: Dial Plan (dial plan prefix string).

P615

EPM Default Value: 0

Description: Subscribe for MWI.0 - no,do not send SUBSCRIBE for Message Waiting Indication, 1 - yes,send periodical SUBBSCRIBE for , Message Waiting indication

P621

EPM Default Value: 0

Description: Send Anonymous.0 - no, 1 - yes

P1946

EPM Default Value: __acr__

Description: Anonymous Call Rejection.0 - no, 1 - yes

P667

EPM Default Value: 1

Description: Check SIP User ID.0 - no, 1 - yes

P625

EPM Default Value: 0

Description: Auto Answer.0 - no, 1 - yes

P638

EPM Default Value: 1

Description: Allow Auto Answer By Call-Info.0 - no, 1 - yes

P639

EPM Default Value: __remoteDisconnect__

Description: Turn off Speaker on remote disconnect.0 - no, 1 - yes

P634

EPM Default Value: 180

Description: Session Expiration(default is 180 seconds)

P627

EPM Default Value: 90

Description: Min-SE(default and minimum is 90 seconds)

P628

EPM Default Value: 0

Description: Caller Request Timer (Request for timer when making outbound calls) 0 - No, 1 - Yes

P629

EPM Default Value: 0

Description: Callee Request Timer (when caller supports timer but did not request one) 0 - No, 1 - Yes

P630

EPM Default Value: 0

Description: Force Timer (use timer even when remote party does not support) 0 - No, 1 - Yes

P632

EPM Default Value: 0

Description: UAC Specify Refresher. 1 - UAC, 2 - UAS, 0 - omit(Recommended)

P633

EPM Default Value: 1

Description: UAS Specify Refresher. 1 - UAC, 2 - UAS(When UAC did not)

P631

EPM Default Value: 0

Description: Force INVITE (Always refresh with INVITE instead of UPDATE) 0 - No, 1 - Yes

P1911

EPM Default Value: 30

Description: Hook Flash Timing

P1912

EPM Default Value: 100

Description: Hook Flash Timing

P624
EPM Default Value: 100
Description: Special Feature 100 - Standard, 104 - World Call, 106 - NETHID

P644
EPM Default Value:
Description: Eventlist BLF URL

P8774
EPM Default Value: 0
Description: Share Line 0 - Disable, 1 - Broadsoft, 2 - BLA

P8794
EPM Default Value: 0
Description: SIP Server Type

P8814
EPM Default Value: 0
Description: 100 reliable retransmission

P8844
EPM Default Value: 0
Description: Early-Session 0 - Disable, 1 - Enable

P4735
EPM Default Value: __directedCallPickup__
Description: Direct Call Pickup Code

P4736
EPM Default Value:
Description: Group Call Pickup Code

P8
EPM Default Value: 0
Description: WAN. 0 - DHCP, 1 - Static IP Address, 2 - PPPoE

P146
EPM Default Value:
Description: DHCP HostName, DHCP option 12. Max length allowed is 64 characters. Default value is 0.

P147
EPM Default Value:
Description: DHCP Domain

P148
EPM Default Value:
Description: DHCP Vendor Class ID, DHCP option 60. Max length allowed is 64 characters.
Phone Default Value: udhcp 1.12.1

P149
EPM Default Value:
Description: DHCP User Class

P9
EPM Default Value: 0
Description: IP Address 1'st octet

P10
EPM Default Value: 0
Description: IP Address 2'nd octet

P11
EPM Default Value: 0
Description: IP Address 3'rd octet

P12
EPM Default Value: 0
Description: IP Address 4'th octet

P13
EPM Default Value: 0
Description: Subnet Mask 1'st octet

P14

EPM Default Value: 0
Description: Subnet Mask 2'nd octet

P15
EPM Default Value: 0
Description: Subnet Mask 3'rd octet

P16
EPM Default Value: 0
Description: Subnet Mask 4'th octet

P17
EPM Default Value: 0
Description: Default Gateway 1'st octet

P18
EPM Default Value: 0
Description: Default Gateway 2'nd octet

P19
EPM Default Value: 0
Description: Default Gateway 3'rd octet

P20
EPM Default Value: 0
Description: Default Gateway 4'th octet

P21
EPM Default Value: 8
Description: Primary DNS 1'st octet

P22
EPM Default Value: 8
Description: Primary DNS 2'nd octet

P23
EPM Default Value: 8
Description: Primary DNS 3'rd octet

P24
EPM Default Value: 8
Description: Primary DNS 4'th octet

P25
EPM Default Value: 8
Description: Secondary DNS 1'st octet

P26
EPM Default Value: 8
Description: Secondary DNS 2'nd octet

P27
EPM Default Value: 4
Description: Secondary DNS 3'rd octet

P28
EPM Default Value: 4
Description: Secondary DNS 4'th octet

P82
EPM Default Value:
Description: PPPoE account ID

P83
EPM Default Value:
Description: PPPoE password

P269
EPM Default Value:
Description: PPPoE Service Name

P92
EPM Default Value: 8
Description: DNS Server 1'st octet

P93

EPM Default Value: 8

Description: DNS Server 2'nd octet

P94

EPM Default Value: 8

Description: DNS Server 3'rd octet

P95

EPM Default Value: 8

Description: DNS Server 4'th octet

P189

EPM Default Value: 1

Description: Reply To ICMP

P190

EPM Default Value: 1

Description: Http Access 0 - no, 1 - yes

P231

EPM Default Value: __pc_port__

Description: PC Port 1 - As Bridge, 0 - as Router, 2 - as Expansion module

P111

EPM Default Value: 192.168.66.1

Description: IP Address

P110

EPM Default Value: 255.255.255.0

Description: Subnet Mask

P112

EPM Default Value: 24

Description: IP Lease Time

P5438

EPM Default Value: __lldp__

Description: LLDP Active 0 - Disable, 1 - Enable

P5439

EPM Default Value: __lldpPacket__

Description: Packed Interval

P38

EPM Default Value: 48

Description: Layer 3 QoS (Diff-Serv or Precedence value)

P51

EPM Default Value: __vVlan__

Description: Layer 2 QoS. 802.1Q/VLAN Tag (VLAN classification for RTP)

P87

EPM Default Value: __vVlanP__

Description: Layer 2 QoS. 802.1p priority value (0 - 7).

P229

EPM Default Value: __dVlan__

Description: Data VLAN Tag (vaild only when Bridge mode)

P30

EPM Default Value: __timeserver1__

Description: NTP Server

P144

EPM Default Value: 0

Description: Allow DHCP Option 42 To Override NTP Server 0 - no, 1 - yes

P8629

EPM Default Value: __vpnEnable__

Description: VPN Active 0 - no, 1 - yes

P901

EPM Default Value: 80

Description: Web Server HTTP Port

P8724

EPM Default Value: 443

Description: Web Server HTTPS Port

P8725

EPM Default Value: 1

Description: Web Server Type 0 - Disable, 1 - HTTP&HTTPS, 2 - HTTP Only, 3 - HTTPS Only

P8626

EPM Default Value: __vlanMode__

Description: 802.1X Mode 0 - Disable, 1 - EAP-MD5

P8627

EPM Default Value: __vlanIdentity__

Description: Identity

P8628

EPM Default Value: __vlanPass__

Description: MD5 Password

P76

EPM Default Value:

Description: STUN Server (url or ip:port)

P84

EPM Default Value: 20

Description: Keep-ative Interval(seconds default:20)

P2525

EPM Default Value: __language__

Description: Web Language 0 - English, 1 - Chinese

P64

EPM Default Value: __timezone__

Description: Time Zone

P143

EPM Default Value: 0

Description: DHCP Time 0 - no, 1 - yes

P75

EPM Default Value: __daylight__

Description: Daylight Saving Time 0 - no, 1 - yes

P102

EPM Default Value: __dateFormat__

Description: Date Display Format 0 - Year - Month - Day, 1 - Month - Day - Year, 2 - Day - Month - Year

P8624

EPM Default Value: __timeFormat__

Description: Time Format, 1-12 Hour,0-24 Hour

P88

EPM Default Value: 0

Description: Lock Keypad Update 0 - no, 1 - yes

P1300

EPM Default Value: __keypressTone__

Description: Keypad DTMF Tone 1 - no, 0 - yes

P249

EPM Default Value: 0

Description: MIC Volume Amplification 0 - 0dB default, 1 - +6dB, 2 - +4dB, 3 - +2dB, 4 - -2dB, 5 - -4dB, 6 - -6dB

P8940

EPM Default Value: __screensavertimeout__

Description: Screen Time Out 0 - Off, 1 - 1min, 2 - 2min, 3 - 5min, 4 - 10min, 5 - 30min

P8950

EPM Default Value: __screensaver__

Description: ScreenSaver Type 0 - backlight off, 0 - time & logo, 2 - photo switch

P8721

EPM Default Value: __ringtone__

Description: Ring Tones

P85

EPM Default Value: __entryTimeout__

Description: NO Key Entry Timeout(in seconds, 0 means never timeout, default is 0 seconds)

P3734

EPM Default Value: __powerStatusEnable__

Description: LED Status.Power Status.0 - no, 1 - yes

P3735

EPM Default Value: __ringingStatusEnable__

Description: LED Status.Ringing Status.0 - no, 1 - yes

P3736

EPM Default Value: __misscallsStatusEnable__

Description: LED Status. MissCalls Status.0 - no, 1 - yes

P53100

EPM Default Value: 0

Description: Forward--always 1 - on, 0 - off

P53101

EPM Default Value:

Description: Target(Target number for transfer)

P53102

EPM Default Value:

Description: On Code

P53103

EPM Default Value:

Description: Off Code

P53110

EPM Default Value: 0

Description: Forward--Busy 1 - on, 0 - off

P53111

EPM Default Value:

Description: Target(Target number for transfer)

P53112

EPM Default Value:

Description: On Code

P53113

EPM Default Value:

Description: Off Code

P53120

EPM Default Value: 0

Description: Forward--No Answer 1 - on, 0 - off

P53124

EPM Default Value:

Description: After Ring Time(seconds)(waiting time for NoAnswer forward)

P53121

EPM Default Value:

Description: Target(Target number for transfer)

P53122

EPM Default Value:

Description: On Code

P53123

EPM Default Value:

Description: Off Code

P53200

EPM Default Value: __dndOn__

Description: Do Not Disturb.DND On Code(The feature code to enable DND,the phone will send the feature code directly to open DND)

P53201

EPM Default Value: __dndOff__

Description: Do Not Disturb.DND Off Code(The feature code to disable DND,the phone will send the feature code directly to close DND)

P53202

EPM Default Value:

Description: Do Not Disturb.Authorized Numbers(comma separated)

P4210

EPM Default Value: __hotline__

Description: Hotline.Hotline Number

P8638

EPM Default Value: 0

Description: Hotline.Hotline Time-out(seconds)(0~180s)

P3201

EPM Default Value: 1

Description: Transfer Settings.Blind Transfer On Hook.0 - off, 1 - on

P3202

EPM Default Value: 1

Description: Transfer Settings.Semi-Attended Transfer.0 - off, 1 - on

P3204

EPM Default Value: 1

Description: Transfer Settings.Attended Transfer On Hook.0 - off, 1 - on

P3205

EPM Default Value: 1

Description: Transfer Settings.Transfer Mode via DSSkey 0 - Attended Transfer, 1 - Blind Transfer, 2 - New Call

P4701

EPM Default Value: 0

Description: Call Pickup.Direct Call Pickup.0 - off, 1 - on

P4745

EPM Default Value: __directedCallPickup__

Description: Call Pickup.Direct Call Pickup Code

P4702

EPM Default Value: 0

Description: Call Pickup.Group Call Pickup.0 - off, 1 - on

P4746

EPM Default Value:

Description: Call Pickup.Group Call Pickup Code

P4703

EPM Default Value: __blfVisual__

Description: Call Pickup.Visual Alert for BLF Pickup.0 - off, 1 - on

P4704

EPM Default Value: __blfAudio__

Description: Call Pickup.Audio Alert for BLF Pickup.0 - off, 1 - on

P8630

EPM Default Value: 0

Description: Phone Lock.Keypad Lock.0 - Disabled, 1 - All Keys, 2 - Menu Key 3 - Function Keys, 4 - Answer All Only

P5730

EPM Default Value:

Description: Phone Lock.Phone Unlock Pin(0~15digital)

P5731

EPM Default Value:

Description: Phone Lock.Auto Lock Time-Out(0~3600s)

P5732

EPM Default Value:

Description: Phone Lock.Emergency

P4000

EPM Default Value: f1=350@-13,f2=440@-13,c=0/0;

Description: Call Progress Tones.Dial Tone

P4001
EPM Default Value: f1=440@-19,f2=480@-19,c=2000/4000;
Description: Call Progress Tones.Ringback Tone

P4002
EPM Default Value: f1=480@-24,f2=620@-24,c=500/500;
Description: Call Progress Tones.Busy Tone

P4003
EPM Default Value: f1=480@-24,f2=620@-24,c=250/250;
Description: Call Progress Tones.Reorder Tone

P4004
EPM Default Value: f1=350@-11,f2=440@-11,c=100/100-100/100-100/100;
Description: Call Progress Tones.Confirmation Tone

P4005
EPM Default Value: f1=440@-13,c=300/10000-300/10000-0/0;
Description: Call Progress Tones.Call Waiting Tone

P58100
EPM Default Value: 0
Description: SMS Account.0 - Account 1, 1 - Account 2, 2 - Account 3, 3 - Account 4

P3701
EPM Default Value:
Description: Setup Completed(This message will be sent out when the phone is start-up completed, available for use.)

P3702
EPM Default Value:
Description: Registered (This message will be sent out when an account is successfully registered.)

P3703
EPM Default Value:
Description: Deregistered (This message will be sent out when an account is deregistered.)

P3704
EPM Default Value:
Description: Register Failed(This message will be sent out when an account is registered failed.)

P3705
EPM Default Value:
Description: Offhook(This message will be sent out when the phone is off hook.)

P3706
EPM Default Value:
Description: Onhook(This message will be sent out when the phone is on hook.)

P3707
EPM Default Value:
Description: Incoming Call(This message will be sent out when there is an incoming call.)

P3708
EPM Default Value:
Description: Outgoing Call(This message will be sent out when there is an outgoing call.)

P3709
EPM Default Value:
Description: Call Established(This message will be sent out when a call is established.)

P3710
EPM Default Value:
Description: Call Terminated(This message will be sent out when a call is terminated.)

P3711
EPM Default Value:
Description: Open DND(This message will be sent out when DND is enabled.)

P3712
EPM Default Value:
Description: Close DND(This message will be sent out when DND is disabled.)

P3713

EPM Default Value:

Description: Open Always Forward(This message will be sent out when always-forward is enabled.)

P3714

EPM Default Value:

Description: Close Always Forward(This message will be sent out when always-forward is disabled.)

P3715

EPM Default Value:

Description: Open Busy Forward(This message will be sent out when busy-forward is enabled.)

P3716

EPM Default Value:

Description: Close Busy Forward(This message will be sent out when busy-forward is disabled.)

P3717

EPM Default Value:

Description: Open No Busy Forward(This message will be sent out when no-answer-forward is enabled.)

P3718

EPM Default Value:

Description: Close No Busy Forward(This message will be sent out when no-answer-forward is disable.)

P3719

EPM Default Value:

Description: Transfer Call(This message will be sent out when transferring a call(including all kinds of transfer).)

P3720

EPM Default Value:

Description: Blind Transfer call(This message will be sent out when doing blind-transfer.)

P3721

EPM Default Value:

Description: Attended Transfer Call(This message will be sent out when doing attended and semi-attended transfer.)

P3722

EPM Default Value:

Description: Hold(This message will be sent out when holding a call.)

P3723

EPM Default Value:

Description: Unhold(This message will be sent out when unholding the call.)

P3724

EPM Default Value:

Description: Mute(This message will be sent out when muting a call.)

P3725

EPM Default Value:

Description: Unmute(This message will be sent out when unmuting a call.)

P3726

EPM Default Value:

Description: Missed Call(This message will be sent out when there is a new missed call even if missed call logs is disabled.)

P3727

EPM Default Value:

Description: Idle ToBusy(call logs is disabled.)

P3728

EPM Default Value:

Description: Busy To Idle(Busy to IdleBusy to Idle)

P3729

EPM Default Value:

Description: Forward Incoming Call(Forward Incoming Call)

P3730

EPM Default Value:

Description: Reject Incoming Call(Reject Incoming Call)

P3731
EPM Default Value:
Description: Answer New Incoming Call(Answer New Incoming Call)

P3732
EPM Default Value:
Description: TransferFinished(Transfer Finished)

P3733
EPM Default Value:
Description: Transfer Failed(Transfer Failed)

P2
EPM Default Value: __adminPass__
Description: Admin password for web interface

P212
EPM Default Value: __protocol__
Description: Firmware Upgrade Upgrade Mode.0 - TFTP, 1 - HTTP, 2 - FTP

P192
EPM Default Value: __firmware__
Description: Firmware Server Path

P237
EPM Default Value: __provisionAddress__
Description: Config Server Path

P1360
EPM Default Value: __ftpuser__
Description: HTTP/FTP/HTTPS UserName

P1361
EPM Default Value: __ftppass__
Description: HTTP/FTP/HTTPS Password

P1145
EPM Default Value: 66
Description: Allow DHCP Option

P145
EPM Default Value: 0
Description: To Override Server. 0 - no, 1 - yes

P194
EPM Default Value: 1
Description: AUTO Upgrade. 0 - no, 1 - yes

P193
EPM Default Value: __resync__
Description: check for upgrade every () Minutes

P238
EPM Default Value: 0
Description: Upgrade Check Mode 0 - Always Check For New Firmware, 1 - check new firmware only when F/W pre/suffix changes, 2 - Always Skip The Firmware Check

P240
EPM Default Value: 0
Description: Authenticate Cfg File 0 - no, 1 - yes

P331
EPM Default Value:
Description: Phonebook XML Download

P332
EPM Default Value: 0
Description: Phonebook Download Interval(the interval time should be 0-720 days))

P333
EPM Default Value: 0
Description: Remove Manually-edited Entries On Download.0 - no, 1 - yes

P330

EPM Default Value: 0

Description: Phonebook XML Download Enable.0 - no, 1 - yes,HTTP, 2 - yes,TFTP, 3 - yes,FTP

P8150

EPM Default Value: 0

Description: SNMP Service Enable.0 - no, 1 - yes

P8151

EPM Default Value:

Description: SNMP Get Community

P8152

EPM Default Value:

Description: SNMP Set Community

P8153

EPM Default Value:

Description: SNMP Manager IP 1

P8154

EPM Default Value:

Description: SNMP Manager IP 2

P8155

EPM Default Value:

Description: SNMP Manager IP 3

P8156

EPM Default Value:

Description: SNMP Manager IP 4

P207

EPM Default Value:

Description: System Log.Syslog Server

Values: Dotted IP address of server, not inclusive of port definition. Port defaults to 514 and is not configurable.

P208

EPM Default Value: 0

Description: System Log.Syslog level 0 - NONE, 1 - DEBUG, 2 - INFO, 3 - WARNING, 4 - ERROR

P41200

EPM Default Value: __line1type__

Description: linekey_type_01

P41300

EPM Default Value: __line1value__

Description: linekey_value_01

P41400

EPM Default Value: __line1label__

Description: linekey_label_01

P41500

EPM Default Value: __line1acct__

Description: linekey_account_01

P41600

EPM Default Value: __line1pu__

Description: linekey_pickup_01

P41201

EPM Default Value: __line2type__

Description: linekey_type_02

P41301

EPM Default Value: __line2value__

Description: linekey_value_02

P41401

EPM Default Value: __line2label__

Description: linekey_label_02

P41501
EPM Default Value: __line2acct__
Description: linekey_account_02

P41601
EPM Default Value: __line2pu__
Description: linekey_pickup_02

P41202
EPM Default Value: __line3type__
Description: linekey_type_03

P41302
EPM Default Value: __line3value__
Description: linekey_value_03

P41402
EPM Default Value: __line3label__
Description: linekey_label_03

P41502
EPM Default Value: __line3acct__
Description: linekey_account_03

P41602
EPM Default Value: __line3pu__
Description: linekey_pickup_03

P41203
EPM Default Value: __line4type__
Description: linekey_type_04

P41303
EPM Default Value: __line4value__
Description: linekey_value_04

P41403
EPM Default Value: __line4label__
Description: linekey_label_04

P41503
EPM Default Value: __line4acct__
Description: linekey_account_04

P41603
EPM Default Value: __line4pu__
Description: linekey_pickup_04

P20200
EPM Default Value: __line5type__
Description: Linekey Type

P20604
EPM Default Value: __line5mode__
Description: Linekey Mode

P20201
EPM Default Value: __line5value__
Description: Linekey Value

P20202
EPM Default Value: __line5label__
Description: Linekey Label

P20203
EPM Default Value: __line5acct__
Description: Linekey Account

P20204
EPM Default Value: __line5pu__
Description: Linekey PickupCode

P20205
EPM Default Value: __line6type__
Description: Linekey Type

P20605
EPM Default Value: __line6mode__
Description: Linekey Mode

P20206
EPM Default Value: __line6value__
Description: Linekey Value

P20207
EPM Default Value: __line6label__
Description: Linekey Label

P20208
EPM Default Value: __line6acct__
Description: Linekey Account

P20209
EPM Default Value: __line6pu__
Description: Linekey PickupCode

P20210
EPM Default Value: __line7type__
Description: Linekey Type

P20606
EPM Default Value: __line7mode__
Description: Linekey Mode

P20211
EPM Default Value: __line7value__
Description: Linekey Value

P20212
EPM Default Value: __line7label__
Description: Linekey Label

P20213
EPM Default Value: __line7acct__
Description: Linekey Account

P20214
EPM Default Value: __line7pu__
Description: Linekey PickupCode

P20215
EPM Default Value: __line8type__
Description: Linekey Type

P20607
EPM Default Value: __line8mode__
Description: Linekey Mode

P20216
EPM Default Value: __line8value__
Description: Linekey Value

P20217
EPM Default Value: __line8label__
Description: Linekey Label

P20218
EPM Default Value: __line8acct__
Description: Linekey Account

P20219
EPM Default Value: __line8pu__
Description: Linekey PickupCode

P20220
EPM Default Value: __line9type__
Description: Linekey Type

P20608
EPM Default Value: __line9mode__
Description: Linekey Mode

P20221
EPM Default Value: __line9value__
Description: Linekey Value

P20222
EPM Default Value: __line9label__
Description: Linekey Label

P20223
EPM Default Value: __line9acct__
Description: Linekey Account

P20224
EPM Default Value: __line9pu__
Description: Linekey PickupCode

P20225
EPM Default Value: __line10type__
Description: LineKey Type

P20609
EPM Default Value: __line10mode__
Description: LineKey Mode

P20226
EPM Default Value: __line10value__
Description: LineKey Value

P20227
EPM Default Value: __line10label__
Description: LineKey Label

P20228
EPM Default Value: __line10acct__
Description: LineKey Account

P20229
EPM Default Value: __line10pu__
Description: LineKey PickupCode

P20230
EPM Default Value: __line11type__
Description: LineKey Type

P20610
EPM Default Value: __line11mode__
Description: LineKey Mode

P20231
EPM Default Value: __line11value__
Description: LineKey Value

P20232
EPM Default Value: __line11label__
Description: LineKey Label

P20233
EPM Default Value: __line11acct__
Description: LineKey Account

P20234
EPM Default Value: __line11pu__
Description: LineKey PickupCode

P20235
EPM Default Value: __line12type__
Description: LineKey Type

P20611
EPM Default Value: __line12mode__
Description: LineKey Mode

P20236
EPM Default Value: __line12value__
Description: LineKey Value

P20237
EPM Default Value: __line12label__
Description: LineKey Label

P20238
EPM Default Value: __line12acct__
Description: LineKey Account

P20239
EPM Default Value: __line12pu__
Description: LineKey PickupCode

P20240
EPM Default Value: __line13type__
Description: LineKey Type

P20612
EPM Default Value: __line13mode__
Description: LineKey Mode

P20241
EPM Default Value: __line13value__
Description: LineKey Value

P20242
EPM Default Value: __line13label__
Description: LineKey Label

P20243
EPM Default Value: __line13acct__
Description: LineKey Account

P20244
EPM Default Value: __line13pu__
Description: LineKey PickupCode

P20245
EPM Default Value: __line14type__
Description: LineKey Type

P20613
EPM Default Value: __line14mode__
Description: LineKey Mode

P20246
EPM Default Value: __line14value__
Description: LineKey Value

P20247
EPM Default Value: __line14label__
Description: LineKey Label

P20248
EPM Default Value: __line14acct__
Description: LineKey Account

P20249
EPM Default Value: __line14pu__
Description: LineKey PickupCode

P20250
EPM Default Value: __line15type__
Description: LineKey Type

P20614
EPM Default Value: __line15mode__
Description: LineKey Mode

P20251
EPM Default Value: __line15value__
Description: LineKey Value

P20252
EPM Default Value: __line15label__
Description: LineKey Label

P20253
EPM Default Value: __line15acct__
Description: LineKey Account

P20254
EPM Default Value: __line15pu__
Description: LineKey PickupCode

P20255
EPM Default Value: __line16type__
Description: LineKey Type

P20615
EPM Default Value: __line16mode__
Description: LineKey Mode

P20256
EPM Default Value: __line16value__
Description: LineKey Value

P20257
EPM Default Value: __line16label__
Description: LineKey Label

P20258
EPM Default Value: __line16acct__
Description: LineKey Account

P20259
EPM Default Value: __line16pu__
Description: LineKey PickupCode

P20260
EPM Default Value: __line17type__
Description: LineKey Type

P20616
EPM Default Value: __line17mode__
Description: LineKey Mode

P20261
EPM Default Value: __line17value__
Description: LineKey Value

P20262
EPM Default Value: __line17label__
Description: LineKey Label

P20263
EPM Default Value: __line17acct__
Description: LineKey Account

P20264
EPM Default Value: __line17pu__
Description: LineKey PickupCode

P20265
EPM Default Value: __line18type__
Description: LineKey Type

P20617
EPM Default Value: __line18mode__
Description: LineKey Mode

P20266
EPM Default Value: __line18value__
Description: LineKey Value

P20267
EPM Default Value: __line18label__
Description: LineKey Label

P20268
EPM Default Value: __line18acct__
Description: LineKey Account

P20269
EPM Default Value: __line18pu__
Description: LineKey PickupCode

P20270
EPM Default Value: __line19type__
Description: LineKey Type

P20618
EPM Default Value: __line19mode__
Description: LineKey Mode

P20271
EPM Default Value: __line19value__
Description: LineKey Value

P20272
EPM Default Value: __line19label__
Description: LineKey Label

P20273
EPM Default Value: __line19acct__
Description: LineKey Account

P20274
EPM Default Value: __line19pu__
Description: LineKey PickupCode

P20275
EPM Default Value: __line20type__
Description: LineKey Type

P20619
EPM Default Value: __line20mode__
Description: LineKey Mode

P20276
EPM Default Value: __line20value__
Description: LineKey Value

P20277
EPM Default Value: __line20label__
Description: LineKey Label

P20278
EPM Default Value: __line20acct__
Description: LineKey Account

P20279
EPM Default Value: __line20pu__
Description: LineKey PickupCode

P20280
EPM Default Value: __line21type__
Description: LineKey Type

P20620
EPM Default Value: __line21mode__
Description: LineKey Mode

P20281
EPM Default Value: __line21value__
Description: LineKey Value

P20282
EPM Default Value: __line21label__
Description: LineKey Label

P20283
EPM Default Value: __line21acct__
Description: LineKey Account

P20284
EPM Default Value: __line21pu__
Description: LineKey PickupCode

P20285
EPM Default Value: __line22type__
Description: LineKey Type

P20621
EPM Default Value: __line22mode__
Description: LineKey Mode

P20286
EPM Default Value: __line22value__
Description: LineKey Value

P20287
EPM Default Value: __line22label__
Description: LineKey Label

P20288
EPM Default Value: __line22acct__
Description: LineKey Account

P20289
EPM Default Value: __line22pu__
Description: LineKey PickupCode

P20290
EPM Default Value: __line23type__
Description: LineKey Type

P20622
EPM Default Value: __line23mode__
Description: LineKey Mode

P20291
EPM Default Value: __line23value__
Description: LineKey Value

P20292
EPM Default Value: __line23label__
Description: LineKey Label

P20293
EPM Default Value: __line23acct__
Description: LineKey Account

P20294
EPM Default Value: __line23pu__
Description: LineKey PickupCode

P20295
EPM Default Value: __line24type__
Description: LineKey Type

P20623
EPM Default Value: __line24mode__
Description: LineKey Mode

P20296
EPM Default Value: __line24value__
Description: LineKey Value

P20297
EPM Default Value: __line24label__
Description: LineKey Label

P20298
EPM Default Value: __line24acct__
Description: LineKey Account

P20299
EPM Default Value: __line24pu__
Description: LineKey PickupCode

P20300
EPM Default Value: __line25type__
Description: Linekey Type

P20624
EPM Default Value: __line25mode__
Description: LineKey Mode

P20301
EPM Default Value: __line25value__
Description: LineKey Value

P20302
EPM Default Value: __line25label__
Description: LineKey Label

P20303
EPM Default Value: __line25acct__
Description: LineKey Account

P20304
EPM Default Value: __line25pu__
Description: LineKey PickupCode

P20305
EPM Default Value: __line26type__
Description: LineKey Type

P20625
EPM Default Value: __line26mode__
Description: LineKey Mode

P20306
EPM Default Value: __line26value__
Description: LineKey Value

P20307
EPM Default Value: __line26label__
Description: LineKey Label

P20308
EPM Default Value: __line26acct__
Description: LineKey Account

P20309
EPM Default Value: __line26pu__
Description: LineKey PickupCode

P20310
EPM Default Value: __line27type__
Description: LineKey Type

P20626
EPM Default Value: __line27mode__
Description: LineKey Mode

P20311
EPM Default Value: __line27value__
Description: LineKey Value

P20312
EPM Default Value: __line27label__
Description: LineKey Label

P20313
EPM Default Value: __line27acct__
Description: LineKey Account

P20314
EPM Default Value: __line27pu__
Description: LineKey PickupCode

P20315
EPM Default Value: __line28type__
Description: LineKey Type

P20627
EPM Default Value: __line28mode__
Description: LineKey Mode

P20316
EPM Default Value: __line28value__
Description: LineKey Value

P20317
EPM Default Value: __line28label__
Description: LineKey Label

P20318
EPM Default Value: __line28acct__
Description: LineKey Account

P20319
EPM Default Value: __line28pu__
Description: LineKey PickupCode

P20320
EPM Default Value: __line29type__
Description: LineKey Type

P20628
EPM Default Value: __line29mode__
Description: LineKey Mode

P20321
EPM Default Value: __line29value__
Description: LineKey Value

P20322
EPM Default Value: __line29label__
Description: LineKey Label

P20323
EPM Default Value: __line29acct__
Description: LineKey Account

P20324
EPM Default Value: __line29pu__
Description: LineKey PickupCode

P20325
EPM Default Value: __line30type__
Description: LineKey Type

P20629
EPM Default Value: __line30mode__
Description: LineKey Mode

P20326
EPM Default Value: __line30value__
Description: LineKey Value

P20327
EPM Default Value: __line30label__
Description: LineKey Label

P20328
EPM Default Value: __line30acct__
Description: LineKey Account

P20329
EPM Default Value: __line30pu__
Description: LineKey PickupCode

P20330
EPM Default Value: __line31type__
Description: LineKey Type

P20630
EPM Default Value: __line31mode__
Description: LineKey Mode

P20331
EPM Default Value: __line31value__
Description: LineKey Value

P20332
EPM Default Value: __line31label__
Description: LineKey Label

P20333
EPM Default Value: __line31acct__
Description: LineKey Account

P20334
EPM Default Value: __line31pu__
Description: LineKey PickupCode

P20335
EPM Default Value: __line32type__
Description: LineKey Type

P20631
EPM Default Value: __line32mode__
Description: LineKey Mode

P20336
EPM Default Value: __line32value__
Description: LineKey Value

P20337
EPM Default Value: __line32label__
Description: LineKey Label

P20338
EPM Default Value: __line32acct__
Description: LineKey Account

P20339
EPM Default Value: __line32pu__
Description: LineKey PickupCode

P20340
EPM Default Value: __line33type__
Description: LineKey Type

P20632
EPM Default Value: __line33mode__
Description: LineKey Mode

P20341
EPM Default Value: __line33value__
Description: LineKey Value

P20342
EPM Default Value: __line33label__
Description: LineKey Label

P20343
EPM Default Value: __line33acct__
Description: LineKey Account

P20344
EPM Default Value: __line33pu__
Description: LineKey PickupCode

P20345
EPM Default Value: __line34type__
Description: LineKey Type

P20633
EPM Default Value: __line34mode__
Description: LineKey Mode

P20346
EPM Default Value: __line34value__
Description: LineKey Value

P20347
EPM Default Value: __line34label__
Description: LineKey Label

P20348
EPM Default Value: __line34acct__
Description: LineKey Account

P20349
EPM Default Value: __line34pu__
Description: LineKey PickupCode

P20350
EPM Default Value: __line35type__
Description: Linekey Type

P20634
EPM Default Value: __line35mode__
Description: LineKey Mode

P20351
EPM Default Value: __line35value__
Description: LineKey Value

P20352
EPM Default Value: __line35label__
Description: LineKey Label

P20353
EPM Default Value: __line35acct__
Description: LineKey Account

P20354
EPM Default Value: __line35pu__
Description: LineKey PickupCode

P20355
EPM Default Value: __line36type__
Description: LineKey Type

P20635
EPM Default Value: __line36mode__
Description: LineKey Mode

P20356
EPM Default Value: __line36value__
Description: LineKey Value

P20357
EPM Default Value: __line36label__
Description: LineKey Label

P20358
EPM Default Value: __line36acct__
Description: LineKey Account

P20359
EPM Default Value: __line36pu__
Description: LineKey PickupCode

P23000
EPM Default Value: __line37type__
Description: LineKey Type

P23001
EPM Default Value: __line37mode__
Description: LineKey Mode

P23002
EPM Default Value: __line37value__
Description: LineKey Value

P23003
EPM Default Value: __line37label__
Description: LineKey Label

P23004
EPM Default Value: __line37acct__
Description: LineKey Account

P23005
EPM Default Value: __line37pu__
Description: LineKey PickupCode

P23006
EPM Default Value: __line38type__
Description: LineKey Type

P23007
EPM Default Value: __line38mode__
Description: LineKey Mode

P23008
EPM Default Value: __line38value__
Description: LineKey Value

P23009
EPM Default Value: __line38label__
Description: LineKey Label

P23010
EPM Default Value: __line38acct__
Description: LineKey Account

P23011
EPM Default Value: __line38pu__
Description: LineKey PickupCode

P23012
EPM Default Value: __line39type__
Description: LineKey Type

P23013
EPM Default Value: __line39mode__
Description: LineKey Mode

P23014
EPM Default Value: __line39value__
Description: LineKey Value

P23015
EPM Default Value: __line39label__
Description: LineKey Label

P23016
EPM Default Value: __line39acct__
Description: LineKey Account

P23017
EPM Default Value: __line39pu__
Description: LineKey PickupCode

P23018
EPM Default Value: __line40type__
Description: LineKey Type

P23019
EPM Default Value: __line40mode__
Description: LineKey Mode

P23020
EPM Default Value: __line40value__
Description: LineKey Value

P23021
EPM Default Value: __line40label__
Description: LineKey Label

P23022
EPM Default Value: __line40acct__
Description: LineKey Account

P23023
EPM Default Value: __line40pu__
Description: LineKey PickupCode

P23024
EPM Default Value: __line41type__
Description: LineKey Type

P23025
EPM Default Value: __line41mode__
Description: LineKey Mode

P23026
EPM Default Value: __line41value__
Description: LineKey Value

P23027
EPM Default Value: __line41label__
Description: LineKey Label

P23028
EPM Default Value: __line41acct__
Description: LineKey Account

P23029
EPM Default Value: __line41pu__
Description: LineKey PickupCode

P23030
EPM Default Value: __line42type__
Description: LineKey Type

P23031
EPM Default Value: __line42mode__
Description: LineKey Mode

P23032
EPM Default Value: __line42value__
Description: LineKey Value

P23033
EPM Default Value: __line42label__
Description: LineKey Label

P23034
EPM Default Value: __line42acct__
Description: LineKey Account

P23035
EPM Default Value: __line42pu__
Description: LineKey PickupCode

P23036
EPM Default Value: __line43type__
Description: LineKey Type

P23037
EPM Default Value: __line43mode__
Description: LineKey Mode

P23038
EPM Default Value: __line43value__
Description: LineKey Value

P23039
EPM Default Value: __line43label__
Description: LineKey Label

P23040
EPM Default Value: __line43acct__
Description: LineKey Account

P23041
EPM Default Value: __line43pu__
Description: LineKey PickupCode

P23042
EPM Default Value: __line44type__
Description: LineKey Type

P23043
EPM Default Value: __line44mode__
Description: LineKey Mode

P23044
EPM Default Value: __line44value__
Description: LineKey Value

P23045
EPM Default Value: __line44label__
Description: LineKey Label

P23046
EPM Default Value: __line44acct__
Description: LineKey Account

P23047
EPM Default Value: __line44pu__
Description: LineKey PickupCode

P23048
EPM Default Value: __line45type__
Description: LineKey Type

P23049
EPM Default Value: __line45mode__
Description: LineKey Mode

P23050
EPM Default Value: __line45value__
Description: LineKey Value

P23051
EPM Default Value: __line45label__
Description: LineKey Label

P23052
EPM Default Value: __line45acct__
Description: LineKey Account

P23053
EPM Default Value: __line45pu__
Description: LineKey PickupCode

P42200
EPM Default Value: __b1type__
Description: memkey_type_01

P42300
EPM Default Value: __b1value__
Description: memkey_value_01

P42400
EPM Default Value: __b1acct__
Description: memkey_account_01

P42500
EPM Default Value: __b1pu__
Description: memkey_pickup_01

P42201
EPM Default Value: __b2type__
Description: memkey_type_02

P42301
EPM Default Value: __b2value__
Description: memkey_value_02

P42401
EPM Default Value: __b2acct__
Description: memkey_account_02

P42501
EPM Default Value: __b2pu__
Description: memkey_pickup_02

P42202
EPM Default Value: __b3type__
Description: memkey_type_03

P42302
EPM Default Value: __b3value__
Description: memkey_value_03

P42402
EPM Default Value: __b3acct__
Description: memkey_account_03

P42502
EPM Default Value: __b3pu__
Description: memkey_pickup_03

P42203
EPM Default Value: __b4type__
Description: memkey_type_04

P42303
EPM Default Value: __b4value__
Description: memkey_value_04

P42403
EPM Default Value: __b4acct__
Description: memkey_account_04

P42503
EPM Default Value: __b4pu__
Description: memkey_pickup_04

P42204
EPM Default Value: __b5type__
Description: memkey_type_05

P42304
EPM Default Value: __b5value__
Description: memkey_value_05

P42404
EPM Default Value: __b5acct__
Description: memkey_account_05

P42504
EPM Default Value: __b5pu__
Description: memkey_pickup_05

P42205
EPM Default Value: __b6type__
Description: memkey_type_06

P42305
EPM Default Value: __b6value__
Description: memkey_value_06

P42405
EPM Default Value: __b6acct__
Description: memkey_account_06

P42505
EPM Default Value: __b6pu__
Description: memkey_pickup_06

P42206
EPM Default Value: __b7type__
Description: memkey_type_07

P42306
EPM Default Value: __b7value__
Description: memkey_value_07

P42406
EPM Default Value: __b7acct__
Description: memkey_account_07

P42506
EPM Default Value: __b7pu__
Description: memkey_pickup_07

P42207
EPM Default Value: __b8type__
Description: memkey_type_08

P42307
EPM Default Value: __b8value__
Description: memkey_value_08

P42407
EPM Default Value: __b8acct__
Description: memkey_account_08

P42507
EPM Default Value: __b8pu__
Description: memkey_pickup_08

P42208
EPM Default Value: __b9type__
Description: memkey_type_09

P42308
EPM Default Value: __b9value__
Description: memkey_value_09

P42408
EPM Default Value: __b9acct__
Description: memkey_account_09

P42508
EPM Default Value: __b9pu__
Description: memkey_pickup_09

P42209
EPM Default Value: __b10type__
Description: memkey_type_10

P42309
EPM Default Value: __b10value__
Description: memkey_value_10

P42409
EPM Default Value: __b10acct__
Description: memkey_account_10

P42509
EPM Default Value: __b10pu__
Description: memkey_pickup_10

P43200
EPM Default Value: __sk1type__
Description: softkey_type_01

P43300
EPM Default Value: __sk1acct__
Description: softkey_account_01

P43400
EPM Default Value: __sk1value__
Description: softkey_value_01

P43201
EPM Default Value: __sk2type__
Description: softkey_type_02

P43301
EPM Default Value: __sk2acct__
Description: softkey_account_02

P43401
EPM Default Value: __sk2value__
Description: softkey_value_02

P43202
EPM Default Value: __sk3type__
Description: softkey_type_03

P43302
EPM Default Value: __sk3acct__
Description: softkey_account_03

P43402
EPM Default Value: __sk3value__
Description: softkey_value_03

P43203
EPM Default Value: __sk4type__
Description: softkey_type_04

P43303
EPM Default Value: __sk4acct__
Description: softkey_account_04

P43403
EPM Default Value: __sk4value__
Description: softkey_value_04

P60000
EPM Default Value: __exp11type__
Description: Expansion Module 1 key 1type

P60001
EPM Default Value: __exp11value__
Description: Expansion Module 1 key 1value

P60002
EPM Default Value: __exp11label__
Description: Expansion Module 1 key 1label

P60003
EPM Default Value: __exp11acct__
Description: Expansion Module 1 key 1account

P60004
EPM Default Value: __exp11pu__
Description: Expansion Module 1 key 1pickup up

P60005
EPM Default Value: __exp12type__
Description: Expansion Module 1 key 2type

P60006
EPM Default Value: __exp12value__
Description: Expansion Module 1 key 2value

P60007
EPM Default Value: __exp12label__
Description: Expansion Module 1 key 2label

P60008
EPM Default Value: __exp12acct__
Description: Expansion Module 1 key 2account

P60009
EPM Default Value: __exp12pu__
Description: Expansion Module 1 key 2pickup up

P60010
EPM Default Value: __exp13type__
Description: Expansion Module 1 key 3type

P60011
EPM Default Value: __exp13value__
Description: Expansion Module 1 key 3value

P60012
EPM Default Value: __exp13label__
Description: Expansion Module 1 key 3label

P60013
EPM Default Value: __exp13acct__
Description: Expansion Module 1 key 3account

P60014
EPM Default Value: __exp13pu__
Description: Expansion Module 1 key 3pickup up

P60015
EPM Default Value: __exp14type__
Description: Expansion Module 1 key 4type

P60016
EPM Default Value: __exp14value__
Description: Expansion Module 1 key 4value

P60017
EPM Default Value: __exp14label__
Description: Expansion Module 1 key 4label

P60018
EPM Default Value: __exp14acct__
Description: Expansion Module 1 key 4account

P60019
EPM Default Value: __exp14pu__
Description: Expansion Module 1 key 4pickup up

P60020
EPM Default Value: __exp15type__
Description: Expansion Module 1 key 5type

P60021
EPM Default Value: __exp15value__
Description: Expansion Module 1 key 5value

P60022
EPM Default Value: __exp15label__
Description: Expansion Module 1 key 5label

P60023
EPM Default Value: __exp15acct__
Description: Expansion Module 1 key 5account

P60024
EPM Default Value: __exp15pu__
Description: Expansion Module 1 key 5pickup up

P60025
EPM Default Value: __exp16type__
Description: Expansion Module 1 key 6type

P60026
EPM Default Value: __exp16value__
Description: Expansion Module 1 key 6value

P60027
EPM Default Value: __exp16label__
Description: Expansion Module 1 key 6label

P60028
EPM Default Value: __exp16acct__
Description: Expansion Module 1 key 6account

P60029
EPM Default Value: __exp16pu__
Description: Expansion Module 1 key 6pickup up

P60030
EPM Default Value: __exp17type__
Description: Expansion Module 1 key 7type

P60031
EPM Default Value: __exp17value__
Description: Expansion Module 1 key 7value

P60032
EPM Default Value: __exp17label__
Description: Expansion Module 1 key 7label

P60033
EPM Default Value: __exp17acct__
Description: Expansion Module 1 key 7account

P60034
EPM Default Value: __exp17pu__
Description: Expansion Module 1 key 7pickup up

P60035
EPM Default Value: __exp18type__
Description: Expansion Module 1 key 8type

P60036
EPM Default Value: __exp18value__
Description: Expansion Module 1 key 8value

P60037
EPM Default Value: __exp18label__
Description: Expansion Module 1 key 8label

P60038
EPM Default Value: __exp18acct__
Description: Expansion Module 1 key 8account

P60039
EPM Default Value: __exp18pu__
Description: Expansion Module 1 key 8pickup up

P60040
EPM Default Value: __exp19type__
Description: Expansion Module 1 key 9type

P60041
EPM Default Value: __exp19value__
Description: Expansion Module 1 key 9value

P60042
EPM Default Value: __exp19label__
Description: Expansion Module 1 key 9label

P60043
EPM Default Value: __exp19acct__
Description: Expansion Module 1 key 9account

P60044
EPM Default Value: __exp19pu__
Description: Expansion Module 1 key 9pickup up

P60045
EPM Default Value: __exp110type__
Description: Expansion Module 1 key 10type

P60046
EPM Default Value: __exp110value__
Description: Expansion Module 1 key 10value

P60047
EPM Default Value: __exp110label__
Description: Expansion Module 1 key 10label

P60048
EPM Default Value: __exp110acct__
Description: Expansion Module 1 key 10account

P60049
EPM Default Value: __exp110pu__
Description: Expansion Module 1 key 10pickup up

P60050
EPM Default Value: __exp111type__
Description: Expansion Module 1 key 11type

P60051
EPM Default Value: __exp111value__
Description: Expansion Module 1 key 11value

P60052
EPM Default Value: __exp111label__
Description: Expansion Module 1 key 11label

P60053
EPM Default Value: __exp111acct__
Description: Expansion Module 1 key 11account

P60054
EPM Default Value: __exp111pu__
Description: Expansion Module 1 key 11pickup up

P60055
EPM Default Value: __exp112type__
Description: Expansion Module 1 key 12type

P60056
EPM Default Value: __exp112value__
Description: Expansion Module 1 key 12value

P60057
EPM Default Value: __exp112label__
Description: Expansion Module 1 key 12label

P60058
EPM Default Value: __exp112acct__
Description: Expansion Module 1 key 12account

P60059
EPM Default Value: __exp112pu__
Description: Expansion Module 1 key 12pickup up

P60060
EPM Default Value: __exp113type__
Description: Expansion Module 1 key 13type

P60061
EPM Default Value: __exp113value__
Description: Expansion Module 1 key 13value

P60062
EPM Default Value: __exp113label__
Description: Expansion Module 1 key 13label

P60063
EPM Default Value: __exp113acct__
Description: Expansion Module 1 key 13account

P60064
EPM Default Value: __exp113pu__
Description: Expansion Module 1 key 13pickup up

P60065
EPM Default Value: __exp114type__
Description: Expansion Module 1 key 14type

P60066
EPM Default Value: __exp114value__
Description: Expansion Module 1 key 14value

P60067
EPM Default Value: __exp114label__
Description: Expansion Module 1 key 14label

P60068
EPM Default Value: __exp114acct__
Description: Expansion Module 1 key 14account

P60069
EPM Default Value: __exp114pu__
Description: Expansion Module 1 key 14pickup up

P60070
EPM Default Value: __exp115type__
Description: Expansion Module 1 key 15type

P60071
EPM Default Value: __exp115value__
Description: Expansion Module 1 key 15value

P60072
EPM Default Value: __exp115label__
Description: Expansion Module 1 key 15label

P60073
EPM Default Value: __exp115acct__
Description: Expansion Module 1 key 15account

P60074
EPM Default Value: __exp115pu__
Description: Expansion Module 1 key 15pickup up

P60075
EPM Default Value: __exp116type__
Description: Expansion Module 1 key 16type

P60076
EPM Default Value: __exp116value__
Description: Expansion Module 1 key 16value

P60077
EPM Default Value: __exp116label__
Description: Expansion Module 1 key 16label

P60078
EPM Default Value: __exp116acct__
Description: Expansion Module 1 key 16account

P60079
EPM Default Value: __exp116pu__
Description: Expansion Module 1 key 16pickup up

P60080
EPM Default Value: __exp117type__
Description: Expansion Module 1 key 17type

P60081
EPM Default Value: __exp117value__
Description: Expansion Module 1 key 17value

P60082
EPM Default Value: __exp117label__
Description: Expansion Module 1 key 17label

P60083
EPM Default Value: __exp117acct__
Description: Expansion Module 1 key 17account

P60084
EPM Default Value: __exp117pu__
Description: Expansion Module 1 key 17pickup up

P60085
EPM Default Value: __exp118type__
Description: Expansion Module 1 key 18type

P60086
EPM Default Value: __exp118value__
Description: Expansion Module 1 key 18value

P60087
EPM Default Value: __exp118label__
Description: Expansion Module 1 key 18label

P60088
EPM Default Value: __exp118acct__
Description: Expansion Module 1 key 18account

P60089
EPM Default Value: __exp118pu__
Description: Expansion Module 1 key 18pickup up

P60090
EPM Default Value: __exp119type__
Description: Expansion Module 1 key 19type

P60091
EPM Default Value: __exp119value__
Description: Expansion Module 1 key 19value

P60092
EPM Default Value: __exp119label__
Description: Expansion Module 1 key 19label

P60093
EPM Default Value: __exp119acct__
Description: Expansion Module 1 key 19account

P60094
EPM Default Value: __exp119pu__
Description: Expansion Module 1 key 19pickup up

P60095
EPM Default Value: __exp120type__
Description: Expansion Module 1 key 20type

P60096
EPM Default Value: __exp120value__
Description: Expansion Module 1 key 20value

P60097
EPM Default Value: __exp120label__
Description: Expansion Module 1 key 20label

P60098
EPM Default Value: __exp120acct__
Description: Expansion Module 1 key 20account

P60099
EPM Default Value: __exp120pu__
Description: Expansion Module 1 key 20pickup up

P60100
EPM Default Value: __exp121type__
Description: Expansion Module 1 key 21type

P60101
EPM Default Value: __exp121value__
Description: Expansion Module 1 key 21value

P60102
EPM Default Value: __exp121label__
Description: Expansion Module 1 key 21label

P60103
EPM Default Value: __exp121acct__
Description: Expansion Module 1 key 21account

P60104
EPM Default Value: __exp121pu__
Description: Expansion Module 1 key 21pickup up

P60105
EPM Default Value: __exp122type__
Description: Expansion Module 1 key 22type

P60106
EPM Default Value: __exp122value__
Description: Expansion Module 1 key 22value

P60107
EPM Default Value: __exp122label__
Description: Expansion Module 1 key 22label

P60108
EPM Default Value: __exp122acct__
Description: Expansion Module 1 key 22account

P60109
EPM Default Value: __exp122pu__
Description: Expansion Module 1 key 22pickup up

P60110
EPM Default Value: __exp123type__
Description: Expansion Module 1 key 23type

P60111
EPM Default Value: __exp123value__
Description: Expansion Module 1 key 23value

P60112
EPM Default Value: __exp123label__
Description: Expansion Module 1 key 23label

P60113
EPM Default Value: __exp123acct__
Description: Expansion Module 1 key 23account

P60114
EPM Default Value: __exp123pu__
Description: Expansion Module 1 key 23pickup up

P60115
EPM Default Value: __exp124type__
Description: Expansion Module 1 key 24type

P60116
EPM Default Value: __exp124value__
Description: Expansion Module 1 key 24value

P60117
EPM Default Value: __exp124label__
Description: Expansion Module 1 key 24label

P60118
EPM Default Value: __exp124acct__
Description: Expansion Module 1 key 24account

P60119
EPM Default Value: __exp124pu__
Description: Expansion Module 1 key 24pickup up

P60120
EPM Default Value: __exp125type__
Description: Expansion Module 1 key 25type

P60121
EPM Default Value: __exp125value__
Description: Expansion Module 1 key 25value

P60122
EPM Default Value: __exp125label__
Description: Expansion Module 1 key 25label

P60123
EPM Default Value: __exp125acct__
Description: Expansion Module 1 key 25account

P60124
EPM Default Value: __exp125pu__
Description: Expansion Module 1 key 25pickup up

P60125
EPM Default Value: __exp126type__
Description: Expansion Module 1 key 26type

P60126
EPM Default Value: __exp126value__
Description: Expansion Module 1 key 26value

P60127
EPM Default Value: __exp126label__
Description: Expansion Module 1 key 26label

P60128
EPM Default Value: __exp126acct__
Description: Expansion Module 1 key 26account

P60129
EPM Default Value: __exp126pu__
Description: Expansion Module 1 key 26pickup up

P60130
EPM Default Value: __exp127type__
Description: Expansion Module 1 key 27type

P60131
EPM Default Value: __exp127value__
Description: Expansion Module 1 key 27value

P60132
EPM Default Value: __exp127label__
Description: Expansion Module 1 key 27label

P60133
EPM Default Value: __exp127acct__
Description: Expansion Module 1 key 27account

P60134
EPM Default Value: __exp127pu__
Description: Expansion Module 1 key 27pickup up

P60135
EPM Default Value: __exp128type__
Description: Expansion Module 1 key 28type

P60136
EPM Default Value: __exp128value__
Description: Expansion Module 1 key 28value

P60137
EPM Default Value: __exp128label__
Description: Expansion Module 1 key 28label

P60138
EPM Default Value: __exp128acct__
Description: Expansion Module 1 key 28account

P60139
EPM Default Value: __exp128pu__
Description: Expansion Module 1 key 28pickup up

P60140
EPM Default Value: __exp129type__
Description: Expansion Module 1 key 29type

P60141
EPM Default Value: __exp129value__
Description: Expansion Module 1 key 29value

P60142
EPM Default Value: __exp129label__
Description: Expansion Module 1 key 29label

P60143
EPM Default Value: __exp129acct__
Description: Expansion Module 1 key 29account

P60144
EPM Default Value: __exp129pu__
Description: Expansion Module 1 key 29pickup up

P60145
EPM Default Value: __exp130type__
Description: Expansion Module 1 key 30type

P60146
EPM Default Value: __exp130value__
Description: Expansion Module 1 key 30value

P60147
EPM Default Value: __exp130label__
Description: Expansion Module 1 key 30label

P60148
EPM Default Value: __exp130acct__
Description: Expansion Module 1 key 30account

P60149
EPM Default Value: __exp130pu__
Description: Expansion Module 1 key 30pickup up

P60150
EPM Default Value: __exp131type__
Description: Expansion Module 1 key 31type

P60151
EPM Default Value: __exp131value__
Description: Expansion Module 1 key 31value

P60152
EPM Default Value: __exp131label__
Description: Expansion Module 1 key 31label

P60153
EPM Default Value: __exp131acct__
Description: Expansion Module 1 key 31account

P60154
EPM Default Value: __exp131pu__
Description: Expansion Module 1 key 31pickup up

P60155
EPM Default Value: __exp132type__
Description: Expansion Module 1 key 32type

P60156
EPM Default Value: __exp132value__
Description: Expansion Module 1 key 32value

P60157
EPM Default Value: __exp132label__
Description: Expansion Module 1 key 32label

P60158
EPM Default Value: __exp132acct__
Description: Expansion Module 1 key 32account

P60159
EPM Default Value: __exp132pu__
Description: Expansion Module 1 key 32pickup up

P60160
EPM Default Value: __exp133type__
Description: Expansion Module 1 key 33type

P60161
EPM Default Value: __exp133value__
Description: Expansion Module 1 key 33value

P60162
EPM Default Value: __exp133label__
Description: Expansion Module 1 key 33label

P60163
EPM Default Value: __exp133acct__
Description: Expansion Module 1 key 33account

P60164
EPM Default Value: __exp133pu__
Description: Expansion Module 1 key 33pickup up

P60165
EPM Default Value: __exp134type__
Description: Expansion Module 1 key 34type

P60166
EPM Default Value: __exp134value__
Description: Expansion Module 1 key 34value

P60167
EPM Default Value: __exp134label__
Description: Expansion Module 1 key 34label

P60168
EPM Default Value: __exp134acct__
Description: Expansion Module 1 key 34account

P60169
EPM Default Value: __exp134pu__
Description: Expansion Module 1 key 34pickup up

P60170
EPM Default Value: __exp135type__
Description: Expansion Module 1 key 35type

P60171
EPM Default Value: __exp135value__
Description: Expansion Module 1 key 35value

P60172
EPM Default Value: __exp135label__
Description: Expansion Module 1 key 35label

P60173
EPM Default Value: __exp135acct__
Description: Expansion Module 1 key 35account

P60174
EPM Default Value: __exp135pu__
Description: Expansion Module 1 key 35pickup up

P60175
EPM Default Value: __exp136type__
Description: Expansion Module 1 key 36type

P60176
EPM Default Value: __exp136value__
Description: Expansion Module 1 key 36value

P60177
EPM Default Value: __exp136label__
Description: Expansion Module 1 key 36label

P60178
EPM Default Value: __exp136acct__
Description: Expansion Module 1 key 36account

P60179
EPM Default Value: __exp136pu__
Description: Expansion Module 1 key 36pickup up

P60180
EPM Default Value: __exp137type__
Description: Expansion Module 1 key 37type

P60181
EPM Default Value: __exp137value__
Description: Expansion Module 1 key 37value

P60182
EPM Default Value: __exp137label__
Description: Expansion Module 1 key 37label

P60183
EPM Default Value: __exp137acct__
Description: Expansion Module 1 key 37account

P60184
EPM Default Value: __exp137pu__
Description: Expansion Module 1 key 37pickup up

P60185
EPM Default Value: __exp138type__
Description: Expansion Module 1 key 38type

P60186
EPM Default Value: __exp138value__
Description: Expansion Module 1 key 38value

P60187
EPM Default Value: __exp138label__
Description: Expansion Module 1 key 38label

P60188
EPM Default Value: __exp138acct__
Description: Expansion Module 1 key 38account

P60189
EPM Default Value: __exp138pu__
Description: Expansion Module 1 key 38pickup up

P60190
EPM Default Value: __exp139type__
Description: Expansion Module 1 key 39type

P60191
EPM Default Value: __exp139value__
Description: Expansion Module 1 key 39value

P60192
EPM Default Value: __exp139label__
Description: Expansion Module 1 key 39label

P60193
EPM Default Value: __exp139acct__
Description: Expansion Module 1 key 39account

P60194
EPM Default Value: __exp139pu__
Description: Expansion Module 1 key 39pickup up

P60195
EPM Default Value: __exp140type__
Description: Expansion Module 1 key 40type

P60196
EPM Default Value: __exp140value__
Description: Expansion Module 1 key 40value

P60197
EPM Default Value: __exp140label__
Description: Expansion Module 1 key 40label

P60198
EPM Default Value: __exp140acct__
Description: Expansion Module 1 key 40account

P60199
EPM Default Value: __exp140pu__
Description: Expansion Module 1 key 40pickup up

P61000
EPM Default Value: __exp21type__
Description: Expansion Module 6 key 1type

P61001
EPM Default Value: __exp21value__
Description: Expansion Module 6 key 1value

P61002
EPM Default Value: __exp21label__
Description: Expansion Module 6 key 1label

P61003
EPM Default Value: __exp21acct__
Description: Expansion Module 6 key 1account

P61004
EPM Default Value: __exp21pu__
Description: Expansion Module 6 key 1pickup up

P61005
EPM Default Value: __exp22type__
Description: Expansion Module 6 key 2type

P61006
EPM Default Value: __exp22value__
Description: Expansion Module 6 key 2value

P61007
EPM Default Value: __exp22label__
Description: Expansion Module 6 key 2label

P61008
EPM Default Value: __exp22acct__
Description: Expansion Module 6 key 2account

P61009
EPM Default Value: __exp22pu__
Description: Expansion Module 6 key 2pickup up

P61010
EPM Default Value: __exp23type__
Description: Expansion Module 6 key 3type

P61011
EPM Default Value: __exp23value__
Description: Expansion Module 6 key 3value

P61012
EPM Default Value: __exp23label__
Description: Expansion Module 6 key 3label

P61013
EPM Default Value: __exp23acct__
Description: Expansion Module 6 key 3account

P61014
EPM Default Value: __exp23pu__
Description: Expansion Module 6 key 3pickup up

P61015
EPM Default Value: __exp24type__
Description: Expansion Module 6 key 4type

P61016
EPM Default Value: __exp24value__
Description: Expansion Module 6 key 4value

P61017
EPM Default Value: __exp24label__
Description: Expansion Module 6 key 4label

P61018
EPM Default Value: __exp24acct__
Description: Expansion Module 6 key 4account

P61019
EPM Default Value: __exp24pu__
Description: Expansion Module 6 key 4pickup up

P61020
EPM Default Value: __exp25type__
Description: Expansion Module 6 key 5type

P61021
EPM Default Value: __exp25value__
Description: Expansion Module 6 key 5value

P61022
EPM Default Value: __exp25label__
Description: Expansion Module 6 key 5label

P61023
EPM Default Value: __exp25acct__
Description: Expansion Module 6 key 5account

P61024
EPM Default Value: __exp25pu__
Description: Expansion Module 6 key 5pickup up

P61025
EPM Default Value: __exp26type__
Description: Expansion Module 6 key 6type

P61026
EPM Default Value: __exp26value__
Description: Expansion Module 6 key 6value

P61027
EPM Default Value: __exp26label__
Description: Expansion Module 6 key 6label

P61028
EPM Default Value: __exp26acct__
Description: Expansion Module 6 key 6account

P61029
EPM Default Value: __exp26pu__
Description: Expansion Module 6 key 6pickup up

P61030
EPM Default Value: __exp27type__
Description: Expansion Module 6 key 7type

P61031
EPM Default Value: __exp27value__
Description: Expansion Module 6 key 7value

P61032
EPM Default Value: __exp27label__
Description: Expansion Module 6 key 7label

P61033
EPM Default Value: __exp27acct__
Description: Expansion Module 6 key 7account

P61034
EPM Default Value: __exp27pu__
Description: Expansion Module 6 key 7pickup up

P61035
EPM Default Value: __exp28type__
Description: Expansion Module 6 key 8type

P61036
EPM Default Value: __exp28value__
Description: Expansion Module 6 key 8value

P61037
EPM Default Value: __exp28label__
Description: Expansion Module 6 key 8label

P61038
EPM Default Value: __exp28acct__
Description: Expansion Module 6 key 8account

P61039
EPM Default Value: __exp28pu__
Description: Expansion Module 6 key 8pickup up

P61040
EPM Default Value: __exp29type__
Description: Expansion Module 6 key 9type

P61041
EPM Default Value: __exp29value__
Description: Expansion Module 6 key 9value

P61042
EPM Default Value: __exp29label__
Description: Expansion Module 6 key 9label

P61043
EPM Default Value: __exp29acct__
Description: Expansion Module 6 key 9account

P61044
EPM Default Value: __exp29pu__
Description: Expansion Module 6 key 9pickup up

P61045
EPM Default Value: __exp210type__
Description: Expansion Module 6 key 10type

P61046
EPM Default Value: __exp210value__
Description: Expansion Module 6 key 10value

P61047
EPM Default Value: __exp210label__
Description: Expansion Module 6 key 10label

P61048
EPM Default Value: __exp210acct__
Description: Expansion Module 6 key 10account

P61049
EPM Default Value: __exp210pu__
Description: Expansion Module 6 key 10pickup up

P61050
EPM Default Value: __exp211type__
Description: Expansion Module 6 key 11type

P61051
EPM Default Value: __exp211value__
Description: Expansion Module 6 key 11value

P61052
EPM Default Value: __exp211label__
Description: Expansion Module 6 key 11label

P61053
EPM Default Value: __exp211acct__
Description: Expansion Module 6 key 11account

P61054
EPM Default Value: __exp211pu__
Description: Expansion Module 6 key 11pickup up

P61055
EPM Default Value: __exp212type__
Description: Expansion Module 6 key 12type

P61056
EPM Default Value: __exp212value__
Description: Expansion Module 6 key 12value

P61057
EPM Default Value: __exp212label__
Description: Expansion Module 6 key 12label

P61058
EPM Default Value: __exp212acct__
Description: Expansion Module 6 key 12account

P61059
EPM Default Value: __exp212pu__
Description: Expansion Module 6 key 12pickup up

P61060
EPM Default Value: __exp213type__
Description: Expansion Module 6 key 13type

P61061
EPM Default Value: __exp213value__
Description: Expansion Module 6 key 13value

P61062
EPM Default Value: __exp213label__
Description: Expansion Module 6 key 13label

P61063
EPM Default Value: __exp213acct__
Description: Expansion Module 6 key 13account

P61064
EPM Default Value: __exp213pu__
Description: Expansion Module 6 key 13pickup up

P61065
EPM Default Value: __exp214type__
Description: Expansion Module 6 key 14type

P61066
EPM Default Value: __exp214value__
Description: Expansion Module 6 key 14value

P61067
EPM Default Value: __exp214label__
Description: Expansion Module 6 key 14label

P61068
EPM Default Value: __exp214acct__
Description: Expansion Module 6 key 14account

P61069
EPM Default Value: __exp214pu__
Description: Expansion Module 6 key 14pickup up

P61070
EPM Default Value: __exp215type__
Description: Expansion Module 6 key 15type

P61071
EPM Default Value: __exp215value__
Description: Expansion Module 6 key 15value

P61072
EPM Default Value: __exp215label__
Description: Expansion Module 6 key 15label

P61073
EPM Default Value: __exp215acct__
Description: Expansion Module 6 key 15account

P61074
EPM Default Value: __exp215pu__
Description: Expansion Module 6 key 15pickup up

P61075
EPM Default Value: __exp216type__
Description: Expansion Module 6 key 16type

P61076
EPM Default Value: __exp216value__
Description: Expansion Module 6 key 16value

P61077
EPM Default Value: __exp216label__
Description: Expansion Module 6 key 16label

P61078
EPM Default Value: __exp216acct__
Description: Expansion Module 6 key 16account

P61079
EPM Default Value: __exp216pu__
Description: Expansion Module 6 key 16pickup up

P61080
EPM Default Value: __exp217type__
Description: Expansion Module 6 key 17type

P61081
EPM Default Value: __exp217value__
Description: Expansion Module 6 key 17value

P61082
EPM Default Value: __exp217label__
Description: Expansion Module 6 key 17label

P61083
EPM Default Value: __exp217acct__
Description: Expansion Module 6 key 17account

P61084
EPM Default Value: __exp217pu__
Description: Expansion Module 6 key 17pickup up

P61085
EPM Default Value: __exp218type__
Description: Expansion Module 6 key 18type

P61086
EPM Default Value: __exp218value__
Description: Expansion Module 6 key 18value

P61087
EPM Default Value: __exp218label__
Description: Expansion Module 6 key 18label

P61088
EPM Default Value: __exp218acct__
Description: Expansion Module 6 key 18account

P61089
EPM Default Value: __exp218pu__
Description: Expansion Module 6 key 18pickup up

P61090
EPM Default Value: __exp219type__
Description: Expansion Module 6 key 19type

P61091
EPM Default Value: __exp219value__
Description: Expansion Module 6 key 19value

P61092
EPM Default Value: __exp219label__
Description: Expansion Module 6 key 19label

P61093
EPM Default Value: __exp219acct__
Description: Expansion Module 6 key 19account

P61094
EPM Default Value: __exp219pu__
Description: Expansion Module 6 key 19pickup up

P61095
EPM Default Value: __exp220type__
Description: Expansion Module 6 key 20type

P61096
EPM Default Value: __exp220value__
Description: Expansion Module 6 key 20value

P61097
EPM Default Value: __exp220label__
Description: Expansion Module 6 key 20label

P61098
EPM Default Value: __exp220acct__
Description: Expansion Module 6 key 20account

P61099
EPM Default Value: __exp220pu__
Description: Expansion Module 6 key 20pickup up

P61100
EPM Default Value: __exp221type__
Description: Expansion Module 6 key 21type

P61101
EPM Default Value: __exp221value__
Description: Expansion Module 6 key 21value

P61102
EPM Default Value: __exp221label__
Description: Expansion Module 6 key 21label

P61103
EPM Default Value: __exp221acct__
Description: Expansion Module 6 key 21account

P61104
EPM Default Value: __exp221pu__
Description: Expansion Module 6 key 21pickup up

P61105
EPM Default Value: __exp222type__
Description: Expansion Module 6 key 22type

P61106
EPM Default Value: __exp222value__
Description: Expansion Module 6 key 22value

P61107
EPM Default Value: __exp222label__
Description: Expansion Module 6 key 22label

P61108
EPM Default Value: __exp222acct__
Description: Expansion Module 6 key 22account

P61109
EPM Default Value: __exp222pu__
Description: Expansion Module 6 key 22pickup up

P61110
EPM Default Value: __exp223type__
Description: Expansion Module 6 key 23type

P61111
EPM Default Value: __exp223value__
Description: Expansion Module 6 key 23value

P61112
EPM Default Value: __exp223label__
Description: Expansion Module 6 key 23label

P61113
EPM Default Value: __exp223acct__
Description: Expansion Module 6 key 23account

P61114
EPM Default Value: __exp223pu__
Description: Expansion Module 6 key 23pickup up

P61115
EPM Default Value: __exp224type__
Description: Expansion Module 6 key 24type

P61116
EPM Default Value: __exp224value__
Description: Expansion Module 6 key 24value

P61117
EPM Default Value: __exp224label__
Description: Expansion Module 6 key 24label

P61118
EPM Default Value: __exp224acct__
Description: Expansion Module 6 key 24account

P61119
EPM Default Value: __exp224pu__
Description: Expansion Module 6 key 24pickup up

P61120
EPM Default Value: __exp225type__
Description: Expansion Module 6 key 25type

P61121
EPM Default Value: __exp225value__
Description: Expansion Module 6 key 25value

P61122
EPM Default Value: __exp225label__
Description: Expansion Module 6 key 25label

P61123
EPM Default Value: __exp225acct__
Description: Expansion Module 6 key 25account

P61124
EPM Default Value: __exp225pu__
Description: Expansion Module 6 key 25pickup up

P61125
EPM Default Value: __exp226type__
Description: Expansion Module 6 key 26type

P61126
EPM Default Value: __exp226value__
Description: Expansion Module 6 key 26value

P61127
EPM Default Value: __exp226label__
Description: Expansion Module 6 key 26label

P61128
EPM Default Value: __exp226acct__
Description: Expansion Module 6 key 26account

P61129
EPM Default Value: __exp226pu__
Description: Expansion Module 6 key 26pickup up

P61130
EPM Default Value: __exp227type__
Description: Expansion Module 6 key 27type

P61131
EPM Default Value: __exp227value__
Description: Expansion Module 6 key 27value

P61132
EPM Default Value: __exp227label__
Description: Expansion Module 6 key 27label

P61133
EPM Default Value: __exp227acct__
Description: Expansion Module 6 key 27account

P61134
EPM Default Value: __exp227pu__
Description: Expansion Module 6 key 27pickup up

P61135
EPM Default Value: __exp228type__
Description: Expansion Module 6 key 28type

P61136
EPM Default Value: __exp228value__
Description: Expansion Module 6 key 28value

P61137
EPM Default Value: __exp228label__
Description: Expansion Module 6 key 28label

P61138
EPM Default Value: __exp228acct__
Description: Expansion Module 6 key 28account

P61139
EPM Default Value: __exp228pu__
Description: Expansion Module 6 key 28pickup up

P61140
EPM Default Value: __exp229type__
Description: Expansion Module 6 key 29type

P61141
EPM Default Value: __exp229value__
Description: Expansion Module 6 key 29value

P61142
EPM Default Value: __exp229label__
Description: Expansion Module 6 key 29label

P61143
EPM Default Value: __exp229acct__
Description: Expansion Module 6 key 29account

P61144
EPM Default Value: __exp229pu__
Description: Expansion Module 6 key 29pickup up

P61145
EPM Default Value: __exp230type__
Description: Expansion Module 6 key 30type

P61146
EPM Default Value: __exp230value__
Description: Expansion Module 6 key 30value

P61147
EPM Default Value: __exp230label__
Description: Expansion Module 6 key 30label

P61148
EPM Default Value: __exp230acct__
Description: Expansion Module 6 key 30account

P61149
EPM Default Value: __exp230pu__
Description: Expansion Module 6 key 30pickup up

P61150
EPM Default Value: __exp231type__
Description: Expansion Module 6 key 31type

P61151
EPM Default Value: __exp231value__
Description: Expansion Module 6 key 31value

P61152
EPM Default Value: __exp231label__
Description: Expansion Module 6 key 31label

P61153
EPM Default Value: __exp231acct__
Description: Expansion Module 6 key 31account

P61154
EPM Default Value: __exp231pu__
Description: Expansion Module 6 key 31pickup up

P61155
EPM Default Value: __exp232type__
Description: Expansion Module 6 key 32type

P61156
EPM Default Value: __exp232value__
Description: Expansion Module 6 key 32value

P61157
EPM Default Value: __exp232label__
Description: Expansion Module 6 key 32label

P61158
EPM Default Value: __exp232acct__
Description: Expansion Module 6 key 32account

P61159
EPM Default Value: __exp232pu__
Description: Expansion Module 6 key 32pickup up

P61160
EPM Default Value: __exp233type__
Description: Expansion Module 6 key 33type

P61161
EPM Default Value: __exp233value__
Description: Expansion Module 6 key 33value

P61162
EPM Default Value: __exp233label__
Description: Expansion Module 6 key 33label

P61163
EPM Default Value: __exp233acct__
Description: Expansion Module 6 key 33account

P61164
EPM Default Value: __exp233pu__
Description: Expansion Module 6 key 33pickup up

P61165
EPM Default Value: __exp234type__
Description: Expansion Module 6 key 34type

P61166
EPM Default Value: __exp234value__
Description: Expansion Module 6 key 34value

P61167
EPM Default Value: __exp234label__
Description: Expansion Module 6 key 34label

P61168
EPM Default Value: __exp234acct__
Description: Expansion Module 6 key 34account

P61169
EPM Default Value: __exp234pu__
Description: Expansion Module 6 key 34pickup up

P61170
EPM Default Value: __exp235type__
Description: Expansion Module 6 key 35type

P61171
EPM Default Value: __exp235value__
Description: Expansion Module 6 key 35value

P61172
EPM Default Value: __exp235label__
Description: Expansion Module 6 key 35label

P61173
EPM Default Value: __exp235acct__
Description: Expansion Module 6 key 35account

P61174
EPM Default Value: __exp235pu__
Description: Expansion Module 6 key 35pickup up

P61175
EPM Default Value: __exp236type__
Description: Expansion Module 6 key 36type

P61176
EPM Default Value: __exp236value__
Description: Expansion Module 6 key 36value

P61177
EPM Default Value: __exp236label__
Description: Expansion Module 6 key 36label

P61178
EPM Default Value: __exp236acct__
Description: Expansion Module 6 key 36account

P61179
EPM Default Value: __exp236pu__
Description: Expansion Module 6 key 36pickup up

P61180
EPM Default Value: __exp237type__
Description: Expansion Module 6 key 37type

P61181
EPM Default Value: __exp237value__
Description: Expansion Module 6 key 37value

P61182
EPM Default Value: __exp237label__
Description: Expansion Module 6 key 37label

P61183
EPM Default Value: __exp237acct__
Description: Expansion Module 6 key 37account

P61184
EPM Default Value: __exp237pu__
Description: Expansion Module 6 key 37pickup up

P61185
EPM Default Value: __exp238type__
Description: Expansion Module 6 key 38type

P61186
EPM Default Value: __exp238value__
Description: Expansion Module 6 key 38value

P61187
EPM Default Value: __exp238label__
Description: Expansion Module 6 key 38label

P61188
EPM Default Value: __exp238acct__
Description: Expansion Module 6 key 38account

P61189
EPM Default Value: __exp238pu__
Description: Expansion Module 6 key 38pickup up

P61190
EPM Default Value: __exp239type__
Description: Expansion Module 6 key 39type

P61191
EPM Default Value: __exp239value__
Description: Expansion Module 6 key 39value

P61192
EPM Default Value: __exp239label__
Description: Expansion Module 6 key 39label

P61193
EPM Default Value: __exp239acct__
Description: Expansion Module 6 key 39account

P61194
EPM Default Value: __exp239pu__
Description: Expansion Module 6 key 39pickup up

P61195
EPM Default Value: __exp240type__
Description: Expansion Module 6 key 40type

P61196
EPM Default Value: __exp240value__
Description: Expansion Module 6 key 40value

P61197
EPM Default Value: __exp240label__
Description: Expansion Module 6 key 40label

P61198
EPM Default Value: __exp240acct__
Description: Expansion Module 6 key 40account

P61199
EPM Default Value: __exp240pu__
Description: Expansion Module 6 key 40pickup up

P20052
EPM Default Value: __background__
Description: Background image url

P8660
EPM Default Value: __enableBackground__
Description: Enable background image

P20178
EPM Default Value: __vpnUrl__
Description: VPN config file

P20082
EPM Default Value: __voicemessageStatusEnable__
Description: Voice Message Status

P20073
EPM Default Value: 1
Description: Redial Mode

P20021
EPM Default Value: __multicastAddress1__
Description: Multicast Address

P20022
EPM Default Value: __line1Name__
Description: Multicast Label

P20023
EPM Default Value: __multicastAddress2__
Description: Multicast Address

P20024
EPM Default Value: __line1Name__
Description: Multicast Label

P20025
EPM Default Value: __multicastAddress3__
Description: Multicast Address

P20026
EPM Default Value: __line1Name__
Description: Multicast Label

P20027
EPM Default Value: __multicastAddress4__
Description: Multicast Address

P20028
EPM Default Value: __line1Name__
Description: Multicast Label

P20029
EPM Default Value: __multicastAddress5__
Description: Multicast Address

P20030
EPM Default Value: __line1Name__
Description: Multicast Label

P20031
EPM Default Value: __multicastAddress6__
Description: Multicast Address

P20032
EPM Default Value: __line1Name__
Description: Multicast Label

P20033
EPM Default Value: __multicastAddress7__
Description: Multicast Address

P20034
EPM Default Value: Multicast 7
Description: Multicast Label

P20035
EPM Default Value: __multicastAddress8__
Description: Multicast Address

P20036
EPM Default Value: __line1Name__
Description: Multicast Label

P20037
EPM Default Value: __multicastAddress9__
Description: Multicast Address

P20038
EPM Default Value: __line1Name__
Description: Multicast Label

P20039
EPM Default Value: __multicastAddress10__
Description: Multicast Address

P20040
EPM Default Value: __line1Name__
Description: Multicast Label

P20041
EPM Default Value: 0
Description: Multicast Barge

P20042
EPM Default Value: 0
Description: Multicast Priority

P20019
EPM Default Value: __headset__
Description: HeadSet Priority

P20020
EPM Default Value: __headsetRing__
Description: Ringer Device For HeadSet

P8850
EPM Default Value: __callwaiting__
Description: Call Waiting Tone Enable/Disable

P1399
EPM Default Value: ring1
Description: Preference.AlertInternalText

P1402
EPM Default Value: 1
Description: Preference.AlertInternalRinger

P1400
EPM Default Value: ring2
Description: Preference.AlertExternalText

P1403
EPM Default Value: 2
Description: Preference.AlertExternalText

P1401
EPM Default Value: ring3
Description: Preference.AlertGroupText

P1404
EPM Default Value: 3
Description: Preference.AlertGroupText

P20059
EPM Default Value: ring4
Description: Preference.AlertGroupText

P20066
EPM Default Value: 4
Description: Preference.AlertGroupText

P20060
EPM Default Value: ring5
Description: Preference.AlertGroupText

P20067
EPM Default Value: 5
Description: Preference.AlertGroupText

P20061
EPM Default Value: ring6
Description: Preference.AlertGroupText

P20068
EPM Default Value: 6
Description: Preference.AlertGroupText

P20062
EPM Default Value: ring7
Description: Preference.AlertGroupText

P20069
EPM Default Value: 7
Description: Preference.AlertGroupText

P20063
EPM Default Value: ring8
Description: Preference.AlertGroupText

P20070
EPM Default Value: 8
Description: Preference.AlertGroupText

P20064
EPM Default Value: ring9
Description: Preference.AlertGroupText

P20071
EPM Default Value: 9
Description: Preference.AlertGroupText

P20065
EPM Default Value: ring10
Description: Preference.AlertGroupText

P20072
EPM Default Value: 10
Description: Preference.AlertGroupText

P8751
EPM Default Value: 1
Description: SoftKeyLayout.CustomSoftkey

P20991
EPM Default Value: __provisionAddress__/cfg__ext__-states.xml
Description: Softkey Layout url

P20043
EPM Default Value: __sk1label__
Description: ProgrammableKey1.Label

P20044
EPM Default Value: __sk2label__
Description: ProgrammableKey2.Label

P20045
EPM Default Value: __sk3label__
Description: ProgrammableKey3.Label

P20046
EPM Default Value: __sk4label__
Description: ProgrammableKey4.Label

P43213
EPM Default Value: 0
Description: TranKey.Type

P20118
EPM Default Value: 1
Description: VoiceMailTone

P20051
EPM Default Value: __sslimage__
Description: ScreenSaverUpgradeUrl

P20058
EPM Default Value: __countryTone__
Description: Country tone selection

P967
EPM Default Value: __backupDestination__
Description: Account1.FailoverSipserver

P48
EPM Default Value: __outboundDestination__
Description: Account1.OutboundProxy

P20047
EPM Default Value: __backupOutboundDestination__
Description: Account1.BackUpOutboundProxy

P8683
EPM Default Value: __backlightTimeout__
Description: Backlight Time

P20157

EPM Default Value: 3

Description: Caller Display Source

P20643

EPM Default Value: __backlightActive__

Description: Backlight Active Level

P20642

EPM Default Value: __backlightInActive__

Description: Backlight In-Active Level

P23253

EPM Default Value: __labelScroll__

Description: Enable line key label scrolling

P20934

EPM Default Value: 1

Description: Enable EHS version number

P8684

EPM Default Value: __dhcpVlan__

Description: DHCP on VLAN

P23259

EPM Default Value: __visualAlert__

Description: BLF Visual Alert keys

P23260

EPM Default Value: __audioAlert__

Description: BLF Audio Alert Keys

P5430

EPM Default Value: __ldapNameFilter__

Description: LDAP Name Filter

P5431

EPM Default Value: __ldapNumberFilter__

Description: LDAP Number Filter

P5432

EPM Default Value: __ldapServerAddress__

Description: LDAP Server Address

P5433

EPM Default Value: __ldapPort__

Description: LDAP Port

P5434

EPM Default Value: __ldapBase__

Description: LDAP Base

P5435

EPM Default Value: __ldapUsername__

Description: LDAP User Name

P5436

EPM Default Value: __ldapPassword__

Description: LDAP Password

P5437

EPM Default Value: __ldapMaxHits__

Description: LDAP Max Hits

P5440

EPM Default Value: __ldapDisplayName__

Description: LDAP Display Name

P5442

EPM Default Value: __ldapSearchDelay__

Description: LDAP Search Delay

P5441

EPM Default Value: __ldapProtocol__

Description: LDAP Protocol

P5443

EPM Default Value: __ldapLookupCall__

Description: LDAP Lookup For Incoming Call

P5444

EPM Default Value: __ldapSort__

Description: LDAP Sorting Results

P23136

EPM Default Value: __ldapNameAttributes__

Description: LDAP Name Attributes

P23137

EPM Default Value: __ldapNumberAttributes__

Description: LDAP Number Attributes

P23254

EPM Default Value: __shortPressIdleState__

Description: BLF Press Setting Short Press Idle

P23255

EPM Default Value: __shortPressInUseState__

Description: BLF Press Setting Short Press In Use

P23256

EPM Default Value: __longPressIdleState__

Description: BLF Press Setting Long Press Idle

P23257

EPM Default Value: __longPressInUseState__

Description: BLF Press Setting Long Press In Use

P23258

EPM Default Value: __longPressRingState__

Description: BLF Press Setting Long Press Ring

P20018

EPM Default Value: __dialFirstDigit__

Description: Dial First Digit

P23263

EPM Default Value: __logoled__

Description: Logo LED status - 0 tie to backlight, 1 always on, 2 always off

P23261

EPM Default Value: __voicemailkey__

Description: Voicemail key type - 0 Feature Code, 1 XML

P23262

EPM Default Value: __voicemailkeyValue__

Description: Voicemail key value - based on voicemail key type

P23274

EPM Default Value: __activecallStatusEnable__

Description: LEDStatus Active Call Status

P23264

EPM Default Value: __ringingStatusSpeed__

Description: LED Status Ringing Speed

P23265

EPM Default Value: __ringingStatusColor__

Description: LED Status Ringing Light Color

P23266

EPM Default Value: __voicemailStatusSpeed__

Description: LED Status Voice Msg Speed

P23267
EPM Default Value: __voicemailStatusColor__
Description: LED Status Voice Msg Light Color

P23268
EPM Default Value: __misscallsStatusSpeed__
Description: LED Status Miss Call Speed

P23269
EPM Default Value: __misscallsStatusColor__
Description: LED Status Miss Call Light Color

P23270
EPM Default Value: __powerStatusSpeed__
Description: LED Status Power Speed

P23271
EPM Default Value: __powerStatusColor__
Description: LED Status Power Light Color

P23272
EPM Default Value: __activecallStatusSpeed__
Description: LED Status Active Call Speed

P23273
EPM Default Value: __activecallStatusColor__
Description: LED Status Active Call Light Color

P20935
EPM Default Value: __confCallRelease__
Description: Three way call release type.

P43206
EPM Default Value: 49
Description: Left arrow key type.

P43207
EPM Default Value: 50
Description: Right arrow key type.

P43208
EPM Default Value: 40
Description: OK key type.

P43204
EPM Default Value: 36
Description: Up arrow key type.

P43205
EPM Default Value: 37
Description: Down arrow key type.

P43209
EPM Default Value: 0
Description: Cancel key type.

P43210
EPM Default Value: 0
Description: Conference key type.

P43211
EPM Default Value: 0
Description: Hold key type.

P43212
EPM Default Value: 0
Description: Mute key type.

P43213
EPM Default Value: 0
Description: Transfer key type.

P43214
EPM Default Value: 1
Description: Speaker key type.

P43215
EPM Default Value: 1
Description: Headset key type.

P43216
EPM Default Value: 1
Description: Voicemail key type.

P43217
EPM Default Value: __menukey__
Description: Menu key type.

P43418
EPM Default Value: __menupin__
Description: Menu PIN.

P43218
EPM Default Value: 1
Description: Volume Up key type.

P43219
EPM Default Value: 1
Description: Volume Down key type.

P20360
EPM Default Value: __line5Enable__
Description: Account 5 Active

P20362
EPM Default Value: __line5Dest__:__line5ServerPort__
Description: Account 5 Sipserver

P20364
EPM Default Value: __backupDestination__
Description: Account 5 Failover Sipserver

P20366
EPM Default Value:
Description: Account 5 Second Failover Sipserver

P20368
EPM Default Value: 0
Description: Account 5 Prefer Primary Server

P20370
EPM Default Value: __outboundDestination__
Description: Account 5 Outbound Proxy

P20372
EPM Default Value: __backupOutboundDestination__
Description: Account 5 Back Up Outbound Proxy

P20374
EPM Default Value: __transport5__
Description: Account 5 Sip Transport

P20376
EPM Default Value: 2
Description: Account 5 Nat Traversal

P20378
EPM Default Value: __line5Name__
Description: Account 5 Label

P1704
EPM Default Value: __line5Ext__
Description: Account 5 Sip User Id

P1705
EPM Default Value: __line5Ext__
Description: Account 5 Authenticate ID

P1706
EPM Default Value: __line5Pass__
Description: Account 5 Authenticate Password

P1707
EPM Default Value: __line5Name__
Description: Account 5 Display Name

P20380
EPM Default Value: 0
Description: Account 5 Dns Mode

P20382
EPM Default Value: 0
Description: Account 5 User Id Is Phone Number

P20384
EPM Default Value: __line5Enable__
Description: Account 5 Sip Registration

P20386
EPM Default Value: 0
Description: Account 5 Unregister On Reboot

P20388
EPM Default Value: 15
Description: Account 5 Register Expiration

P1113
EPM Default Value: 1
Description: Account 5 Out Call Without Reg

P1713
EPM Default Value: __line5extPort__
Description: Account 5 Local Sip Port

P20390
EPM Default Value: 0
Description: Account 5 Use Random Port

P1726
EPM Default Value: __voicemail__
Description: Account 5 Voice Mail Id

P140
EPM Default Value: 0
Description: Account 5 RPort

P1104
EPM Default Value: 1
Description: Account 5 RFC2543 Hold

P20476
EPM Default Value: 0
Description: Account 5 Connect Mode

P20392
EPM Default Value: __line5Codec1__
Description: Account 5 Choice 1

P20394
EPM Default Value: __line5Codec2__
Description: Account 5 Choice 2

P20396
EPM Default Value: __line5Codec3__
Description: Account 5 Choice 3

P20398
EPM Default Value: __line5Codec4__
Description: Account 5 Choice 4

P20400
EPM Default Value: __line5Codec5__
Description: Account 5 Choice 5

P20402
EPM Default Value: __line5Codec6__
Description: Account 5 Choice 6

P20408
EPM Default Value: 2
Description: Account 5 Voice Frames Per TX

P20410
EPM Default Value: 0
Description: Account 5 G723 Rate

P20412
EPM Default Value: 97
Description: Account 5 iLBC Payload Type

P20414
EPM Default Value: 0
Description: Account 5 iLBC Frame Size

P20416
EPM Default Value: 101
Description: Account 5 Dtmf Payload Type

P20170
EPM Default Value: 0
Description: Account 5 Dtmf Mode

P20424
EPM Default Value: 0
Description: Account 5 Send Flash Event

P20426
EPM Default Value: 0
Description: Account 5 Enable Call Features

P20428
EPM Default Value:
Description: Account 5 Proxy Require

P20430
EPM Default Value:
Description: Account 5 Use Nat IP

P20432
EPM Default Value: __srtpMode5__
Description: Account 5 SRtp Mode

P20434
EPM Default Value: 0
Description: Account 5 VAD

P20436
EPM Default Value: 0
Description: Account 5 Symmetric RTP

P20438
EPM Default Value: 1
Description: Account 5 Jitter Buffer Type

P20440
EPM Default Value: 1
Description: Account 5 Jitter Buffer Length

P1723
EPM Default Value: __ringtone__
Description: Account 5 Account Ring Tone

P20442
EPM Default Value: 60
Description: Account 5 Ring Timeout

P20444
EPM Default Value: 1
Description: Account 5 Use # As Dial Key

P4204
EPM Default Value: __dialpattern__
Description: Account 5 Dial Plan

P1715
EPM Default Value: 0
Description: Account 5 Subscribe For MWI

P1721
EPM Default Value: 0
Description: Account 5 Send Anonymous

P20446
EPM Default Value: __acr__
Description: Account 5 Anonymous Call Rejection

P1767
EPM Default Value: 0
Description: Account 5 Check SIP User ID

P1725
EPM Default Value: 0
Description: Account 5 Auto Answer

P1738
EPM Default Value: 1
Description: Account 5 Answer Via Call Info

P1739
EPM Default Value: 1
Description: Account 5 Off Speaker Disconnect

P1734
EPM Default Value: 180
Description: Account 5 Session Expiration

P1727
EPM Default Value: 90
Description: Account 5 Min SE

P1728
EPM Default Value: 0
Description: Account 5 Caller Request Timer

P1729
EPM Default Value: 0
Description: Account 5 Callee Request Timer

P1730
EPM Default Value: 0
Description: Account 5 Force Timer

P1732
EPM Default Value: 0
Description: Account 5 UAC Specify Refresher

P1733
EPM Default Value: 1
Description: Account 5 UAS Specify Refresher

P1731
EPM Default Value: 0
Description: Account 5 Force INVITE

P20448
EPM Default Value: 50
Description: Account 5 Hook Flash Min Timing

P20450
EPM Default Value: 100
Description: Account 5 Hook Flash Max Timing

P20452
EPM Default Value: 100
Description: Account 5 Special Feature

P1744
EPM Default Value:
Description: Account 5 Eventlist Blf Url

P20454
EPM Default Value: 0
Description: Account 5 Share Line

P20456
EPM Default Value: 0
Description: Account 5 SIP Server Type

P20458
EPM Default Value: 0
Description: Account 5 100rel

P20460
EPM Default Value: 0
Description: Account 5 Early Session

P20462
EPM Default Value: 0
Description: Account 5 Refuse Return Code

P20464
EPM Default Value: __directedCallPickup__
Description: Account 5 Direct Call Pickup Code

P20466
EPM Default Value:
Description: Account 5 Group Call Pickup Code

P20468
EPM Default Value: 0
Description: Account 5 Feature Key Syn

P20472
EPM Default Value: 0
Description: Account 5 Conference Type

P20470
EPM Default Value:
Description: Account 5 Conference URI

P20474
EPM Default Value: 0
Description: Account 5 Sip Send Mac

P20161
EPM Default Value: 0
Description: Account 5 Caller Display Source

P20659
EPM Default Value: 0
Description: Account 5 Enable ACD

P20665
EPM Default Value: 0
Description: Account 5 ACD Show Available

P20671
EPM Default Value: 0
Description: Account 5 ACD Initial State

P20677
EPM Default Value: 0
Description: Account 5 ACD Show Unavailable Reason

P20920
EPM Default Value:
Description: Account 5 ACD Un Available Name 1

P20921
EPM Default Value:
Description: Account 5 ACD Un Available Name 2

P20922
EPM Default Value:
Description: Account 5 ACD Un Available Name 3

P20923
EPM Default Value:
Description: Account 5 ACD Un Available Name 4

P20924
EPM Default Value:
Description: Account 5 ACD Un Available Name 5

P20699
EPM Default Value:
Description: Account 5 ACD Un Available Code 1

P20700
EPM Default Value:
Description: Account 5 ACD Un Available Code 2

P20701
EPM Default Value:
Description: Account 5 ACD Un Available Code 3

P20702
EPM Default Value:
Description: Account 5 ACD Un Available Code 4

P20703
EPM Default Value:
Description: Account 5 ACD Un Available Code 5

P20713
EPM Default Value: 0
Description: Account 5 Enable Hoteling

P20719
EPM Default Value: 0
Description: Account 5 Hoteling Auto Login

P20725
EPM Default Value:
Description: Account 5 Hoteling User Id

P20731
EPM Default Value:
Description: Account 5 Hoteling Password

P20737
EPM Default Value: 0
Description: Account 5 Enable Call Center Status

P20743
EPM Default Value: 0
Description: Account 5 Enable Call Center Trace

P20749
EPM Default Value: 0
Description: Account 5 Enable Call Center Emergency Escalation

P20775
EPM Default Value:
Description: Account 5 Call Center Supervisor Code 1

P20776
EPM Default Value:
Description: Account 5 Call Center Supervisor Code 2

P20777
EPM Default Value:
Description: Account 5 Call Center Supervisor Code 3

P20778
EPM Default Value:
Description: Account 5 Call Center Supervisor Code 4

P20779
EPM Default Value:
Description: Account 5 Call Center Supervisor Code 5

P20811
EPM Default Value:
Description: Account 5 Call Center Supervisor Name 1

P20812
EPM Default Value:
Description: Account 5 Call Center Supervisor Name 2

P20813
EPM Default Value:
Description: Account 5 Call Center Supervisor Name 3

P20814
EPM Default Value:
Description: Account 5 Call Center Supervisor Name 4

P20815
EPM Default Value:
Description: Account 5 Call Center Supervisor Name 5

P20827
EPM Default Value: 0
Description: Account 5 Enable Call Center Disp Code

P20853
EPM Default Value:
Description: Account 5 CC Disp Code 1

P20854
EPM Default Value:
Description: Account 5 CC Disp Code 2

P20855
EPM Default Value:
Description: Account 5 CC Disp Code 3

P20856
EPM Default Value:
Description: Account 5 CC Disp Code 4

P20857
EPM Default Value:
Description: Account 5 CC Disp Code 5

P20889
EPM Default Value:
Description: Account 5 CC Disp Name 1

P20890
EPM Default Value:
Description: Account 5 CC Disp Name 2

P20891
EPM Default Value:
Description: Account 5 CC Disp Name 3

P20892
EPM Default Value:
Description: Account 5 CC Disp Name 4

P20893
EPM Default Value:
Description: Account 5 CC Disp Name 5

P20974
EPM Default Value: 300
Description: Account 5 Subscribe Expires

P20980
EPM Default Value: 0
Description: Account 5 SCA Barge In

P20361
EPM Default Value: __line6Enable__
Description: Account 6 Active

P20363
EPM Default Value: __line6Dest__:__line6ServerPort__
Description: Account 6 Sip server

P20365
EPM Default Value: __backupDestination__
Description: Account 6 Failover Sip server

P20367
EPM Default Value:
Description: Account 6 Second Failover Sip server

P20369
EPM Default Value: 0
Description: Account 6 Prefer Primary Server

P20371
EPM Default Value: __outboundDestination__
Description: Account 6 Outbound Proxy

P20373
EPM Default Value: __backupOutboundDestination__
Description: Account 6 Back Up Outbound Proxy

P20375
EPM Default Value: __transport6__
Description: Account 6 Sip Transport

P20377
EPM Default Value: 2
Description: Account 6 Nat Traversal

P20379
EPM Default Value: __line6Name__
Description: Account 6 Label

P1804
EPM Default Value: __line6Ext__
Description: Account 6 Sip User Id

P1805
EPM Default Value: __line6Ext__
Description: Account 6 Authenticate ID

P1806
EPM Default Value: __line6Pass__
Description: Account 6 Authenticate Password

P1807
EPM Default Value: __line6Name__
Description: Account 6 Display Name

P20381
EPM Default Value: 0
Description: Account 6 Dns Mode

P20383
EPM Default Value: 0
Description: Account 6 User Id Is Phone Number

P20385
EPM Default Value: __line6Enable__
Description: Account 6 Sip Registration

P20387
EPM Default Value: 0
Description: Account 6 Unregister On Reboot

P20389
EPM Default Value: 15
Description: Account 6 Register Expiration

P1213
EPM Default Value: 1
Description: Account 6 Out Call Without Reg

P1813
EPM Default Value: __line6extPort__
Description: Account 6 Local Sip Port

P20391
EPM Default Value: 0
Description: Account 6 Use Random Port

P1826
EPM Default Value: __voicemail__
Description: Account 6 Voice Mail Id

P141
EPM Default Value: 0
Description: Account 6 RPort

P1105
EPM Default Value: 1
Description: Account 6 RFC2543 Hold

P20477
EPM Default Value: 0
Description: Account 6 Connect Mode

P20393
EPM Default Value: __line6Codec1__
Description: Account 6 Choice 1

P20395
EPM Default Value: __line6Codec2__
Description: Account 6 Choice 2

P20397
EPM Default Value: __line6Codec3__
Description: Account 6 Choice 3

P20399
EPM Default Value: __line6Codec4__
Description: Account 6 Choice 4

P20401
EPM Default Value: __line6Codec5__
Description: Account 6 Choice 5

P20403
EPM Default Value: __line6Codec6__
Description: Account 6 Choice 6

P20409
EPM Default Value: 2
Description: Account 6 Voice Frames Per TX

P20411
EPM Default Value: 0
Description: Account 6 G723 Rate

P20413
EPM Default Value: 97
Description: Account 6 iLBC Payload Type

P20415
EPM Default Value: 0
Description: Account 6 iLBC Frame Size

P20417
EPM Default Value: 101
Description: Account 6 Dtmf Payload Type

P20171
EPM Default Value: 0
Description: Account 6 Dtmf Mode

P20425
EPM Default Value: 0
Description: Account 6 Send Flash Event

P20427
EPM Default Value: 0
Description: Account 6 Enable Call Features

P20429
EPM Default Value:
Description: Account 6 Proxy Require

P20431
EPM Default Value:
Description: Account 6 Use Nat IP

P20433
EPM Default Value: __srtpMode6__
Description: Account 6 SRtp Mode

P20435
EPM Default Value: 0
Description: Account 6 VAD

P20437
EPM Default Value: 0
Description: Account 6 Symmetric RTP

P20439
EPM Default Value: 1
Description: Account 6 Jitter Buffer Type

P20441
EPM Default Value: 1
Description: Account 6 Jitter Buffer Length

P1823
EPM Default Value: __ringtone__
Description: Account 6 Account Ring Tone

P20443
EPM Default Value: 60
Description: Account 6 Ring Timeout

P20445
EPM Default Value: 1
Description: Account 6 Use # As Dial Key

P4205
EPM Default Value: __dialpattern__
Description: Account 6 Dial Plan

P1815
EPM Default Value: 0
Description: Account 6 Subscribe For MWI

P1821
EPM Default Value: 0
Description: Account 6 Send Anonymous

P20447
EPM Default Value: __acr__
Description: Account 6 Anonymous Call Rejection

P1867
EPM Default Value: 0
Description: Account 6 Check SIP User ID

P1825
EPM Default Value: 0
Description: Account 6 Auto Answer

P1838
EPM Default Value: 1
Description: Account 6 Answer Via Call Info

P1839
EPM Default Value: 1
Description: Account 6 Off Speaker Disconnect

P1834
EPM Default Value: 180
Description: Account 6 Session Expiration

P1827
EPM Default Value: 90
Description: Account 6 Min SE

P1828
EPM Default Value: 0
Description: Account 6 Caller Request Timer

P1829
EPM Default Value: 0
Description: Account 6 Callee Request Timer

P1830
EPM Default Value: 0
Description: Account 6 Force Timer

P1832
EPM Default Value: 0
Description: Account 6 UAC Specify Refresher

P1833
EPM Default Value: 1
Description: Account 6 UAS Specify Refresher

P1831
EPM Default Value: 0
Description: Account 6 Force INVITE

P20449
EPM Default Value: 50
Description: Account 6 Hook Flash Min Timing

P20451
EPM Default Value: 100
Description: Account 6 Hook Flash Max Timing

P20453
EPM Default Value: 100
Description: Account 6 Special Feature

P1844
EPM Default Value:
Description: Account 6 Eventlist Blf Url

P20455
EPM Default Value: 0
Description: Account 6 Share Line

P20457
EPM Default Value: 0
Description: Account 6 SIP Server Type

P20459
EPM Default Value: 0
Description: Account 6 100rel

P20461
EPM Default Value: 0
Description: Account 6 Early Session

P20463
EPM Default Value: 0
Description: Account 6 Refuse Return Code

P20465
EPM Default Value: __directedCallPickup__
Description: Account 6 Direct Call Pickup Code

P20467
EPM Default Value:
Description: Account 6 Group Call Pickup Code

P20469
EPM Default Value: 0
Description: Account 6 Feature Key Syn

P20473
EPM Default Value: 0
Description: Account 6 Conference Type

P20471
EPM Default Value:
Description: Account 6 Conference URI

P20475
EPM Default Value: 0
Description: Account 6 Sip Send Mac

P20162
EPM Default Value: 0
Description: Account 6 Caller Display Source

P20660
EPM Default Value: 0
Description: Account 6 Enable ACD

P20666
EPM Default Value: 0
Description: Account 6 ACD Show Available

P20672
EPM Default Value: 0
Description: Account 6 ACD Initial State

P20678
EPM Default Value: 0
Description: Account 6 ACD Show Unavailable Reason

P20925
EPM Default Value:
Description: Account 6 ACD Un Available Name 1

P20926
EPM Default Value:
Description: Account 6 ACD Un Available Name 2

P20927
EPM Default Value:
Description: Account 6 ACD Un Available Name 3

P20928
EPM Default Value:
Description: Account 6 ACD Un Available Name 4

P20929
EPM Default Value:
Description: Account 6 ACD Un Available Name 5

P20704
EPM Default Value:
Description: Account 6 ACD Un Available Code 1

P20705
EPM Default Value:
Description: Account 6 ACD Un Available Code 2

P20706
EPM Default Value:
Description: Account 6 ACD Un Available Code 3

P20707
EPM Default Value:
Description: Account 6 ACD Un Available Code 4

P20708
EPM Default Value:
Description: Account 6 ACD Un Available Code 5

P20714
EPM Default Value: 0
Description: Account 6 Enable Hoteling

P20720
EPM Default Value: 0
Description: Account 6 Hoteling Auto Login

P20726
EPM Default Value:
Description: Account 6 Hoteling User Id

P20732
EPM Default Value:
Description: Account 6 Hoteling Password

P20738
EPM Default Value: 0
Description: Account 6 Enable Call Center Status

P20744
EPM Default Value: 0
Description: Account 6 Enable Call Center Trace

P20750
EPM Default Value: 0
Description: Account 6 Enable Call Center Emergency Escalation

P20781
EPM Default Value:
Description: Account 6 Call Center Supervisor Code 1

P20782
EPM Default Value:
Description: Account 6 Call Center Supervisor Code 2

P20783
EPM Default Value:
Description: Account 6 Call Center Supervisor Code 3

P20784
EPM Default Value:
Description: Account 6 Call Center Supervisor Code 4

P20785
EPM Default Value:
Description: Account 6 Call Center Supervisor Code 5

P20817
EPM Default Value:
Description: Account 6 Call Center Supervisor Name 1

P20818
EPM Default Value:
Description: Account 6 Call Center Supervisor Name 2

P20819
EPM Default Value:
Description: Account 6 Call Center Supervisor Name 3

P20820
EPM Default Value:
Description: Account 6 Call Center Supervisor Name 4

P20821
EPM Default Value:
Description: Account 6 Call Center Supervisor Name 5

P20828
EPM Default Value: 0
Description: Account 6 Enable Call Center Disp Code

P20859
EPM Default Value:
Description: Account 6 CC Disp Code 1

P20860
EPM Default Value:
Description: Account 6 CC Disp Code 2

P20861
EPM Default Value:
Description: Account 6 CC Disp Code 3

P20862
EPM Default Value:
Description: Account 6 CC Disp Code 4

P20863
EPM Default Value:
Description: Account 6 CC Disp Code 5

P20895
EPM Default Value:
Description: Account 6 CC Disp Name 1

P20896
EPM Default Value:
Description: Account 6 CC Disp Name 2

P20897
EPM Default Value:
Description: Account 6 CC Disp Name 3

P20898
EPM Default Value:
Description: Account 6 CC Disp Name 4

P20899
EPM Default Value:
Description: Account 6 CC Disp Name 5

P20975
EPM Default Value: 300
Description: Account 6 Subscribe Expires

P20981
EPM Default Value: 0
Description: Account 6 SCA Barge In

P8951
EPM Default Value: __textLogo__
Description: Logo Screen Saver Text

P20000
EPM Default Value: __line1Name__
Description: Account 1 Label

P20001
EPM Default Value: __line2Name__
Description: Account 2 Label

P20002
EPM Default Value: __line3Name__
Description: Account 3 Label

P20003
EPM Default Value: __line4Name__
Description: Account 4 Label

P23279
EPM Default Value: __guiOverride__
Description: Web Setting High Priority

P39
EPM Default Value: 12100
Description: MinRtpPort

P40
EPM Default Value: __line1extPort__
Description: Account1 LocalSipPort

P113
EPM Default Value:
Description: DMZIpAddr

P136
EPM Default Value: 0
Description: Account1 RPort

P137
EPM Default Value: 0
Description: Account2 RPort

P138
EPM Default Value: 0
Description: Account3 RPort

P139
EPM Default Value: 0
Description: Account4 RPort

P150
EPM Default Value: 0
Description: PortMap WanPort1

P152
EPM Default Value: 0
Description: PortMap WanPort3

P153
EPM Default Value: 0
Description: PortMap WanPort4

P154
EPM Default Value: 0
Description: PortMap WanPort5

P155
EPM Default Value: 0
Description: PortMap WanPort6

P156
EPM Default Value: 0
Description: PortMap WanPort7

P157
EPM Default Value: 0
Description: PortMap WanPort8

P158
EPM Default Value:
Description: PortMap LanIp1

P159
EPM Default Value:
Description: PortMap LanIp2

P160
EPM Default Value:
Description: PortMap LanIp3

P161
EPM Default Value:
Description: PortMap LanIp4

P162
EPM Default Value:
Description: PortMap LanIp5

P163
EPM Default Value:
Description: PortMap LanIp6

P164
EPM Default Value:
Description: PortMap LanIp7

P165
EPM Default Value:
Description: PortMap LanIp8

P166
EPM Default Value: 0
Description: PortMap LanPort1

P167
EPM Default Value: 0
Description: PortMap LanPort2

P168
EPM Default Value: 0
Description: PortMap LanPort3

P169
EPM Default Value: 0
Description: PortMap LanPort4

P170
EPM Default Value: 0
Description: PortMap LanPort5

P171
EPM Default Value: 0
Description: PortMap LanPort6

P172
EPM Default Value: 0
Description: PortMap LanPort7

P173
EPM Default Value: 0
Description: PortMap LanPort8

P174
EPM Default Value: 0
Description: PortMap Protocol1

P175
EPM Default Value: 0
Description: PortMap Protocol2

P176
EPM Default Value: 0
Description: PortMap Protocol3

P177
EPM Default Value: 0
Description: PortMap Protocol4

P178
EPM Default Value: 0
Description: PortMap Protocol5

P179
EPM Default Value: 0
Description: PortMap Protocol6

P180
EPM Default Value: 0
Description: PortMap Protocol7

P181
EPM Default Value: 0
Description: PortMap Protocol8

P196
EPM Default Value: __userPass__
Description: UserPassword

P232
EPM Default Value:
Description: FirmwareUpGrade FilePrefix

P233
EPM Default Value:
Description: FirmwareUpGrade FilePostfix

P390
EPM Default Value: 97
Description: Account1 LibcPayloadType

P391
EPM Default Value: 97
Description: Account2 LibcPayloadType

P392
EPM Default Value: 97
Description: Account3 LibcPayloadType

P393
EPM Default Value: 97
Description: Account4 LibcPayloadType

P394
EPM Default Value: 0
Description: Account1 LibcMode

P395
EPM Default Value: 0
Description: Account2 LibcMode

P396
EPM Default Value: 0
Description: Account3 LibcMode

P397
EPM Default Value: 0
Description: Account4 LibcMode

P513
EPM Default Value: __line3extPort__
Description: Account3 LocalSipPort

P613
EPM Default Value: __line4extPort__
Description: Account4 LocalSipPort

P739
EPM Default Value: 12200
Description: MaxRtpPort

P740
EPM Default Value: __line2extPort__
Description: Account2 LocalSipPort

P751
EPM Default Value: 0
Description: Account2 EnableCallFeatures

P775
EPM Default Value: 0
Description: Account3 SendFlashEvent

P776
EPM Default Value: 0
Description: Account4 SendFlashEvent

P792
EPM Default Value:
Description: Account2 ProxyRequire

P1085
EPM Default Value: __dialNow__
Description: DialNow-TimeOut

P1100
EPM Default Value: 1
Description: Account1 RFC2543Hold

P1101
EPM Default Value: 1
Description: Account2 RFC2543Hold

P1102
EPM Default Value: 1
Description: Account3 RFC2543Hold

P1103
EPM Default Value: 1
Description: Account4 RFC2543Hold

P2532
EPM Default Value: 0
Description: Preference DisplayMode

P3207
EPM Default Value: 0
Description: Transfer HoldTransferOnHook

P3312
EPM Default Value:
Description: RemotePhoneBook2 Name

P3313
EPM Default Value:
Description: RemotePhoneBook3 Name

P3314
EPM Default Value:
Description: RemotePhoneBook4 Name

P3315
EPM Default Value:
Description: RemotePhoneBook5 Name

P3316
EPM Default Value:
Description: RemotePhoneBook1 Name

P4203
EPM Default Value: __dialpattern__
Description: Account4 DialPlan

P4401
EPM Default Value:
Description: RemotePhoneBook1 Url

P4402
EPM Default Value:
Description: RemotePhoneBook2 Url

P4403
EPM Default Value:
Description: RemotePhoneBook3 Url

P4404
EPM Default Value:
Description: RemotePhoneBook4 Url

P4405
EPM Default Value:
Description: RemotePhoneBook5 Url

P8519
EPM Default Value:
Description: BroadSoftItem

P8520
EPM Default Value:
Description: BroadSoft1 DisplayName

P8521
EPM Default Value:
Description: BroadSoft1 Server

P8522
EPM Default Value: 0
Description: BroadSoft1 Port

P8523
EPM Default Value:
Description: BroadSoft1 User

P8524
EPM Default Value:
Description: BroadSoft1 PassWord

P8530
EPM Default Value:
Description: BroadSoft2 DisplayName

P8531
EPM Default Value:
Description: BroadSoft2 Server

P8532
EPM Default Value: 0
Description: BroadSoft2 Port

P8533
EPM Default Value:
Description: BroadSoft2 User

P8534
EPM Default Value:
Description: BroadSoft2 PassWord

P8540
EPM Default Value:
Description: BroadSoft3 DisplayName

P8541
EPM Default Value:
Description: BroadSoft3 Server

P8542
EPM Default Value: 0
Description: BroadSoft3 Port

P8543
EPM Default Value:
Description: BroadSoft3 User

P8544
EPM Default Value:
Description: BroadSoft3 PassWord

P8550
EPM Default Value:
Description: BroadSoft4 DisplayName

P8551
EPM Default Value:
Description: BroadSoft4 Server

P8552
EPM Default Value: 0
Description: BroadSoft4 Port

P8553
EPM Default Value:
Description: BroadSoft4 User

P8554
EPM Default Value:
Description: BroadSoft4 PassWord

P8560
EPM Default Value:
Description: BroadSoft5 DisplayName

P8561
EPM Default Value:
Description: BroadSoft5 Server

P8562
EPM Default Value: 0
Description: BroadSoft5 Port

P8563
EPM Default Value:
Description: BroadSoft5 User

P8564
EPM Default Value:
Description: BroadSoft5 PassWord

P8570
EPM Default Value:
Description: BroadSoft6 DisplayName

P8571
EPM Default Value:
Description: BroadSoft6 Server

P8572
EPM Default Value: 0
Description: BroadSoft6 Port

P8573
EPM Default Value:
Description: BroadSoft6 User

P8574
EPM Default Value:
Description: BroadSoft6 PassWord

P8579
EPM Default Value:
Description: CallLogItem

P8580
EPM Default Value:
Description: CallLog1 DisplayName

P8581
EPM Default Value:
Description: CallLog1 Server

P8582
EPM Default Value: 0
Description: CallLog1 Port

P8583
EPM Default Value:
Description: CallLog1 User

P8584
EPM Default Value:
Description: CallLog1 PassWord

P8585
EPM Default Value:
Description: CallLog2 DisplayName

P8586
EPM Default Value:
Description: CallLog2 Server

P8587
EPM Default Value: 0
Description: CallLog2 Port

P8588
EPM Default Value:
Description: CallLog2 User

P8589
EPM Default Value:
Description: CallLog2 PassWord

P8590
EPM Default Value:
Description: CallLog3 DisplayName

P8591
EPM Default Value:
Description: CallLog3 Server

P8592
EPM Default Value: 0
Description: CallLog3 Port

P8593
EPM Default Value:
Description: CallLog3 User

P8594
EPM Default Value:
Description: CallLog3 PassWord

P8620
EPM Default Value: 0
Description: Preference HistoryRecord

P8621
EPM Default Value: __lcdLanguage__
Description: Preference LcdLanguage

P8622
EPM Default Value:
Description: DateTime BackUpNTPServer

P8631
EPM Default Value:
Description: FirmwareUpGrade SetCommonAESKey

P8633
EPM Default Value: 0
Description: Account1 FeatureKeySyn

P8634
EPM Default Value: 0
Description: Account2 FeatureKeySyn

P8635
EPM Default Value: 0
Description: Account3 FeatureKeySyn

P8639
EPM Default Value: 0
Description: DhcpServerFlag

P8656
EPM Default Value: 0
Description: Account4 FeatureKeySyn

P8672
EPM Default Value: 1
Description: Preference IncomingCallShowMode

P8678
EPM Default Value: 1
Description: Preference PhoneFontHeightSize

P8680
EPM Default Value: 1
Description: Preference WatchDogEnable

P8681
EPM Default Value: admin
Description: LogUser Admin

P8682
EPM Default Value: user
Description: LogUser User

P8685
EPM Default Value:
Description: GlobalConfig CopyRight

P8686
EPM Default Value: SANGOMA
Description: GlobalConfig OEMTag

P8775
EPM Default Value: __vpnMode__
Description: Account1 ConnectMode

P8776
EPM Default Value: __vpnMode__
Description: Account2 ConnectMode

P8777
EPM Default Value: __vpnMode__
Description: Account3 ConnectMode

P8778
EPM Default Value: __vpnMode__
Description: Account4 ConnectMode

P8845
EPM Default Value: 0
Description: Account1 RefuseReturnCode

P8846
EPM Default Value: 0
Description: Account2 RefuseReturnCode

P8847
EPM Default Value: 0
Description: Account3 RefuseReturnCode

P8848
EPM Default Value: 0
Description: Account4 RefuseReturnCode

P8849
EPM Default Value: 1
Description: CallWaiting OnOff

P8851
EPM Default Value:
Description: Account1 SecondFailoverSipserver

P8852
EPM Default Value:
Description: Account2 SecondFailoverSipserver

P8853
EPM Default Value:
Description: Account3 SecondFailoverSipserver

P8854
EPM Default Value:
Description: Account4 SecondFailoverSipserver

P20004
EPM Default Value: 0
Description: Account1 ConferenceType

P20005
EPM Default Value: 0
Description: Account2 ConferenceType

P20006
EPM Default Value: 0
Description: Account3 ConferenceType

P20007
EPM Default Value: 0
Description: Account4 ConferenceType

P20008
EPM Default Value:
Description: Account1 ConferenceURI

P20009
EPM Default Value:
Description: Account2 ConferenceURI

P20010
EPM Default Value:
Description: Account3 ConferenceURI

P20011
EPM Default Value:
Description: Account4 ConferenceURI

P20017
EPM Default Value: 0
Description: Preference RefreshCallerIdViaContact

P20048
EPM Default Value: __backupOutboundDestination__
Description: Account2 BackUpOutboundProxy

P20049
EPM Default Value: __backupOutboundDestination__
Description: Account3 BackUpOutboundProxy

P20050
EPM Default Value: __backupOutboundDestination__
Description: Account4 BackUpOutboundProxy

P20053
EPM Default Value: 0
Description: Account1 SipSendMac

P20054
EPM Default Value: 0
Description: Account2 SipSendMac

P20055
EPM Default Value: 0
Description: Account3 SipSendMac

P20056
EPM Default Value: 0
Description: Account4 SipSendMac

P20074
EPM Default Value: 0
Description: InterComBarge

P20075
EPM Default Value: 0
Description: LcdShowMissCall

P20076
EPM Default Value: 3
Description: DSTStartTime-Month

P20077
EPM Default Value: 12
Description: DSTStartTime-Day

P20078
EPM Default Value: 2
Description: DSTStartTime-Hour

P20079
EPM Default Value: 11
Description: DSTEndTime-Month

P20080
EPM Default Value: 5
Description: DSTEndTime-Day

P20081
EPM Default Value: 1
Description: DSTEndTime-Hour

P20083
EPM Default Value: 0
Description: HandSetSendVolume

P20084
EPM Default Value: 0
Description: HeadSetSendVolume

P20085
EPM Default Value: 0
Description: BLFSelectType

P20086
EPM Default Value: 0
Description: CurrentCallStatus-1

P20087
EPM Default Value: 1
Description: CurrentCallStatus-2

P20088
EPM Default Value: 2
Description: CurrentCallStatus-3

P20089
EPM Default Value: 3
Description: CurrentCallStatus-4

P20090
EPM Default Value: 4
Description: CurrentCallStatus-5

P20091
EPM Default Value: 5
Description: CurrentCallStatus-6

P20092
EPM Default Value: 6
Description: CurrentCallStatus-7

P20093
EPM Default Value: 0
Description: CurrentCallStatus-8

P20094
EPM Default Value: 0
Description: CurrentCallStatus-9

P20095
EPM Default Value: 0
Description: CurrentCallStatus-10

P20096
EPM Default Value: terminated
Description: BlfStatusText-1

P20097
EPM Default Value: early
Description: BlfStatusText-2

P20098
EPM Default Value: confirmed
Description: BlfStatusText-3

P20099
EPM Default Value: confirmed
Description: BlfStatusText-4

P20100
EPM Default Value: confirmed
Description: BlfStatusText-5

P20101
EPM Default Value: confirmed
Description: BlfStatusText-6

P20102
EPM Default Value: unknown
Description: BlfStatusText-7

P20103
EPM Default Value: BlfStatusText-8
Description: BlfStatusText-8

P20104
EPM Default Value: BlfStatusText-9
Description: BlfStatusText-9

P20105
EPM Default Value: BlfStatusText-10
Description: BlfStatusText-10

P20106
EPM Default Value: 2
Description: BlfLedMode-1

P20107
EPM Default Value: 6
Description: BlfLedMode-2

P20108
EPM Default Value: 1
Description: BlfLedMode-3

P20109
EPM Default Value: 1
Description: BlfLedMode-4

P20110
EPM Default Value: 1
Description: BlfLedMode-5

P20111
EPM Default Value: 1
Description: BifLedMode-6

P20112
EPM Default Value: 0
Description: BifLedMode-7

P20113
EPM Default Value: 0
Description: BifLedMode-8

P20114
EPM Default Value: 0
Description: BifLedMode-9

P20115
EPM Default Value: 0
Description: BifLedMode-10

P20116
EPM Default Value: 1
Description: SuppressDTMF

P20117
EPM Default Value: 1
Description: SuppressDTMFDelay

P20119
EPM Default Value: 0
Description: RTCPReportFlag

P20120
EPM Default Value: RTCPReportCollector
Description: RTCPReportCollector

P20121
EPM Default Value: RTCPReportFormat
Description: RTCPReportFormat

P20155
EPM Default Value: 0
Description: ServerCaType

P20156
EPM Default Value: 2
Description: TrustedCaType

P20158
EPM Default Value: 0
Description: Account2 CallerDisplaySource

P20159
EPM Default Value: 0
Description: Account3 CallerDisplaySource

P20160
EPM Default Value: 0
Description: Account4 CallerDisplaySource

P20163
EPM Default Value: 0
Description: NetWork StaticDNS

P20164
EPM Default Value: 0
Description: MulticastPaging MulticatCodec

P20165
EPM Default Value: 1
Description: FirmwareUpGrade PnPActive

P20166
EPM Default Value: 0
Description: Account1 DtmfMode

P20167
EPM Default Value: 0
Description: Account2 DtmfMode

P20168
EPM Default Value: 0
Description: Account3 DtmfMode

P20169
EPM Default Value: 0
Description: Account4 DtmfMode

P20172
EPM Default Value: 0
Description: Preference VmTransfer

P20173
EPM Default Value:
Description: Preference VmTransferCode

P20174
EPM Default Value: __ringtoneUrl__
Description: FirmwareUpGrade RingUrl

P20175
EPM Default Value:
Description: FirmwareUpGrade LanguageUrl

P20176
EPM Default Value:
Description: FirmwareUpGrade HlpresUrl

P20177
EPM Default Value:
Description: FirmwareUpGrade ExpPresUrl

P20179
EPM Default Value:
Description: FirmwareUpGrade TCAUrl

P20180
EPM Default Value:
Description: FirmwareUpGrade SCAUrl

P20600
EPM Default Value: 0
Description: LineKey1 Mode

P20601
EPM Default Value: 0
Description: LineKey2 Mode

P20602
EPM Default Value: 0
Description: LineKey3 Mode

P20603
EPM Default Value: 0
Description: LineKey4 Mode

P20655
EPM Default Value: 0
Description: Account1 EnableACD

P20656
EPM Default Value: 0
Description: Account2 EnableACD

P20657
EPM Default Value: 0
Description: Account3 EnableACD

P20658
EPM Default Value: 0
Description: Account4 EnableACD

P20661
EPM Default Value: 0
Description: Account1 ACDSHowAvailable

P20662
EPM Default Value: 0
Description: Account2 ACDSHowAvailable

P20663
EPM Default Value: 0
Description: Account3 ACDSHowAvailable

P20664
EPM Default Value: 0
Description: Account4 ACDSHowAvailable

P20667
EPM Default Value: 0
Description: Account1 ACDInitialState

P20668
EPM Default Value: 0
Description: Account2 ACDInitialState

P20669
EPM Default Value: 0
Description: Account3 ACDInitialState

P20670
EPM Default Value: 0
Description: Account4 ACDInitialState

P20673
EPM Default Value: 0
Description: Account1 ACDSHowUnavailableReason

P20674
EPM Default Value: 0
Description: Account2 ACDSHowUnavailableReason

P20675
EPM Default Value: 0
Description: Account3 ACDSHowUnavailableReason

P20676
EPM Default Value: 0
Description: Account4 ACDSHowUnavailableReason

P20679
EPM Default Value:
Description: Account1 ACDSUnAvailableCode1

P20680
EPM Default Value:
Description: Account1 ACDSUnAvailableCode2

P20681
EPM Default Value:
Description: Account1 ACDSUnAvailableCode3

P20682
EPM Default Value:
Description: Account1 ACDSUnAvailableCode4

P20683
EPM Default Value:
Description: Account1 ACDUnAvailableCode5

P20684
EPM Default Value:
Description: Account2 ACDUnAvailableCode1

P20685
EPM Default Value:
Description: Account2 ACDUnAvailableCode2

P20686
EPM Default Value:
Description: Account2 ACDUnAvailableCode3

P20687
EPM Default Value:
Description: Account2 ACDUnAvailableCode4

P20688
EPM Default Value:
Description: Account2 ACDUnAvailableCode5

P20689
EPM Default Value:
Description: Account3 ACDUnAvailableCode1

P20690
EPM Default Value:
Description: Account3 ACDUnAvailableCode2

P20691
EPM Default Value:
Description: Account3 ACDUnAvailableCode3

P20692
EPM Default Value:
Description: Account3 ACDUnAvailableCode4

P20693
EPM Default Value:
Description: Account3 ACDUnAvailableCode5

P20694
EPM Default Value:
Description: Account4 ACDUnAvailableCode1

P20695
EPM Default Value:
Description: Account4 ACDUnAvailableCode2

P20696
EPM Default Value:
Description: Account4 ACDUnAvailableCode3

P20697
EPM Default Value:
Description: Account4 ACDUnAvailableCode4

P20698
EPM Default Value:
Description: Account4 ACDUnAvailableCode5

P20709
EPM Default Value: 0
Description: Account1 EnableHoteling

P20710
EPM Default Value: 0
Description: Account2 EnableHoteling

P20711
EPM Default Value: 0
Description: Account3 EnableHoteling

P20712
EPM Default Value: 0
Description: Account4 EnableHoteling

P20715
EPM Default Value: 0
Description: Account1 HotelingAutoLogin

P20716
EPM Default Value: 0
Description: Account2 HotelingAutoLogin

P20717
EPM Default Value: 0
Description: Account3 HotelingAutoLogin

P20718
EPM Default Value: 0
Description: Account4 HotelingAutoLogin

P20721
EPM Default Value:
Description: Account1 HotelingUserId

P20722
EPM Default Value:
Description: Account2 HotelingUserId

P20723
EPM Default Value:
Description: Account3 HotelingUserId

P20724
EPM Default Value:
Description: Account4 HotelingUserId

P20727
EPM Default Value:
Description: Account1 HotelingPassWord

P20728
EPM Default Value:
Description: Account2 HotelingPassWord

P20729
EPM Default Value:
Description: Account3 HotelingPassWord

P20730
EPM Default Value:
Description: Account4 HotelingPassWord

P20733
EPM Default Value: 0
Description: Account1 EnableCallCenterStatus

P20734
EPM Default Value: 0
Description: Account2 EnableCallCenterStatus

P20735
EPM Default Value: 0
Description: Account3 EnableCallCenterStatus

P20736
EPM Default Value: 0
Description: Account4 EnableCallCenterStatus

P20739
EPM Default Value: 0
Description: Account1 EnableCallCenterTrace

P20740
EPM Default Value: 0
Description: Account2 EnableCallCenterTrace

P20741
EPM Default Value: 0
Description: Account3 EnableCallCenterTrace

P20742
EPM Default Value: 0
Description: Account4 EnableCallCenterTrace

P20745
EPM Default Value: 0
Description: Account1 EnableCallCenterEmergencyEscalation

P20746
EPM Default Value: 0
Description: Account2 EnableCallCenterEmergencyEscalation

P20747
EPM Default Value: 0
Description: Account3 EnableCallCenterEmergencyEscalation

P20748
EPM Default Value: 0
Description: Account4 EnableCallCenterEmergencyEscalation

P20751
EPM Default Value:
Description: Account1 CallCenterSupervisorCode1

P20752
EPM Default Value:
Description: Account1 CallCenterSupervisorCode2

P20753
EPM Default Value:
Description: Account1 CallCenterSupervisorCode3

P20754
EPM Default Value:
Description: Account1 CallCenterSupervisorCode4

P20755
EPM Default Value:
Description: Account1 CallCenterSupervisorCode5

P20757
EPM Default Value:
Description: Account2 CallCenterSupervisorCode1

P20758
EPM Default Value:
Description: Account2 CallCenterSupervisorCode2

P20759
EPM Default Value:
Description: Account2 CallCenterSupervisorCode3

P20760
EPM Default Value:
Description: Account2 CallCenterSupervisorCode4

P20761
EPM Default Value:
Description: Account2 CallCenterSupervisorCode5

P20763
EPM Default Value:
Description: Account3 CallCenterSupervisorCode1

P20764
EPM Default Value:
Description: Account3 CallCenterSupervisorCode2

P20765
EPM Default Value:
Description: Account3 CallCenterSupervisorCode3

P20766
EPM Default Value:
Description: Account3 CallCenterSupervisorCode4

P20767
EPM Default Value:
Description: Account3 CallCenterSupervisorCode5

P20769
EPM Default Value:
Description: Account4 CallCenterSupervisorCode1

P20770
EPM Default Value:
Description: Account4 CallCenterSupervisorCode2

P20771
EPM Default Value:
Description: Account4 CallCenterSupervisorCode3

P20772
EPM Default Value:
Description: Account4 CallCenterSupervisorCode4

P20773
EPM Default Value:
Description: Account4 CallCenterSupervisorCode5

P20787
EPM Default Value:
Description: Account1 CallCenterSupervisorName1

P20788
EPM Default Value:
Description: Account1 CallCenterSupervisorName2

P20789
EPM Default Value:
Description: Account1 CallCenterSupervisorName3

P20790
EPM Default Value:
Description: Account1 CallCenterSupervisorName4

P20791
EPM Default Value:
Description: Account1 CallCenterSupervisorName5

P20793
EPM Default Value:
Description: Account2 CallCenterSupervisorName1

P20794
EPM Default Value:
Description: Account2 CallCenterSupervisorName2

P20795
EPM Default Value:
Description: Account2 CallCenterSupervisorName3

P20796
EPM Default Value:
Description: Account2 CallCenterSupervisorName4

P20797
EPM Default Value:
Description: Account2 CallCenterSupervisorName5

P20799
EPM Default Value:
Description: Account3 CallCenterSupervisorName1

P20800
EPM Default Value:
Description: Account3 CallCenterSupervisorName2

P20801
EPM Default Value:
Description: Account3 CallCenterSupervisorName3

P20802
EPM Default Value:
Description: Account3 CallCenterSupervisorName4

P20803
EPM Default Value:
Description: Account3 CallCenterSupervisorName5

P20805
EPM Default Value:
Description: Account4 CallCenterSupervisorName1

P20806
EPM Default Value:
Description: Account4 CallCenterSupervisorName2

P20807
EPM Default Value:
Description: Account4 CallCenterSupervisorName3

P20808
EPM Default Value:
Description: Account4 CallCenterSupervisorName4

P20809
EPM Default Value:
Description: Account4 CallCenterSupervisorName5

P20823
EPM Default Value: 0
Description: Account1 EnableCallCenterDispCode

P20824
EPM Default Value: 0
Description: Account2 EnableCallCenterDispCode

P20825
EPM Default Value: 0
Description: Account3 EnableCallCenterDispCode

P20826
EPM Default Value: 0
Description: Account4 EnableCallCenterDispCode

P20829
EPM Default Value:
Description: Account1 CCDispCode1

P20830
EPM Default Value:
Description: Account1 CCDispCode2

P20831
EPM Default Value:
Description: Account1 CCDispCode3

P20832
EPM Default Value:
Description: Account1 CCDispCode4

P20833
EPM Default Value:
Description: Account1 CCDispCode5

P20835
EPM Default Value:
Description: Account2 CCDispCode1

P20836
EPM Default Value:
Description: Account2 CCDispCode2

P20837
EPM Default Value:
Description: Account2 CCDispCode3

P20838
EPM Default Value:
Description: Account2 CCDispCode4

P20839
EPM Default Value:
Description: Account2 CCDispCode5

P20841
EPM Default Value:
Description: Account3 CCDispCode1

P20842
EPM Default Value:
Description: Account3 CCDispCode2

P20843
EPM Default Value:
Description: Account3 CCDispCode3

P20844
EPM Default Value:
Description: Account3 CCDispCode4

P20845
EPM Default Value:
Description: Account3 CCDispCode5

P20847
EPM Default Value:
Description: Account4 CCDispCode1

P20848
EPM Default Value:
Description: Account4 CCDispCode2

P20849
EPM Default Value:
Description: Account4 CCDispCode3

P20850
EPM Default Value:
Description: Account4 CCDispCode4

P20851
EPM Default Value:
Description: Account4 CCDispCode5

P20865
EPM Default Value:
Description: Account1 CCDispName1

P20866
EPM Default Value:
Description: Account1 CCDispName2

P20867
EPM Default Value:
Description: Account1 CCDispName3

P20868
EPM Default Value:
Description: Account1 CCDispName4

P20869
EPM Default Value:
Description: Account1 CCDispName5

P20871
EPM Default Value:
Description: Account2 CCDispName1

P20872
EPM Default Value:
Description: Account2 CCDispName2

P20873
EPM Default Value:
Description: Account2 CCDispName3

P20874
EPM Default Value:
Description: Account2 CCDispName4

P20875
EPM Default Value:
Description: Account2 CCDispName5

P20877
EPM Default Value:
Description: Account3 CCDispName1

P20878
EPM Default Value:
Description: Account3 CCDispName2

P20879
EPM Default Value:
Description: Account3 CCDispName3

P20880
EPM Default Value:
Description: Account3 CCDispName4

P20881
EPM Default Value:
Description: Account3 CCDispName5

P20883
EPM Default Value:
Description: Account4 CCDispName1

P20884
EPM Default Value:
Description: Account4 CCDispName2

P20885
EPM Default Value:
Description: Account4 CCDispName3

P20886
EPM Default Value:
Description: Account4 CCDispName4

P20887
EPM Default Value:
Description: Account4 CCDispName5

P20900
EPM Default Value:
Description: Account1 ACDUnAvailableName1

P20901
EPM Default Value:
Description: Account1 ACDUnAvailableName2

P20902
EPM Default Value:
Description: Account1 ACDUnAvailableName3

P20903
EPM Default Value:
Description: Account1 ACDUnAvailableName4

P20904
EPM Default Value:
Description: Account1 ACDUnAvailableName5

P20905
EPM Default Value:
Description: Account2 ACDUnAvailableName1

P20906
EPM Default Value:
Description: Account2 ACDUnAvailableName2

P20907
EPM Default Value:
Description: Account2 ACDUnAvailableName3

P20908
EPM Default Value:
Description: Account2 ACDUnAvailableName4

P20909
EPM Default Value:
Description: Account2 ACDUnAvailableName5

P20910
EPM Default Value:
Description: Account3 ACDUnAvailableName1

P20911
EPM Default Value:
Description: Account3 ACDUnAvailableName2

P20912
EPM Default Value:
Description: Account3 ACDUnAvailableName3

P20913
EPM Default Value:
Description: Account3 ACDUnAvailableName4

P20914
EPM Default Value:
Description: Account3 ACDUnAvailableName5

P20915
EPM Default Value:
Description: Account4 ACDUnAvailableName1

P20916
EPM Default Value:
Description: Account4 ACUnAvailableName2

P20917
EPM Default Value:
Description: Account4 ACUnAvailableName3

P20918
EPM Default Value:
Description: Account4 ACUnAvailableName4

P20919
EPM Default Value:
Description: Account4 ACUnAvailableName5

P20930
EPM Default Value: 0
Description: CallPark Flag

P20931
EPM Default Value:
Description: CallPark Code

P20932
EPM Default Value: 5
Description: FirmwareUpgrade ZeroTouchTime

P20933
EPM Default Value: 0
Description: FirmwareUpgrade ZeroTouchEnable

P20943
EPM Default Value: 1
Description: Preference DetectIPConflict

P20944
EPM Default Value: 0
Description: BwXsiDir AllowSipAuthForXsi

P20945
EPM Default Value:
Description: BwXsiDir Host

P20946
EPM Default Value: 80
Description: BwXsiDir Port

P20947
EPM Default Value: 0
Description: BwXsiDir ServerType

P20948
EPM Default Value:
Description: BwXsiDir UserId

P20949
EPM Default Value:
Description: BwXsiDir PassWord

P20950
EPM Default Value:
Description: BwXsiDir UCUser

P20951
EPM Default Value:
Description: BwXsiDir UCPassWord

P20952
EPM Default Value: 0
Description: LcdItemLevelEnable

P20953
EPM Default Value: 1
Description: BwXsiDir Group

P20954
EPM Default Value: 1
Description: BwXsiDir GroupCommon

P20955
EPM Default Value: 1
Description: BwXsiDir Enterprise

P20956
EPM Default Value: 1
Description: BwXsiDir EnterpriseCommon

P20957
EPM Default Value: 1
Description: BwXsiDir Personal

P20958
EPM Default Value: 1
Description: BwXsiDir CustomDir

P20959
EPM Default Value: 1
Description: BwXsiDir CallLogs

P20960
EPM Default Value:
Description: BwXsiDir GroupName

P20961
EPM Default Value:
Description: BwXsiDir GroupCName

P20962
EPM Default Value:
Description: BwXsiDir EnterpriseName

P20963
EPM Default Value:
Description: BwXsiDir EnterpriseCName

P20964
EPM Default Value:
Description: BwXsiDir PersonalName

P20970
EPM Default Value: 300
Description: Account1 SubscribeExpires

P20971
EPM Default Value: 300
Description: Account2 SubscribeExpires

P20972
EPM Default Value: 300
Description: Account3 SubscribeExpires

P20973
EPM Default Value: 300
Description: Account4 SubscribeExpires

P20976
EPM Default Value: 0
Description: Account1 SCABargeln

P20977
EPM Default Value: 0
Description: Account2 SCABargeln

P20978
EPM Default Value: 0
Description: Account3 SCABargeln

P20979
EPM Default Value: 0
Description: Account4 SCABargeln

P20982
EPM Default Value: 1
Description: Preference SpeedDialDetectDigitMap

P20983
EPM Default Value: 0
Description: Preference CheckSyncWithAuth

P20984
EPM Default Value:
Description: Features CallBackCode

P20992
EPM Default Value: 1
Description: Preference OpenSideTone

P20994
EPM Default Value:
Description: FirmwareUpGrade SoftKeyXmlUrl

P23132
EPM Default Value: 1
Description: FirmwareUpGrade UpgradeEXPRom

P40000
EPM Default Value:
Description: GlobalConfig UserAgent

P40002
EPM Default Value:
Description: FirmwareUpGrade ExpServer

P56203
EPM Default Value: 4
Description: Preference BusyToneTimer

P56204
EPM Default Value: 0
Description: AutoRedial OnOff

P56205
EPM Default Value: 3
Description: AutoRedial Interval

P56206
EPM Default Value: 3
Description: AutoRedial Times

P58101
EPM Default Value:
Description: SMS Number

P58102
EPM Default Value:
Description: SMS Message

P62000
EPM Default Value: __exp31type__
Description: EXP3_1_1 Type

P62001
EPM Default Value: __exp31value__
Description: Exp3_1_1 Value

P62002
EPM Default Value: __exp31label__
Description: Exp3_1_1 Label

P62003
EPM Default Value: __exp31acct__
Description: Exp3_1_1 Account

P62004
EPM Default Value: __exp31pu__
Description: Exp3_1_1 PickupCode

P62005
EPM Default Value: __exp32type__
Description: Exp3_1_2 KeyType

P62006
EPM Default Value: __exp32value__
Description: Exp3_1_2 Value

P62007
EPM Default Value: __exp32label__
Description: Exp3_1_2 Label

P62008
EPM Default Value: __exp32acct__
Description: Exp3_1_2 Account

P62009
EPM Default Value: __exp32pu__
Description: Exp3_1_2 PickupCode

P62010
EPM Default Value: __exp33type__
Description: Exp3_1_3 KeyType

P62011
EPM Default Value: __exp33value__
Description: Exp3_1_3 Value

P62012
EPM Default Value: __exp33label__
Description: Exp3_1_3 Label

P62013
EPM Default Value: __exp33acct__
Description: Exp3_1_3 Account

P62014
EPM Default Value: __exp33pu__
Description: Exp3_1_3 PickupCode

P62015
EPM Default Value: __exp34type__
Description: Exp3_1_4 KeyType

P62016
EPM Default Value: __exp34value__
Description: Exp3_1_4 Value

P62017
EPM Default Value: __exp34label__
Description: Exp3_1_4 Label

P62018
EPM Default Value: __exp34acct__
Description: Exp3_1_4 Account

P62019
EPM Default Value: __exp34pu__
Description: Exp3_1_4 PickupCode

P62020
EPM Default Value: __exp35type__
Description: Exp3_1_5 KeyType

P62021
EPM Default Value: __exp35value__
Description: Exp3_1_5 Value

P62022
EPM Default Value: __exp35label__
Description: Exp3_1_5 Label

P62023
EPM Default Value: __exp35acct__
Description: Exp3_1_5 Account

P62024
EPM Default Value: __exp35pu__
Description: Exp3_1_5 PickupCode

P62025
EPM Default Value: __exp36type__
Description: Exp3_1_6 KeyType

P62026
EPM Default Value: __exp36value__
Description: Exp3_1_6 Value

P62027
EPM Default Value: __exp36label__
Description: Exp3_1_6 Label

P62028
EPM Default Value: __exp36acct__
Description: Exp3_1_6 Account

P62029
EPM Default Value: __exp36pu__
Description: Exp3_1_6 PickupCode

P62030
EPM Default Value: __exp37type__
Description: Exp3_1_7 KeyType

P62031
EPM Default Value: __exp37value__
Description: Exp3_1_7 Value

P62032
EPM Default Value: __exp37label__
Description: Exp3_1_7 Label

P62033
EPM Default Value: __exp37acct__
Description: Exp3_1_7 Account

P62034
EPM Default Value: __exp37pu__
Description: Exp3_1_7 PickupCode

P62035
EPM Default Value: __exp38type__
Description: Exp3_1_8 KeyType

P62036
EPM Default Value: __exp38value__
Description: Exp3_1_8 Value

P62037
EPM Default Value: __exp38label__
Description: Exp3_1_8 Label

P62038
EPM Default Value: __exp38acct__
Description: Exp3_1_8 Account

P62039
EPM Default Value: __exp38pu__
Description: Exp3_1_8 PickupCode

P62040
EPM Default Value: __exp39type__
Description: Exp3_1_9 KeyType

P62041
EPM Default Value: __exp39value__
Description: Exp3_1_9 Value

P62042
EPM Default Value: __exp39label__
Description: Exp3_1_9 Label

P62043
EPM Default Value: __exp39acct__
Description: Exp3_1_9 Account

P62044
EPM Default Value: __exp39pu__
Description: Exp3_1_9 PickupCode

P62045
EPM Default Value: __exp310type__
Description: Exp3_1_10 KeyType

P62046
EPM Default Value: __exp310value__
Description: Exp3_1_10 Value

P62047
EPM Default Value: __exp310label__
Description: Exp3_1_10 Label

P62048
EPM Default Value: __exp310acct__
Description: Exp3_1_10 Account

P62049
EPM Default Value: __exp310pu__
Description: Exp3_1_10 PickupCode

P62050
EPM Default Value: __exp311type__
Description: Exp3_1_11 KeyType

P62051
EPM Default Value: __exp311value__
Description: Exp3_1_11 Value

P62052
EPM Default Value: __exp311label__
Description: Exp3_1_11 Label

P62053
EPM Default Value: __exp311acct__
Description: Exp3_1_11 Account

P62054
EPM Default Value: __exp311pu__
Description: Exp3_1_11 PickupCode

P62055
EPM Default Value: __exp312type__
Description: Exp3_1_12 KeyType

P62056
EPM Default Value: __exp312value__
Description: Exp3_1_12 Value

P62057
EPM Default Value: __exp312label__
Description: Exp3_1_12 Label

P62058
EPM Default Value: __exp312acct__
Description: Exp3_1_12 Account

P62059
EPM Default Value: __exp312pu__
Description: Exp3_1_12 PickupCode

P62060
EPM Default Value: __exp313type__
Description: Exp3_1_13 KeyType

P62061
EPM Default Value: __exp313value__
Description: Exp3_1_13 Value

P62062
EPM Default Value: __exp313label__
Description: Exp3_1_13 Label

P62063
EPM Default Value: __exp313acct__
Description: Exp3_1_13 Account

P62064
EPM Default Value: __exp313pu__
Description: Exp3_1_13 PickupCode

P62065
EPM Default Value: __exp314type__
Description: Exp3_1_14 KeyType

P62066
EPM Default Value: __exp314value__
Description: Exp3_1_14 Value

P62067
EPM Default Value: __exp314label__
Description: Exp3_1_14 Label

P62068
EPM Default Value: __exp314acct__
Description: Exp3_1_14 Account

P62069
EPM Default Value: __exp314pu__
Description: Exp3_1_14 PickupCode

P62070
EPM Default Value: __exp315type__
Description: Exp3_1_15 KeyType

P62071
EPM Default Value: __exp315value__
Description: Exp3_1_15 Value

P62072
EPM Default Value: __exp315label__
Description: Exp3_1_15 Label

P62073
EPM Default Value: __exp315acct__
Description: Exp3_1_15 Account

P62074
EPM Default Value: __exp315pu__
Description: Exp3_1_15 PickupCode

P62075
EPM Default Value: __exp316type__
Description: Exp3_1_16 KeyType

P62076
EPM Default Value: __exp316value__
Description: Exp3_1_16 Value

P62077
EPM Default Value: __exp316label__
Description: Exp3_1_16 Label

P62078
EPM Default Value: __exp316acct__
Description: Exp3_1_16 Account

P62079
EPM Default Value: __exp316pu__
Description: Exp3_1_16 PickupCode

P62080
EPM Default Value: __exp317type__
Description: Exp3_1_17 KeyType

P62081
EPM Default Value: __exp317value__
Description: Exp3_1_17 Value

P62082
EPM Default Value: __exp317label__
Description: Exp3_1_17 Label

P62083
EPM Default Value: __exp317acct__
Description: Exp3_1_17 Account

P62084
EPM Default Value: __exp317pu__
Description: Exp3_1_17 PickupCode

P62085
EPM Default Value: __exp318type__
Description: Exp3_1_18 KeyType

P62086
EPM Default Value: __exp318value__
Description: Exp3_1_18 Value

P62087
EPM Default Value: __exp318label__
Description: Exp3_1_18 Label

P62088
EPM Default Value: __exp318acct__
Description: Exp3_1_18 Account

P62089
EPM Default Value: __exp318pu__
Description: Exp3_1_18 PickupCode

P62090
EPM Default Value: __exp319type__
Description: Exp3_1_19 KeyType

P62091
EPM Default Value: __exp319value__
Description: Exp3_1_19 Value

P62092
EPM Default Value: __exp319label__
Description: Exp3_1_19 Label

P62093
EPM Default Value: __exp319acct__
Description: Exp3_1_19 Account

P62094
EPM Default Value: __exp319pu__
Description: Exp3_1_19 PickupCode

P62095
EPM Default Value: __exp320type__
Description: Exp3_1_20 KeyType

P62096
EPM Default Value: __exp320value__
Description: Exp3_1_20 Value

P62097
EPM Default Value: __exp320label__
Description: Exp3_1_20 Label

P62098
EPM Default Value: __exp320acct__
Description: Exp3_1_20 Account

P62099
EPM Default Value: __exp320pu__
Description: Exp3_1_20 PickupCode

P62100
EPM Default Value: __exp321type__
Description: Exp3_2_1 KeyType

P62101
EPM Default Value: __exp321value__
Description: Exp3_2_1 Value

P62102
EPM Default Value: __exp321label__
Description: Exp3_2_1 Label

P62103
EPM Default Value: __exp321acct__
Description: Exp3_2_1 Account

P62104
EPM Default Value: __exp321pu__
Description: Exp3_2_1 PickupCode

P62105
EPM Default Value: __exp322type__
Description: Exp3_2_2 KeyType

P62106
EPM Default Value: __exp322value__
Description: Exp3_2_2 Value

P62107
EPM Default Value: __exp322label__
Description: Exp3_2_2 Label

P62108
EPM Default Value: __exp322acct__
Description: Exp3_2_2 Account

P62109
EPM Default Value: __exp322pu__
Description: Exp3_2_2 PickupCode

P62110
EPM Default Value: __exp323type__
Description: Exp3_2_3 KeyType

P62111
EPM Default Value: __exp323value__
Description: Exp3_2_3 Value

P62112
EPM Default Value: __exp323label__
Description: Exp3_2_3 Label

P62113
EPM Default Value: __exp323acct__
Description: Exp3_2_3 Account

P62114
EPM Default Value: __exp323pu__
Description: Exp3_2_3 PickupCode

P62115
EPM Default Value: __exp324type__
Description: Exp3_2_4 KeyType

P62116
EPM Default Value: __exp324value__
Description: Exp3_2_4 Value

P62117
EPM Default Value: __exp324label__
Description: Exp3_2_4 Label

P62118
EPM Default Value: __exp324acct__
Description: Exp3_2_4 Account

P62119
EPM Default Value: __exp324pu__
Description: Exp3_2_4 PickupCode

P62120
EPM Default Value: __exp324type__
Description: Exp3_2_5 KeyType

P62121
EPM Default Value: __exp325value__
Description: Exp3_2_5 Value

P62122
EPM Default Value: __exp325label__
Description: Exp3_2_5 Label

P62123
EPM Default Value: __exp325acct__
Description: Exp3_2_5 Account

P62124
EPM Default Value: __exp325pu__
Description: Exp3_2_5 PickupCode

P62125
EPM Default Value: __exp326type__
Description: Exp3_2_6 KeyType

P62126
EPM Default Value: __exp326value__
Description: Exp3_2_6 Value

P62127
EPM Default Value: __exp326label__
Description: Exp3_2_6 Label

P62128
EPM Default Value: __exp326acct__
Description: Exp3_2_6 Account

P62129
EPM Default Value: __exp326pu__
Description: Exp3_2_6 PickupCode

P62130
EPM Default Value: __exp327type__
Description: Exp3_2_7 KeyType

P62131
EPM Default Value: __exp327value__
Description: Exp3_2_7 Value

P62132
EPM Default Value: __exp327label__
Description: Exp3_2_7 Label

P62133
EPM Default Value: __exp327acct__
Description: Exp3_2_7 Account

P62134
EPM Default Value: __exp327pu__
Description: Exp3_2_7 PickupCode

P62135
EPM Default Value: __exp328type__
Description: Exp3_2_8 KeyType

P62136
EPM Default Value: __exp328value__
Description: Exp3_2_8 Value

P62137
EPM Default Value: __exp328label__
Description: Exp3_2_8 Label

P62138
EPM Default Value: __exp328acct__
Description: Exp3_2_8 Account

P62139
EPM Default Value: __exp328pu__
Description: Exp3_2_8 PickupCode

P62140
EPM Default Value: __exp329type__
Description: Exp3_2_9 KeyType

P62141
EPM Default Value: __exp329value__
Description: Exp3_2_9 Value

P62142
EPM Default Value: __exp329label__
Description: Exp3_2_9 Label

P62143
EPM Default Value: __exp329acct__
Description: Exp3_2_9 Account

P62144
EPM Default Value: __exp329pu__
Description: Exp3_2_9 PickupCode

P62145
EPM Default Value: __exp330type__
Description: Exp3_2_10 KeyType

P62146
EPM Default Value: __exp330value__
Description: Exp3_2_10 Value

P62147
EPM Default Value: __exp330label__
Description: Exp3_2_10 Label

P62148
EPM Default Value: __exp330acct__
Description: Exp3_2_10 Account

P62149
EPM Default Value: __exp330pu__
Description: Exp3_2_10 PickupCode

P62150
EPM Default Value: __exp331type__
Description: Exp3_2_11 KeyType

P62151
EPM Default Value: __exp331value__
Description: Exp3_2_11 Value

P62152
EPM Default Value: __exp331label__
Description: Exp3_2_11 Label

P62153
EPM Default Value: __exp331acct__
Description: Exp3_2_11 Account

P62154
EPM Default Value: __exp331pu__
Description: Exp3_2_11 PickupCode

P62155
EPM Default Value: __exp332type__
Description: Exp3_2_12 KeyType

P62156
EPM Default Value: __exp332value__
Description: Exp3_2_12 Value

P62157
EPM Default Value: __exp332label__
Description: Exp3_2_12 Label

P62158
EPM Default Value: __exp332acct__
Description: Exp3_2_12 Account

P62159
EPM Default Value: __exp332pu__
Description: Exp3_2_12 PickupCode

P62160
EPM Default Value: __exp333type__
Description: Exp3_2_13 KeyType

P62161
EPM Default Value: __exp333value__
Description: Exp3_2_13 Value

P62162
EPM Default Value: __exp333label__
Description: Exp3_2_13 Label

P62163
EPM Default Value: __exp333acct__
Description: Exp3_2_13 Account

P62164
EPM Default Value: __exp333pu__
Description: Exp3_2_13 PickupCode

P62165
EPM Default Value: __exp334type__
Description: Exp3_2_14 KeyType

P62166
EPM Default Value: __exp334value__
Description: Exp3_2_14 Value

P62167
EPM Default Value: __exp334label__
Description: Exp3_2_14 Label

P62168
EPM Default Value: __exp334acct__
Description: Exp3_2_14 Account

P62169
EPM Default Value: __exp334pu__
Description: Exp3_2_14 PickupCode

P62170
EPM Default Value: __exp335type__
Description: Exp3_2_15 KeyType

P62171
EPM Default Value: __exp335value__
Description: Exp3_2_15 Value

P62172
EPM Default Value: __exp335label__
Description: Exp3_2_15 Label

P62173
EPM Default Value: __exp335acct__
Description: Exp3_2_15 Account

P62174
EPM Default Value: __exp335pu__
Description: Exp3_2_15 PickupCode

P62175
EPM Default Value: __exp336type__
Description: Exp3_2_16 KeyType

P62176
EPM Default Value: __exp336value__
Description: Exp3_2_16 Value

P62177
EPM Default Value: __exp336label__
Description: Exp3_2_16 Label

P62178
EPM Default Value: __exp336acct__
Description: Exp3_2_16 Account

P62179
EPM Default Value: __exp336pu__
Description: Exp3_2_16 PickupCode

P62180
EPM Default Value: __exp337type__
Description: Exp3_2_17 KeyType

P62181
EPM Default Value: __exp337value__
Description: Exp3_2_17 Value

P62182
EPM Default Value: __exp337label__
Description: Exp3_2_17 Label

P62183
EPM Default Value: __exp337acct__
Description: Exp3_2_17 Account

P62184
EPM Default Value: __exp337pu__
Description: Exp3_2_17 PickupCode

P62185
EPM Default Value: __exp338type__
Description: Exp3_2_18 KeyType

P62186
EPM Default Value: __exp338value__
Description: Exp3_2_18 Value

P62187
EPM Default Value: __exp338label__
Description: Exp3_2_18 Label

P62188
EPM Default Value: __exp338acct__
Description: Exp3_2_18 Account

P62189
EPM Default Value: __exp338pu__
Description: Exp3_2_18 PickupCode

P62190
EPM Default Value: __exp339type__
Description: Exp3_2_19 KeyType

P62191
EPM Default Value: __exp339value__
Description: Exp3_2_19 Value

P62192
EPM Default Value: __exp339label__
Description: Exp3_2_19 Label

P62193
EPM Default Value: __exp339acct__
Description: Exp3_2_19 Account

P62194
EPM Default Value: __exp339pu__
Description: Exp3_2_19 PickupCode

P62195
EPM Default Value: __exp340type__
Description: Exp3_2_20 KeyType

P62196
EPM Default Value: __exp340value__
Description: Exp3_2_20 Value

P62197
EPM Default Value: __exp340label__
Description: Exp3_2_20 Label

P62198
EPM Default Value: __exp340acct__
Description: Exp3_2_20 Account

P62199
EPM Default Value: __exp340pu__
Description: Exp3_2_20 PickupCode

P63000
EPM Default Value: __exp41type__
Description: Exp4_1_1 KeyType

P63001
EPM Default Value: __exp41value__
Description: Exp4_1_1 Value

P63002
EPM Default Value: __exp41label__
Description: Exp4_1_1 Label

P63003
EPM Default Value: __exp41acct__
Description: Exp4_1_1 Account

P63004
EPM Default Value: __exp41pu__
Description: Exp4_1_1 PickupCode

P63005
EPM Default Value: __exp42type__
Description: Exp4_1_2 KeyType

P63006
EPM Default Value: __exp42value__
Description: Exp4_1_2 Value

P63007
EPM Default Value: __exp42label__
Description: Exp4_1_2 Label

P63008
EPM Default Value: __exp42acct__
Description: Exp4_1_2 Account

P63009
EPM Default Value: __exp42pu__
Description: Exp4_1_2 PickupCode

P63010
EPM Default Value: __exp43type__
Description: Exp4_1_3 KeyType

P63011
EPM Default Value: __exp43value__
Description: Exp4_1_3 Value

P63012
EPM Default Value: __exp43label__
Description: Exp4_1_3 Label

P63013
EPM Default Value: __exp43acct__
Description: Exp4_1_3 Account

P63014
EPM Default Value: __exp43pu__
Description: Exp4_1_3 PickupCode

P63015
EPM Default Value: __exp44type__
Description: Exp4_1_4 KeyType

P63016
EPM Default Value: __exp44value__
Description: Exp4_1_4 Value

P63017
EPM Default Value: __exp44label__
Description: Exp4_1_4 Label

P63018
EPM Default Value: __exp44acct__
Description: Exp4_1_4 Account

P63019
EPM Default Value: __exp44pu__
Description: Exp4_1_4 PickupCode

P63020
EPM Default Value: __exp45type__
Description: Exp4_1_5 KeyType

P63021
EPM Default Value: __exp45value__
Description: Exp4_1_5 Value

P63022
EPM Default Value: __exp45label__
Description: Exp4_1_5 Label

P63023
EPM Default Value: __exp45acct__
Description: Exp4_1_5 Account

P63024
EPM Default Value: __exp45pu__
Description: Exp4_1_5 PickupCode

P63025
EPM Default Value: __exp46type__
Description: Exp4_1_6 KeyType

P63026
EPM Default Value: __exp46value__
Description: Exp4_1_6 Value

P63027
EPM Default Value: __exp46label__
Description: Exp4_1_6 Label

P63028
EPM Default Value: __exp46acct__
Description: Exp4_1_6 Account

P63029
EPM Default Value: __exp46pu__
Description: Exp4_1_6 PickupCode

P63030
EPM Default Value: __exp47type__
Description: Exp4_1_7 KeyType

P63031
EPM Default Value: __exp47value__
Description: Exp4_1_7 Value

P63032
EPM Default Value: __exp47label__
Description: Exp4_1_7 Label

P63033
EPM Default Value: __exp47acct__
Description: Exp4_1_7 Account

P63034
EPM Default Value: __exp47pu__
Description: Exp4_1_7 PickupCode

P63035
EPM Default Value: __exp48type__
Description: Exp4_1_8 KeyType

P63036
EPM Default Value: __exp48value__
Description: Exp4_1_8 Value

P63037
EPM Default Value: __exp48label__
Description: Exp4_1_8 Label

P63038
EPM Default Value: __exp48acct__
Description: Exp4_1_8 Account

P63039
EPM Default Value: __exp48pu__
Description: Exp4_1_8 PickupCode

P63040
EPM Default Value: __exp49type__
Description: Exp4_1_9 KeyType

P63041
EPM Default Value: __exp49value__
Description: Exp4_1_9 Value

P63042
EPM Default Value: __exp49label__
Description: Exp4_1_9 Label

P63043
EPM Default Value: __exp49acct__
Description: Exp4_1_9 Account

P63044
EPM Default Value: __exp49pu__
Description: Exp4_1_9 PickupCode

P63045
EPM Default Value: __exp410type__
Description: Exp4_1_10 KeyType

P63046
EPM Default Value: __exp410value__
Description: Exp4_1_10 Value

P63047
EPM Default Value: __exp410label__
Description: Exp4_1_10 Label

P63048
EPM Default Value: __exp410acct__
Description: Exp4_1_10 Account

P63049
EPM Default Value: __exp410pu__
Description: Exp4_1_10 PickupCode

P63050
EPM Default Value: __exp411type__
Description: Exp4_1_11 KeyType

P63051
EPM Default Value: __exp411value__
Description: Exp4_1_11 Value

P63052
EPM Default Value: __exp411label__
Description: Exp4_1_11 Label

P63053
EPM Default Value: __exp411acct__
Description: Exp4_1_11 Account

P63054
EPM Default Value: __exp411pu__
Description: Exp4_1_11 PickupCode

P63055
EPM Default Value: __exp412type__
Description: Exp4_1_12 KeyType

P63056
EPM Default Value: __exp412value__
Description: Exp4_1_12 Value

P63057
EPM Default Value: __exp412label__
Description: Exp4_1_12 Label

P63058
EPM Default Value: __exp412acct__
Description: Exp4_1_12 Account

P63059
EPM Default Value: __exp412pu__
Description: Exp4_1_12 PickupCode

P63060
EPM Default Value: __exp413type__
Description: Exp4_1_13 KeyType

P63061
EPM Default Value: __exp413value__
Description: Exp4_1_13 Value

P63062
EPM Default Value: __exp413label__
Description: Exp4_1_13 Label

P63063
EPM Default Value: __exp413acct__
Description: Exp4_1_13 Account

P63064
EPM Default Value: __exp413pu__
Description: Exp4_1_13 PickupCode

P63065
EPM Default Value: __exp414type__
Description: Exp4_1_14 KeyType

P63066
EPM Default Value: __exp414value__
Description: Exp4_1_14 Value

P63067
EPM Default Value: __exp414label__
Description: Exp4_1_14 Label

P63068
EPM Default Value: __exp414acct__
Description: Exp4_1_14 Account

P63069
EPM Default Value: __exp414pu__
Description: Exp4_1_14 PickupCode

P63070
EPM Default Value: __exp415type__
Description: Exp4_1_15 KeyType

P63071
EPM Default Value: __exp415value__
Description: Exp4_1_15 Value

P63072
EPM Default Value: __exp415label__
Description: Exp4_1_15 Label

P63073
EPM Default Value: __exp415acct__
Description: Exp4_1_15 Account

P63074
EPM Default Value: __exp415pu__
Description: Exp4_1_15 PickupCode

P63075
EPM Default Value: __exp416type__
Description: Exp4_1_16 KeyType

P63076
EPM Default Value: __exp416value__
Description: Exp4_1_16 Value

P63077
EPM Default Value: __exp416label__
Description: Exp4_1_16 Label

P63078
EPM Default Value: __exp416acct__
Description: Exp4_1_16 Account

P63079
EPM Default Value: __exp416pu__
Description: Exp4_1_16 PickupCode

P63080
EPM Default Value: __exp417type__
Description: Exp4_1_17 KeyType

P63081
EPM Default Value: __exp417value__
Description: Exp4_1_17 Value

P63082
EPM Default Value: __exp417label__
Description: Exp4_1_17 Label

P63083
EPM Default Value: __exp417acct__
Description: Exp4_1_17 Account

P63084
EPM Default Value: __exp417pu__
Description: Exp4_1_17 PickupCode

P63085
EPM Default Value: __exp418type__
Description: Exp4_1_18 KeyType

P63086
EPM Default Value: __exp418value__
Description: Exp4_1_18 Value

P63087
EPM Default Value: __exp418label__
Description: Exp4_1_18 Label

P63088
EPM Default Value: __exp418acct__
Description: Exp4_1_18 Account

P63089
EPM Default Value: __exp418pu__
Description: Exp4_1_18 PickupCode

P63090
EPM Default Value: __exp419type__
Description: Exp4_1_19 KeyType

P63091
EPM Default Value: __exp419value__
Description: Exp4_1_19 Value

P63092
EPM Default Value: __exp419label__
Description: Exp4_1_19 Label

P63093
EPM Default Value: __exp419acct__
Description: Exp4_1_19 Account

P63094
EPM Default Value: __exp419pu__
Description: Exp4_1_19 PickupCode

P63095
EPM Default Value: __exp420type__
Description: Exp4_1_20 KeyType

P63096
EPM Default Value: __exp420value__
Description: Exp4_1_20 Value

P63097
EPM Default Value: __exp420label__
Description: Exp4_1_20 Label

P63098
EPM Default Value: __exp420acct__
Description: Exp4_1_20 Account

P63099
EPM Default Value: __exp420pu__
Description: Exp4_1_20 PickupCode

P63100
EPM Default Value: __exp421type__
Description: Exp4_2_1 KeyType

P63101
EPM Default Value: __exp421value__
Description: Exp4_2_1 Value

P63102
EPM Default Value: __exp421label__
Description: Exp4_2_1 Label

P63103
EPM Default Value: __exp421acct__
Description: Exp4_2_1 Account

P63104
EPM Default Value: __exp421pu__
Description: Exp4_2_1 PickupCode

P63105
EPM Default Value: __exp422type__
Description: Exp4_2_2 KeyType

P63106
EPM Default Value: __exp422value__
Description: Exp4_2_2 Value

P63107
EPM Default Value: __exp422label__
Description: Exp4_2_2 Label

P63108
EPM Default Value: __exp422acct__
Description: Exp4_2_2 Account

P63109
EPM Default Value: __exp422pu__
Description: Exp4_2_2 PickupCode

P63110
EPM Default Value: __exp423type__
Description: Exp4_2_3 KeyType

P63111
EPM Default Value: __exp423value__
Description: Exp4_2_3 Value

P63112
EPM Default Value: __exp423label__
Description: Exp4_2_3 Label

P63113
EPM Default Value: __exp423acct__
Description: Exp4_2_3 Account

P63114
EPM Default Value: __exp423pu__
Description: Exp4_2_3 PickupCode

P63115
EPM Default Value: __exp424type__
Description: Exp4_2_4 KeyType

P63116
EPM Default Value: __exp424value__
Description: Exp4_2_4 Value

P63117
EPM Default Value: __exp424label__
Description: Exp4_2_4 Label

P63118
EPM Default Value: __exp424acct__
Description: Exp4_2_4 Account

P63119
EPM Default Value: __exp424pu__
Description: Exp4_2_4 PickupCode

P63120
EPM Default Value: __exp425type__
Description: Exp4_2_5 KeyType

P63121
EPM Default Value: __exp425value__
Description: Exp4_2_5 Value

P63122
EPM Default Value: __exp425label__
Description: Exp4_2_5 Label

P63123
EPM Default Value: __exp425acct__
Description: Exp4_2_5 Account

P63124
EPM Default Value: __exp425pu__
Description: Exp4_2_5 PickupCode

P63125
EPM Default Value: __exp426type__
Description: Exp4_2_6 KeyType

P63126
EPM Default Value: __exp426value__
Description: Exp4_2_6 Value

P63127
EPM Default Value: __exp426label__
Description: Exp4_2_6 Label

P63128
EPM Default Value: __exp426acct__
Description: Exp4_2_6 Account

P63129
EPM Default Value: __exp426pu__
Description: Exp4_2_6 PickupCode

P63130
EPM Default Value: __exp427type__
Description: Exp4_2_7 KeyType

P63131
EPM Default Value: __exp427value__
Description: Exp4_2_7 Value

P63132
EPM Default Value: __exp427label__
Description: Exp4_2_7 Label

P63133
EPM Default Value: __exp427acct__
Description: Exp4_2_7 Account

P63134
EPM Default Value: __exp427pu__
Description: Exp4_2_7 PickupCode

P63135
EPM Default Value: __exp428type__
Description: Exp4_2_8 KeyType

P63136
EPM Default Value: __exp428value__
Description: Exp4_2_8 Value

P63137
EPM Default Value: __exp428label__
Description: Exp4_2_8 Label

P63138
EPM Default Value: __exp428acct__
Description: Exp4_2_8 Account

P63139
EPM Default Value: __exp428pu__
Description: Exp4_2_8 PickupCode

P63140
EPM Default Value: __exp429type__
Description: Exp4_2_9 KeyType

P63141
EPM Default Value: __exp429value__
Description: Exp4_2_9 Value

P63142
EPM Default Value: __exp429label__
Description: Exp4_2_9 Label

P63143
EPM Default Value: __exp429acct__
Description: Exp4_2_9 Account

P63144
EPM Default Value: __exp429pu__
Description: Exp4_2_9 PickupCode

P63145
EPM Default Value: __exp430type__
Description: Exp4_2_10 KeyType

P63146
EPM Default Value: __exp431value__
Description: Exp4_2_10 Value

P63147
EPM Default Value: __exp431label__
Description: Exp4_2_10 Label

P63148
EPM Default Value: __exp431acct__
Description: Exp4_2_10 Account

P63149
EPM Default Value: __exp431pu__
Description: Exp4_2_10 PickupCode

P63150
EPM Default Value: __exp431type__
Description: Exp4_2_11 KeyType

P63151
EPM Default Value: __exp431value__
Description: Exp4_2_11 Value

P63152
EPM Default Value: __exp431label__
Description: Exp4_2_11 Label

P63153
EPM Default Value: __exp431acct__
Description: Exp4_2_11 Account

P63154
EPM Default Value: __exp431pu__
Description: Exp4_2_11 PickupCode

P63155
EPM Default Value: __exp432type__
Description: Exp4_2_12 KeyType

P63156
EPM Default Value: __exp432value__
Description: Exp4_2_12 Value

P63157
EPM Default Value: __exp432label__
Description: Exp4_2_12 Label

P63158
EPM Default Value: __exp432acct__
Description: Exp4_2_12 Account

P63159
EPM Default Value: __exp432pu__
Description: Exp4_2_12 PickupCode

P63160
EPM Default Value: __exp433type__
Description: Exp4_2_13 KeyType

P63161
EPM Default Value: __exp433value__
Description: Exp4_2_13 Value

P63162
EPM Default Value: __exp433label__
Description: Exp4_2_13 Label

P63163
EPM Default Value: __exp433acct__
Description: Exp4_2_13 Account

P63164
EPM Default Value: __exp433pu__
Description: Exp4_2_13 PickupCode

P63165
EPM Default Value: __exp434type__
Description: Exp4_2_14 KeyType

P63166
EPM Default Value: __exp434value__
Description: Exp4_2_14 Value

P63167
EPM Default Value: __exp434label__
Description: Exp4_2_14 Label

P63168
EPM Default Value: __exp434acct__
Description: Exp4_2_14 Account

P63169
EPM Default Value: __exp434pu__
Description: Exp4_2_14 PickupCode

P63170
EPM Default Value: __exp435type__
Description: Exp4_2_15 KeyType

P63171
EPM Default Value: __exp435value__
Description: Exp4_2_15 Value

P63172
EPM Default Value: __exp435label__
Description: Exp4_2_15 Label

P63173
EPM Default Value: __exp435acct__
Description: Exp4_2_15 Account

P63174
EPM Default Value: __exp435pu__
Description: Exp4_2_15 PickupCode

P63175
EPM Default Value: __exp436type__
Description: Exp4_2_16 KeyType

P63176
EPM Default Value: __exp436value__
Description: Exp4_2_16 Value

P63177
EPM Default Value: __exp436label__
Description: Exp4_2_16 Label

P63178
EPM Default Value: __exp436acct__
Description: Exp4_2_16 Account

P63179
EPM Default Value: __exp436pu__
Description: Exp4_2_16 PickupCode

P63180
EPM Default Value: __exp437type__
Description: Exp4_2_17 KeyType

P63181
EPM Default Value: __exp437value__
Description: Exp4_2_17 Value

P63182
EPM Default Value: __exp437label__
Description: Exp4_2_17 Label

P63183
EPM Default Value: __exp437acct__
Description: Exp4_2_17 Account

P63184
EPM Default Value: __exp437pu__
Description: Exp4_2_17 PickupCode

P63185
EPM Default Value: __exp438type__
Description: Exp4_2_18 KeyType

P63186
EPM Default Value: __exp438value__
Description: Exp4_2_18 Value

P63187
EPM Default Value: __exp438label__
Description: Exp4_2_18 Label

P63188
EPM Default Value: __exp438acct__
Description: Exp4_2_18 Account

P63189
EPM Default Value: __exp438pu__
Description: Exp4_2_18 PickupCode

P63190
EPM Default Value: __exp439type__
Description: Exp4_2_19 KeyType

P63191
EPM Default Value: __exp439value__
Description: Exp4_2_19 Value

P63192
EPM Default Value: __exp439label__
Description: Exp4_2_19 Label

P63193
EPM Default Value: __exp439acct__
Description: Exp4_2_19 Account

P63194
EPM Default Value: __exp439pu__
Description: Exp4_2_19 PickupCode

P63195
EPM Default Value: __exp440type__
Description: Exp4_2_20 KeyType

P63196
EPM Default Value: __exp440value__
Description: Exp4_2_20 Value

P63197
EPM Default Value: __exp440label__
Description: Exp4_2_20 Label

P63198
EPM Default Value: __exp440acct__
Description: Exp4_2_20 Account

P63199
EPM Default Value: __exp440pu__
Description: Exp4_2_20 PickupCode

P64000
EPM Default Value: __exp51type__
Description: Exp5_1_1 KeyType

P64001
EPM Default Value: __exp51value__
Description: Exp5_1_1 Value

P64002
EPM Default Value: __exp51label__
Description: Exp5_1_1 Label

P64003
EPM Default Value: __exp51acct__
Description: Exp5_1_1 Account

P64004
EPM Default Value: __exp51pu__
Description: Exp5_1_1 PickupCode

P64005
EPM Default Value: __exp52type__
Description: Exp5_1_2 KeyType

P64006
EPM Default Value: __exp52value__
Description: Exp5_1_2 Value

P64007
EPM Default Value: __exp52label__
Description: Exp5_1_2 Label

P64008
EPM Default Value: __exp52acct__
Description: Exp5_1_2 Account

P64009
EPM Default Value: __exp52pu__
Description: Exp5_1_2 PickupCode

P64010
EPM Default Value: __exp53type__
Description: Exp5_1_3 KeyType

P64011
EPM Default Value: __exp53value__
Description: Exp5_1_3 Value

P64012
EPM Default Value: __exp53label__
Description: Exp5_1_3 Label

P64013
EPM Default Value: __exp53acct__
Description: Exp5_1_3 Account

P64014
EPM Default Value: __exp53pu__
Description: Exp5_1_3 PickupCode

P64015
EPM Default Value: __exp54type__
Description: Exp5_1_4 KeyType

P64016
EPM Default Value: __exp54value__
Description: Exp5_1_4 Value

P64017
EPM Default Value: __exp54label__
Description: Exp5_1_4 Label

P64018
EPM Default Value: __exp54acct__
Description: Exp5_1_4 Account

P64019
EPM Default Value: __exp54pu__
Description: Exp5_1_4 PickupCode

P64020
EPM Default Value: __exp55type__
Description: Exp5_1_5 KeyType

P64021
EPM Default Value: __exp55value__
Description: Exp5_1_5 Value

P64022
EPM Default Value: __exp55label__
Description: Exp5_1_5 Label

P64023
EPM Default Value: __exp55acct__
Description: Exp5_1_5 Account

P64024
EPM Default Value: __exp55pu__
Description: Exp5_1_5 PickupCode

P64025
EPM Default Value: __exp56type__
Description: Exp5_1_6 KeyType

P64026
EPM Default Value: __exp56value__
Description: Exp5_1_6 Value

P64027
EPM Default Value: __exp56label__
Description: Exp5_1_6 Label

P64028
EPM Default Value: __exp56acct__
Description: Exp5_1_6 Account

P64029
EPM Default Value: __exp56pu__
Description: Exp5_1_6 PickupCode

P64030
EPM Default Value: __exp57type__
Description: Exp5_1_7 KeyType

P64031
EPM Default Value: __exp57value__
Description: Exp5_1_7 Value

P64032
EPM Default Value: __exp57label__
Description: Exp5_1_7 Label

P64033
EPM Default Value: __exp57acct__
Description: Exp5_1_7 Account

P64034
EPM Default Value: __exp57pu__
Description: Exp5_1_7 PickupCode

P64035
EPM Default Value: __exp58type__
Description: Exp5_1_8 KeyType

P64036
EPM Default Value: __exp58value__
Description: Exp5_1_8 Value

P64037
EPM Default Value: __exp58label__
Description: Exp5_1_8 Label

P64038
EPM Default Value: __exp58acct__
Description: Exp5_1_8 Account

P64039
EPM Default Value: __exp58pu__
Description: Exp5_1_8 PickupCode

P64040
EPM Default Value: __exp59type__
Description: Exp5_1_9 KeyType

P64041
EPM Default Value: __exp59value__
Description: Exp5_1_9 Value

P64042
EPM Default Value: __exp59label__
Description: Exp5_1_9 Label

P64043
EPM Default Value: __exp59acct__
Description: Exp5_1_9 Account

P64044
EPM Default Value: __exp59pu__
Description: Exp5_1_9 PickupCode

P64045
EPM Default Value: __exp510type__
Description: Exp5_1_10 KeyType

P64046
EPM Default Value: __exp510value__
Description: Exp5_1_10 Value

P64047
EPM Default Value: __exp510label__
Description: Exp5_1_10 Label

P64048
EPM Default Value: __exp510acct__
Description: Exp5_1_10 Account

P64049
EPM Default Value: __exp510pu__
Description: Exp5_1_10 PickupCode

P64050
EPM Default Value: __exp511type__
Description: Exp5_1_11 KeyType

P64051
EPM Default Value: __exp511value__
Description: Exp5_1_11 Value

P64052
EPM Default Value: __exp511label__
Description: Exp5_1_11 Label

P64053
EPM Default Value: __exp511acct__
Description: Exp5_1_11 Account

P64054
EPM Default Value: __exp511pu__
Description: Exp5_1_11 PickupCode

P64055
EPM Default Value: __exp512type__
Description: Exp5_1_12 KeyType

P64056
EPM Default Value: __exp512value__
Description: Exp5_1_12 Value

P64057
EPM Default Value: __exp512label__
Description: Exp5_1_12 Label

P64058
EPM Default Value: __exp512acct__
Description: Exp5_1_12 Account

P64059
EPM Default Value: __exp512pu__
Description: Exp5_1_12 PickupCode

P64060
EPM Default Value: __exp513type__
Description: Exp5_1_13 KeyType

P64061
EPM Default Value: __exp513value__
Description: Exp5_1_13 Value

P64062
EPM Default Value: __exp513label__
Description: Exp5_1_13 Label

P64063
EPM Default Value: __exp513acct__
Description: Exp5_1_13 Account

P64064
EPM Default Value: __exp513pu__
Description: Exp5_1_13 PickupCode

P64065
EPM Default Value: __exp514type__
Description: Exp5_1_14 KeyType

P64066
EPM Default Value: __exp514value__
Description: Exp5_1_14 Value

P64067
EPM Default Value: __exp514label__
Description: Exp5_1_14 Label

P64068
EPM Default Value: __exp514acct__
Description: Exp5_1_14 Account

P64069
EPM Default Value: __exp514pu__
Description: Exp5_1_14 PickupCode

P64070
EPM Default Value: __exp515type__
Description: Exp5_1_15 KeyType

P64071
EPM Default Value: __exp515value__
Description: Exp5_1_15 Value

P64072
EPM Default Value: __exp515label__
Description: Exp5_1_15 Label

P64073
EPM Default Value: __exp515acct__
Description: Exp5_1_15 Account

P64074
EPM Default Value: __exp515pu__
Description: Exp5_1_15 PickupCode

P64075
EPM Default Value: __exp516type__
Description: Exp5_1_16 KeyType

P64076
EPM Default Value: __exp516value__
Description: Exp5_1_16 Value

P64077
EPM Default Value: __exp516label__
Description: Exp5_1_16 Label

P64078
EPM Default Value: __exp516acct__
Description: Exp5_1_16 Account

P64079
EPM Default Value: __exp516pu__
Description: Exp5_1_16 PickupCode

P64080
EPM Default Value: __exp517type__
Description: Exp5_1_17 KeyType

P64081
EPM Default Value: __exp517value__
Description: Exp5_1_17 Value

P64082
EPM Default Value: __exp517label__
Description: Exp5_1_17 Label

P64083
EPM Default Value: __exp517acct__
Description: Exp5_1_17 Account

P64084
EPM Default Value: __exp517pu__
Description: Exp5_1_17 PickupCode

P64085
EPM Default Value: __exp518type__
Description: Exp5_1_18 KeyType

P64086
EPM Default Value: __exp518value__
Description: Exp5_1_18 Value

P64087
EPM Default Value: __exp518label__
Description: Exp5_1_18 Label

P64088
EPM Default Value: __exp518acct__
Description: Exp5_1_18 Account

P64089
EPM Default Value: __exp518pu__
Description: Exp5_1_18 PickupCode

P64090
EPM Default Value: __exp519type__
Description: Exp5_1_19 KeyType

P64091
EPM Default Value: __exp519value__
Description: Exp5_1_19 Value

P64092
EPM Default Value: __exp519label__
Description: Exp5_1_19 Label

P64093
EPM Default Value: __exp519acct__
Description: Exp5_1_19 Account

P64094
EPM Default Value: __exp519pu__
Description: Exp5_1_19 PickupCode

P64095
EPM Default Value: __exp520type__
Description: Exp5_1_20 KeyType

P64096
EPM Default Value: __exp520value__
Description: Exp5_1_20 Value

P64097
EPM Default Value: __exp520label__
Description: Exp5_1_20 Label

P64098
EPM Default Value: __exp520acct__
Description: Exp5_1_20 Account

P64099
EPM Default Value: __exp520pu__
Description: Exp5_1_20 PickupCode

P64100
EPM Default Value: __exp521type__
Description: Exp5_2_1 KeyType

P64101
EPM Default Value: __exp521value__
Description: Exp5_2_1 Value

P64102
EPM Default Value: __exp521label__
Description: Exp5_2_1 Label

P64103
EPM Default Value: __exp521acct__
Description: Exp5_2_1 Account

P64104
EPM Default Value: __exp521pu__
Description: Exp5_2_1 PickupCode

P64105
EPM Default Value: __exp522type__
Description: Exp5_2_2 KeyType

P64106
EPM Default Value: __exp522value__
Description: Exp5_2_2 Value

P64107
EPM Default Value: __exp522label__
Description: Exp5_2_2 Label

P64108
EPM Default Value: __exp522acct__
Description: Exp5_2_2 Account

P64109
EPM Default Value: __exp522pu__
Description: Exp5_2_2 PickupCode

P64110
EPM Default Value: __exp523type__
Description: Exp5_2_3 KeyType

P64111
EPM Default Value: __exp523value__
Description: Exp5_2_3 Value

P64112
EPM Default Value: __exp523label__
Description: Exp5_2_3 Label

P64113
EPM Default Value: __exp523acct__
Description: Exp5_2_3 Account

P64114
EPM Default Value: __exp523pu__
Description: Exp5_2_3 PickupCode

P64115
EPM Default Value: __exp524type__
Description: Exp5_2_4 KeyType

P64116
EPM Default Value: __exp524value__
Description: Exp5_2_4 Value

P64117
EPM Default Value: __exp524label__
Description: Exp5_2_4 Label

P64118
EPM Default Value: __exp524acct__
Description: Exp5_2_4 Account

P64119
EPM Default Value: __exp524pu__
Description: Exp5_2_4 PickupCode

P64120
EPM Default Value: __exp525type__
Description: Exp5_2_5 KeyType

P64121
EPM Default Value: __exp525value__
Description: Exp5_2_5 Value

P64122
EPM Default Value: __exp525label__
Description: Exp5_2_5 Label

P64123
EPM Default Value: __exp525acct__
Description: Exp5_2_5 Account

P64124
EPM Default Value: __exp525pu__
Description: Exp5_2_5 PickupCode

P64125
EPM Default Value: __exp526type__
Description: Exp5_2_6 KeyType

P64126
EPM Default Value: __exp526value__
Description: Exp5_2_6 Value

P64127
EPM Default Value: __exp526label__
Description: Exp5_2_6 Label

P64128
EPM Default Value: __exp526acct__
Description: Exp5_2_6 Account

P64129
EPM Default Value: __exp526pu__
Description: Exp5_2_6 PickupCode

P64130
EPM Default Value: __exp527type__
Description: Exp5_2_7 KeyType

P64131
EPM Default Value: __exp527value__
Description: Exp5_2_7 Value

P64132
EPM Default Value: __exp527label__
Description: Exp5_2_7 Label

P64133
EPM Default Value: __exp527acct__
Description: Exp5_2_7 Account

P64134
EPM Default Value: __exp527pu__
Description: Exp5_2_7 PickupCode

P64135
EPM Default Value: __exp528type__
Description: Exp5_2_8 KeyType

P64136
EPM Default Value: __exp528value__
Description: Exp5_2_8 Value

P64137
EPM Default Value: __exp528label__
Description: Exp5_2_8 Label

P64138
EPM Default Value: __exp528acct__
Description: Exp5_2_8 Account

P64139
EPM Default Value: __exp528pu__
Description: Exp5_2_8 PickupCode

P64140
EPM Default Value: __exp529type__
Description: Exp5_2_9 KeyType

P64141
EPM Default Value: __exp529value__
Description: Exp5_2_9 Value

P64142
EPM Default Value: __exp529label__
Description: Exp5_2_9 Label

P64143
EPM Default Value: __exp529acct__
Description: Exp5_2_9 Account

P64144
EPM Default Value: __exp529pu__
Description: Exp5_2_9 PickupCode

P64145
EPM Default Value: __exp530type__
Description: Exp5_2_10 KeyType

P64146
EPM Default Value: __exp530value__
Description: Exp5_2_10 Value

P64147
EPM Default Value: __exp530label__
Description: Exp5_2_10 Label

P64148
EPM Default Value: __exp530acct__
Description: Exp5_2_10 Account

P64149
EPM Default Value: __exp530pu__
Description: Exp5_2_10 PickupCode

P64150
EPM Default Value: __exp531type__
Description: Exp5_2_11 KeyType

P64151
EPM Default Value: __exp531value__
Description: Exp5_2_11 Value

P64152
EPM Default Value: __exp531label__
Description: Exp5_2_11 Label

P64153
EPM Default Value: __exp531acct__
Description: Exp5_2_11 Account

P64154
EPM Default Value: __exp531pu__
Description: Exp5_2_11 PickupCode

P64155
EPM Default Value: __exp532type__
Description: Exp5_2_12 KeyType

P64156
EPM Default Value: __exp532value__
Description: Exp5_2_12 Value

P64157
EPM Default Value: __exp532label__
Description: Exp5_2_12 Label

P64158
EPM Default Value: __exp532acct__
Description: Exp5_2_12 Account

P64159
EPM Default Value: __exp532pu__
Description: Exp5_2_12 PickupCode

P64160
EPM Default Value: __exp533type__
Description: Exp5_2_13 KeyType

P64161
EPM Default Value: __exp533value__
Description: Exp5_2_13 Value

P64162
EPM Default Value: __exp533label__
Description: Exp5_2_13 Label

P64163
EPM Default Value: __exp533acct__
Description: Exp5_2_13 Account

P64164
EPM Default Value: __exp533pu__
Description: Exp5_2_13 PickupCode

P64165
EPM Default Value: __exp534type__
Description: Exp5_2_14 KeyType

P64166
EPM Default Value: __exp534value__
Description: Exp5_2_14 Value

P64167
EPM Default Value: __exp534label__
Description: Exp5_2_14 Label

P64168
EPM Default Value: __exp534acct__
Description: Exp5_2_14 Account

P64169
EPM Default Value: __exp534pu__
Description: Exp5_2_14 PickupCode

P64170
EPM Default Value: __exp535type__
Description: Exp5_2_15 KeyType

P64171
EPM Default Value: __exp535value__
Description: Exp5_2_15 Value

P64172
EPM Default Value: __exp535label__
Description: Exp5_2_15 Label

P64173
EPM Default Value: __exp535acct__
Description: Exp5_2_15 Account

P64174
EPM Default Value: __exp535pu__
Description: Exp5_2_15 PickupCode

P64175
EPM Default Value: __exp536type__
Description: Exp5_2_16 KeyType

P64176
EPM Default Value: __exp536value__
Description: Exp5_2_16 Value

P64177
EPM Default Value: __exp536label__
Description: Exp5_2_16 Label

P64178
EPM Default Value: __exp536acct__
Description: Exp5_2_16 Account

P64179
EPM Default Value: __exp536pu__
Description: Exp5_2_16 PickupCode

P64180
EPM Default Value: __exp537type__
Description: Exp5_2_17 KeyType

P64181
EPM Default Value: __exp537value__
Description: Exp5_2_17 Value

P64182
EPM Default Value: __exp537label__
Description: Exp5_2_17 Label

P64183
EPM Default Value: __exp537acct__
Description: Exp5_2_17 Account

P64184
EPM Default Value: __exp537pu__
Description: Exp5_2_17 PickupCode

P64185
EPM Default Value: __exp538type__
Description: Exp5_2_18 KeyType

P64186
EPM Default Value: __exp538value__
Description: Exp5_2_18 Value

P64187
EPM Default Value: __exp538label__
Description: Exp5_2_18 Label

P64188
EPM Default Value: __exp538acct__
Description: Exp5_2_18 Account

P64189
EPM Default Value: __exp538pu__
Description: Exp5_2_18 PickupCode

P64190
EPM Default Value: __exp539type__
Description: Exp5_2_19 KeyType

P64191
EPM Default Value: __exp539value__
Description: Exp5_2_19 Value

P64192
EPM Default Value: __exp539label__
Description: Exp5_2_19 Label

P64193
EPM Default Value: __exp539acct__
Description: Exp5_2_19 Account

P64194
EPM Default Value: __exp539pu__
Description: Exp5_2_19 PickupCode

P64195
EPM Default Value: __exp540type__
Description: Exp5_2_20 KeyType

P64196
EPM Default Value: __exp540value__
Description: Exp5_2_20 Value

P64197
EPM Default Value: __exp540label__
Description: Exp5_2_20 Label

P64198
EPM Default Value: __exp540acct__
Description: Exp5_2_20 Account

P64199
EPM Default Value: __exp540pu__
Description: Exp5_2_20 PickupCode

P65000
EPM Default Value: __exp61type__
Description: Exp6_1_1 KeyType

P65001
EPM Default Value: __exp61value__
Description: Exp6_1_1 Value

P65002
EPM Default Value: __exp61label__
Description: Exp6_1_1 Label

P65003
EPM Default Value: __exp61acct__
Description: Exp6_1_1 Account

P65004
EPM Default Value: __exp61pu__
Description: Exp6_1_1 PickupCode

P65005
EPM Default Value: __exp62type__
Description: Exp6_1_2 KeyType

P65006
EPM Default Value: __exp62value__
Description: Exp6_1_2 Value

P65007
EPM Default Value: __exp62label__
Description: Exp6_1_2 Label

P65008
EPM Default Value: __exp62acct__
Description: Exp6_1_2 Account

P65009
EPM Default Value: __exp62pu__
Description: Exp6_1_2 PickupCode

P65010
EPM Default Value: __exp63type__
Description: Exp6_1_3 KeyType

P65011
EPM Default Value: __exp63value__
Description: Exp6_1_3 Value

P65012
EPM Default Value: __exp63label__
Description: Exp6_1_3 Label

P65013
EPM Default Value: __exp63acct__
Description: Exp6_1_3 Account

P65014
EPM Default Value: __exp63pu__
Description: Exp6_1_3 PickupCode

P65015
EPM Default Value: __exp64type__
Description: Exp6_1_4 KeyType

P65016
EPM Default Value: __exp64value__
Description: Exp6_1_4 Value

P65017
EPM Default Value: __exp64label__
Description: Exp6_1_4 Label

P65018
EPM Default Value: __exp64acct__
Description: Exp6_1_4 Account

P65019
EPM Default Value: __exp64pu__
Description: Exp6_1_4 PickupCode

P65020
EPM Default Value: __exp65type__
Description: Exp6_1_5 KeyType

P65021
EPM Default Value: __exp65value__
Description: Exp6_1_5 Value

P65022
EPM Default Value: __exp65label__
Description: Exp6_1_5 Label

P65023
EPM Default Value: __exp65acct__
Description: Exp6_1_5 Account

P65024
EPM Default Value: __exp65pu__
Description: Exp6_1_5 PickupCode

P65025
EPM Default Value: __exp66type__
Description: Exp6_1_6 KeyType

P65026
EPM Default Value: __exp66value__
Description: Exp6_1_6 Value

P65027
EPM Default Value: __exp66label__
Description: Exp6_1_6 Label

P65028
EPM Default Value: __exp66acct__
Description: Exp6_1_6 Account

P65029
EPM Default Value: __exp66pu__
Description: Exp6_1_6 PickupCode

P65030
EPM Default Value: __exp67type__
Description: Exp6_1_7 KeyType

P65031
EPM Default Value: __exp67value__
Description: Exp6_1_7 Value

P65032
EPM Default Value: __exp67label__
Description: Exp6_1_7 Label

P65033
EPM Default Value: __exp67acct__
Description: Exp6_1_7 Account

P65034
EPM Default Value: __exp67pu__
Description: Exp6_1_7 PickupCode

P65035
EPM Default Value: __exp67type__
Description: Exp6_1_8 KeyType

P65036
EPM Default Value: __exp68value__
Description: Exp6_1_8 Value

P65037
EPM Default Value: __exp68label__
Description: Exp6_1_8 Label

P65038
EPM Default Value: __exp68acct__
Description: Exp6_1_8 Account

P65039
EPM Default Value: __exp68pu__
Description: Exp6_1_8 PickupCode

P65040
EPM Default Value: __exp69type__
Description: Exp6_1_9 KeyType

P65041
EPM Default Value: __exp69value__
Description: Exp6_1_9 Value

P65042
EPM Default Value: __exp69label__
Description: Exp6_1_9 Label

P65043
EPM Default Value: __exp69acct__
Description: Exp6_1_9 Account

P65044
EPM Default Value: __exp69pu__
Description: Exp6_1_9 PickupCode

P65045
EPM Default Value: __exp610type__
Description: Exp6_1_10 KeyType

P65046
EPM Default Value: __exp610value__
Description: Exp6_1_10 Value

P65047
EPM Default Value: __exp610label__
Description: Exp6_1_10 Label

P65048
EPM Default Value: __exp610acct__
Description: Exp6_1_10 Account

P65049
EPM Default Value: __exp610pu__
Description: Exp6_1_10 PickupCode

P65050
EPM Default Value: __exp611type__
Description: Exp6_1_11 KeyType

P65051
EPM Default Value: __exp611value__
Description: Exp6_1_11 Value

P65052
EPM Default Value: __exp611label__
Description: Exp6_1_11 Label

P65053
EPM Default Value: __exp611acct__
Description: Exp6_1_11 Account

P65054
EPM Default Value: __exp611pu__
Description: Exp6_1_11 PickupCode

P65055
EPM Default Value: __exp612type__
Description: Exp6_1_12 KeyType

P65056
EPM Default Value: __exp612value__
Description: Exp6_1_12 Value

P65057
EPM Default Value: __exp612label__
Description: Exp6_1_12 Label

P65058
EPM Default Value: __exp612acct__
Description: Exp6_1_12 Account

P65059
EPM Default Value: __exp612pu__
Description: Exp6_1_12 PickupCode

P65060
EPM Default Value: __exp613type__
Description: Exp6_1_13 KeyType

P65061
EPM Default Value: __exp613value__
Description: Exp6_1_13 Value

P65062
EPM Default Value: __exp613label__
Description: Exp6_1_13 Label

P65063
EPM Default Value: __exp613acct__
Description: Exp6_1_13 Account

P65064
EPM Default Value: __exp613pu__
Description: Exp6_1_13 PickupCode

P65065
EPM Default Value: __exp614type__
Description: Exp6_1_14 KeyType

P65066
EPM Default Value: __exp614value__
Description: Exp6_1_14 Value

P65067
EPM Default Value: __exp614label__
Description: Exp6_1_14 Label

P65068
EPM Default Value: __exp614acct__
Description: Exp6_1_14 Account

P65069
EPM Default Value: __exp614pu__
Description: Exp6_1_14 PickupCode

P65070
EPM Default Value: __exp615type__
Description: Exp6_1_15 KeyType

P65071
EPM Default Value: __exp615value__
Description: Exp6_1_15 Value

P65072
EPM Default Value: __exp615label__
Description: Exp6_1_15 Label

P65073
EPM Default Value: __exp615acct__
Description: Exp6_1_15 Account

P65074
EPM Default Value: __exp615pu__
Description: Exp6_1_15 PickupCode

P65075
EPM Default Value: __exp616type__
Description: Exp6_1_16 KeyType

P65076
EPM Default Value: __exp616value__
Description: Exp6_1_16 Value

P65077
EPM Default Value: __exp616label__
Description: Exp6_1_16 Label

P65078
EPM Default Value: __exp616acct__
Description: Exp6_1_16 Account

P65079
EPM Default Value: __exp616pu__
Description: Exp6_1_16 PickupCode

P65080
EPM Default Value: __exp617type__
Description: Exp6_1_17 KeyType

P65081
EPM Default Value: __exp617value__
Description: Exp6_1_17 Value

P65082
EPM Default Value: __exp617label__
Description: Exp6_1_17 Label

P65083
EPM Default Value: __exp617acct__
Description: Exp6_1_17 Account

P65084
EPM Default Value: __exp617pu__
Description: Exp6_1_17 PickupCode

P65085
EPM Default Value: __exp618type__
Description: Exp6_1_18 KeyType

P65086
EPM Default Value: __exp618value__
Description: Exp6_1_18 Value

P65087
EPM Default Value: __exp618label__
Description: Exp6_1_18 Label

P65088
EPM Default Value: __exp618acct__
Description: Exp6_1_18 Account

P65089
EPM Default Value: __exp618pu__
Description: Exp6_1_18 PickupCode

P65090
EPM Default Value: __exp619type__
Description: Exp6_1_19 KeyType

P65091
EPM Default Value: __exp619value__
Description: Exp6_1_19 Value

P65092
EPM Default Value: __exp619label__
Description: Exp6_1_19 Label

P65093
EPM Default Value: __exp619acct__
Description: Exp6_1_19 Account

P65094
EPM Default Value: __exp619pu__
Description: Exp6_1_19 PickupCode

P65095
EPM Default Value: __exp620type__
Description: Exp6_1_20 KeyType

P65096
EPM Default Value: __exp620value__
Description: Exp6_1_20 Value

P65097
EPM Default Value: __exp620label__
Description: Exp6_1_20 Label

P65098
EPM Default Value: __exp620acct__
Description: Exp6_1_20 Account

P65099
EPM Default Value: __exp620pu__
Description: Exp6_1_20 PickupCode

P65100
EPM Default Value: __exp621type__
Description: Exp6_2_1 KeyType

P65101
EPM Default Value: __exp621value__
Description: Exp6_2_1 Value

P65102
EPM Default Value: __exp621label__
Description: Exp6_2_1 Label

P65103
EPM Default Value: __exp621acct__
Description: Exp6_2_1 Account

P65104
EPM Default Value: __exp621pu__
Description: Exp6_2_1 PickupCode

P65105
EPM Default Value: __exp622type__
Description: Exp6_2_2 KeyType

P65106
EPM Default Value: __exp622value__
Description: Exp6_2_2 Value

P65107
EPM Default Value: __exp622label__
Description: Exp6_2_2 Label

P65108
EPM Default Value: __exp622acct__
Description: Exp6_2_2 Account

P65109
EPM Default Value: __exp622pu__
Description: Exp6_2_2 PickupCode

P65110
EPM Default Value: __exp623type__
Description: Exp6_2_3 KeyType

P65111
EPM Default Value: __exp623value__
Description: Exp6_2_3 Value

P65112
EPM Default Value: __exp623label__
Description: Exp6_2_3 Label

P65113
EPM Default Value: __exp623acct__
Description: Exp6_2_3 Account

P65114
EPM Default Value: __exp623pu__
Description: Exp6_2_3 PickupCode

P65115
EPM Default Value: __exp624type__
Description: Exp6_2_4 KeyType

P65116
EPM Default Value: __exp624value__
Description: Exp6_2_4 Value

P65117
EPM Default Value: __exp624label__
Description: Exp6_2_4 Label

P65118
EPM Default Value: __exp624acct__
Description: Exp6_2_4 Account

P65119
EPM Default Value: __exp624pu__
Description: Exp6_2_4 PickupCode

P65120
EPM Default Value: __exp625type__
Description: Exp6_2_5 KeyType

P65121
EPM Default Value: __exp625value__
Description: Exp6_2_5 Value

P65122
EPM Default Value: __exp625label__
Description: Exp6_2_5 Label

P65123
EPM Default Value: __exp625acct__
Description: Exp6_2_5 Account

P65124
EPM Default Value: __exp625pu__
Description: Exp6_2_5 PickupCode

P65125
EPM Default Value: __exp626type__
Description: Exp6_2_6 KeyType

P65126
EPM Default Value: __exp626value__
Description: Exp6_2_6 Value

P65127
EPM Default Value: __exp626label__
Description: Exp6_2_6 Label

P65128
EPM Default Value: __exp626acct__
Description: Exp6_2_6 Account

P65129
EPM Default Value: __exp626pu__
Description: Exp6_2_6 PickupCode

P65130
EPM Default Value: __exp627type__
Description: Exp6_2_7 KeyType

P65131
EPM Default Value: __exp627value__
Description: Exp6_2_7 Value

P65132
EPM Default Value: __exp627label__
Description: Exp6_2_7 Label

P65133
EPM Default Value: __exp627acct__
Description: Exp6_2_7 Account

P65134
EPM Default Value: __exp627pu__
Description: Exp6_2_7 PickupCode

P65135
EPM Default Value: __exp628type__
Description: Exp6_2_8 KeyType

P65136
EPM Default Value: __exp628value__
Description: Exp6_2_8 Value

P65137
EPM Default Value: __exp628label__
Description: Exp6_2_8 Label

P65138
EPM Default Value: __exp628acct__
Description: Exp6_2_8 Account

P65139
EPM Default Value: __exp628pu__
Description: Exp6_2_8 PickupCode

P65140
EPM Default Value: __exp629type__
Description: Exp6_2_9 KeyType

P65141
EPM Default Value: __exp629value__
Description: Exp6_2_9 Value

P65142
EPM Default Value: __exp629label__
Description: Exp6_2_9 Label

P65143
EPM Default Value: __exp629acct__
Description: Exp6_2_9 Account

P65144
EPM Default Value: __exp629pu__
Description: Exp6_2_9 PickupCode

P65145
EPM Default Value: __exp630type__
Description: Exp6_2_10 KeyType

P65146
EPM Default Value: __exp630value__
Description: Exp6_2_10 Value

P65147
EPM Default Value: __exp630label__
Description: Exp6_2_10 Label

P65148
EPM Default Value: __exp630acct__
Description: Exp6_2_10 Account

P65149
EPM Default Value: __exp630pu__
Description: Exp6_2_10 PickupCode

P65150
EPM Default Value: __exp631type__
Description: Exp6_2_11 KeyType

P65151
EPM Default Value: __exp631value__
Description: Exp6_2_11 Value

P65152
EPM Default Value: __exp631label__
Description: Exp6_2_11 Label

P65153
EPM Default Value: __exp631acct__
Description: Exp6_2_11 Account

P65154
EPM Default Value: __exp631pu__
Description: Exp6_2_11 PickupCode

P65155
EPM Default Value: __exp632type__
Description: Exp6_2_12 KeyType

P65156
EPM Default Value: __exp632value__
Description: Exp6_2_12 Value

P65157
EPM Default Value: __exp632label__
Description: Exp6_2_12 Label

P65158
EPM Default Value: __exp632acct__
Description: Exp6_2_12 Account

P65159
EPM Default Value: __exp632pu__
Description: Exp6_2_12 PickupCode

P65160
EPM Default Value: __exp633type__
Description: Exp6_2_13 KeyType

P65161
EPM Default Value: __exp633value__
Description: Exp6_2_13 Value

P65162
EPM Default Value: __exp633label__
Description: Exp6_2_13 Label

P65163
EPM Default Value: __exp633acct__
Description: Exp6_2_13 Account

P65164
EPM Default Value: __exp633pu__
Description: Exp6_2_13 PickupCode

P65165
EPM Default Value: __exp634type__
Description: Exp6_2_14 KeyType

P65166
EPM Default Value: __exp634value__
Description: Exp6_2_14 Value

P65167
EPM Default Value: __exp634label__
Description: Exp6_2_14 Label

P65168
EPM Default Value: __exp634acct__
Description: Exp6_2_14 Account

P65169
EPM Default Value: __exp634pu__
Description: Exp6_2_14 PickupCode

P65170
EPM Default Value: __exp635type__
Description: Exp6_2_15 KeyType

P65171
EPM Default Value: __exp635value__
Description: Exp6_2_15 Value

P65172
EPM Default Value: __exp635label__
Description: Exp6_2_15 Label

P65173
EPM Default Value: __exp635acct__
Description: Exp6_2_15 Account

P65174
EPM Default Value: __exp635pu__
Description: Exp6_2_15 PickupCode

P65175
EPM Default Value: __exp636type__
Description: Exp6_2_16 KeyType

P65176
EPM Default Value: __exp636value__
Description: Exp6_2_16 Value

P65177
EPM Default Value: __exp636label__
Description: Exp6_2_16 Label

P65178
EPM Default Value: __exp636acct__
Description: Exp6_2_16 Account

P65179
EPM Default Value: __exp636pu__
Description: Exp6_2_16 PickupCode

P65180
EPM Default Value: __exp637type__
Description: Exp6_2_17 KeyType

P65181
EPM Default Value: __exp637value__
Description: Exp6_2_17 Value

P65182
EPM Default Value: __exp637label__
Description: Exp6_2_17 Label

P65183
EPM Default Value: __exp637acct__
Description: Exp6_2_17 Account

P65184
EPM Default Value: __exp637pu__
Description: Exp6_2_17 PickupCode

P65185
EPM Default Value: __exp638type__
Description: Exp6_2_18 KeyType

P65186
EPM Default Value: __exp638value__
Description: Exp6_2_18 Value

P65187
EPM Default Value: __exp638label__
Description: Exp6_2_18 Label

P65188
EPM Default Value: __exp638acct__
Description: Exp6_2_18 Account

P65189
EPM Default Value: __exp638pu__
Description: Exp6_2_18 PickupCode

P65190
EPM Default Value: __exp639type__
Description: Exp6_2_19 KeyType

P65191
EPM Default Value: __exp639value__
Description: Exp6_2_19 Value

P65192
EPM Default Value: __exp639label__
Description: Exp6_2_19 Label

P65193
EPM Default Value: __exp639acct__
Description: Exp6_2_19 Account

P65194
EPM Default Value: __exp639pu__
Description: Exp6_2_19 PickupCode

P65195
EPM Default Value: __exp640type__
Description: Exp6_2_20 KeyType

P65196
EPM Default Value: __exp640value__
Description: Exp6_2_20 Value

P65197
EPM Default Value: __exp640label__
Description: Exp6_2_20 Label

P65198
EPM Default Value: __exp640acct__
Description: Exp6_2_20 Account

P65199
EPM Default Value: __exp640pu__
Description: Exp6_2_20 PickupCode

P20479
EPM Default Value: __labelWidth__
Description: Wide labels

P23280
EPM Default Value: __contactPhoto__
Description: Contact Images Path

P23283
EPM Default Value: __failoverXML__
Description: Failover XML Browser Server

P23284
EPM Default Value:
Description: Second Failover XML Browser Server

P23290
EPM Default Value: __failoverVPN__
Description: Failover VPN configuration address

P23289
EPM Default Value: __browserNote__
Description: Xml Browser Note Popup

P8678
EPM Default Value: __fontSize__
Description: Font size for phone and expansion modules

P23351
EPM Default Value: __sunStart__
Description: Sunday Start Time

P23352
EPM Default Value: __sunEnd__
Description: Sunday End Time

P23353
EPM Default Value: __monStart__
Description: Monday Start Time

P23354
EPM Default Value: __monEnd__
Description: Monday End Time

P23355
EPM Default Value: __tueStart__
Description: Tuesday Start Time

P23356

EPM Default Value: __tueEnd__

Description: Tuesday End Time

P23357

EPM Default Value: __wedStart__

Description: Wednesday Start Time

P23358

EPM Default Value: __wedEnd__

Description: Wednesday End Time

P23359

EPM Default Value: __thrStart__

Description: Thursday Start Time

P23360

EPM Default Value: __thrEnd__

Description: Thursday End Time

P23361

EPM Default Value: __friStart__

Description: Friday Start Time

P23362

EPM Default Value: __friEnd__

Description: Friday End Time

P23363

EPM Default Value: __satStart__

Description: Saturday Start Time

P23364

EPM Default Value: __satEnd__

Description: Saturday End Time

P23291

EPM Default Value: __callHistory__

Description: Flush call history 1 - Yes;0 - No

P23365

EPM Default Value:

Description: Log On (This message will be sent out when phone apps log on.)

P23366

EPM Default Value:

Description: Log Off (This message will be sent out when phone apps log off.)

P23367

EPM Default Value: __explImagePath__

Description: Expansion Module Contact Images Path

P23204

EPM Default Value: __holdTone__

Description: Hold Tone 1 - Yes, 0 - No

P23205

EPM Default Value: __holdToneDelay__

Description: Hold Tone Delay (Number of seconds between tones)

P23292

EPM Default Value: __phoneLabel__

Description: Toolbar Label

P23388

EPM Default Value: __sipKeepAliveMode__

Description: SIP KeepAlive Mode 0 - Disable, 1 - SIP OPTION

P23382

EPM Default Value: 15

Description: SIP KeepAlive Interval

P23500
EPM Default Value: 0
Description: PC Port Mirroring

P24001
EPM Default Value: 0
Description: PC Port Active 0 - Enable, 1 - Disable

P23400
EPM Default Value: 1
Description: Auto Answer Alert 0 - Disable, 1 - Enable

P24887
EPM Default Value: 0
Description: Call Pickup, Send Pickup Code on Refer 0 - Disable, 1 - Enable. Phone default is 1.

P24792
EPM Default Value: 0
Description: If enabled, causes incoming Intercom calls to be put to the loudspeaker, rather than the headset, if the phone is otherwise configured for headset mode. Defaults to 0. To enable, set to 1.

P23406
EPM Default Value: 0
Description: If enabled, while the phone is in the ringing state due to an inbound call, and the user presses a BLF or speed dial button, the phone will generate a new call to the BLF or speed dial. If disabled, the phone will blind transfer the incoming call to the BLF or speed dial destination. Defaults to 0. To enable, set to 1.

P24972
EPM Default Value: 0
Description: If enabled, the phone, if on non-primary pages of BLF keys, will return to the primary page following a timeout set by this option. The timeout is in seconds and is from 1-120. Defaults to 0 (disabled). Added in x.0.4.77.

P24953
EPM Default Value: 0
Description: If enabled, only send pickup prefix codes on BLF keypress while the phone is idle. If disabled, send always. Defaults to 0. To enable, set to 1. Added in x.0.4.76.